



User's Guide



PREFACE

Every effort has been made to ensure that the information in this document is complete, accurate, and up-to-date. Oki Printing Solutions assumes no responsibility for the results of errors beyond its control. Oki Printing Solutions also cannot guarantee that changes in software and equipment made by other manufacturers and referred to in this guide will not affect the applicability of the information in it. Mention of software products manufactured by other companies does not necessarily constitute endorsement by Oki Printing Solutions.

While all reasonable efforts have been made to make this document as accurate and helpful as possible, we make no warranty of any kind, expressed or implied, as to the accuracy or completeness of the information contained herein.

The most up-to-date drivers and manuals are available from the Oki Printing Solutions web site:

<http://www.okiprintingsolutions.com>

Copyright © Oki Data Corporation. All rights reserved.

OKI is a registered trademark of Oki Electric Industry Co., Ltd.

Microline is a trademark of Oki Data Corporation.

ENERGY STAR is a trademark of the United States Environmental Protection Agency.

Microsoft, MS-DOS and Windows are registered trademarks of Microsoft Corporation.

Other product names and brand names are registered trademarks or trademarks of their proprietors.



As an ENERGY STAR Program Participant, the manufacturer has determined that this product meets the ENERGY STAR guidelines for energy efficiency.



This product complies with the requirements of the Council Directives 2004/108/EC(EMC), 2006/95/EC(LVD) and 2011/65/EU(ROHS) as amended where applicable, on the approximation of the laws of the member states relating to electromagnetic compatibility, low voltage and restriction of hazardous substances.



CONTENTS

Preface	2
Notes, cautions and warnings.	5
Introduction	6
About this guide	6
On-line usage	7
Printing pages	7
Getting started	9
Retaining packing materials	9
Identifying component parts	9
Front view	9
Rear view	11
Locating your printer	12
Powering on your printer	12
Producing a test print	14
Connecting to a computer	15
Interfaces	15
Interconnection	15
Installing the printer driver	16
Printing a test page	16
Printing from a computer	17
Paper handling	18
Loading cut sheet paper	18
Ejecting cut sheet paper	20
Loading continuous forms	21
Setting up continuous forms	21
Feeding continuous forms (rear feed)	21
Feeding continuous forms (bottom feed)	25
Tearing off continuous forms	36
Aligning the tear-off perforations	36
Removing continuous forms	37
Setting the paper thickness lever	40
Operating instructions	42
Control panel	42
ML1120 eco	42
ML1190 eco	44
Buttons	46
Change print mode	48
ML1120 eco	48
ML1190 eco	50

Setting menu values	52
Confirming current settings	53
Menu setting	53
Menu items and settings	55
ML1120 eco	55
ML1190 eco	67
Initialising menu settings	78
Adjusting TOF position	79
Printer speed settings	80
Printer impact mode	80
Normal speed printing	80
High speed printing	80
Quiet printing	80
Setting TOF position at the place of user's choice	81
Troubleshooting	82
Clearing paper jams	82
Cut sheet paper jammed in printer	82
Continuous forms jammed in printer	84
Responding to alarm conditions	86
Responding to general problems	87
Cleaning your printer	93
Printer exterior	93
Printer interior	93
Consumables and accessories	95
Consumables	95
Changing a ribbon cartridge	95
Consumable order information	98
Specifications	99
ML1120 eco	99
ML1190eco	102
Index	104
Oki contact details	105

NOTES, CAUTIONS AND WARNINGS

NOTE

A note provides additional information to supplement the main text.

CAUTION!

A caution provides additional information which, if ignored, may result in equipment malfunction or damage.

WARNING!

A warning provides additional information which, if ignored, may result in a risk of personal injury.

INTRODUCTION

Congratulations on purchasing this Oki Printing Solutions printer!

The ML1120 eco (9-pin) and ML1190 eco (24-pin) are designed to provide highly reliable letter quality printing and high resolution graphics for the desktop/office printing environment. Both models combine state-of-the-art serial impact dot matrix printing technology with advanced materials and superior construction to provide high performance and versatility in a desktop sized unit. Careful attention to ergonomics and application needs provides user friendly operation for operators of varying technical capabilities.

ABOUT THIS GUIDE

NOTE

Images used in this manual may include optional features that your printer does not have installed.

This manual is your user's guide (check the web site, www.okiprintingsolutions.com, for the most up-to-date version) for your printer and forms part of the overall user support listed below:

- > **Installation Safety booklet:** to provide information for safe use of the printer.

This is a paper document that is packaged with the printer and should be read before setting up your printer.
- > **Set-up guide:** to describe how to unpack, connect and turn on your printer.

This is a paper document that is packaged with the printer.
- > This **User's Guide:** to help you to become familiar with your printer and make the best use of its many features. Also included are guidelines for troubleshooting and maintenance to ensure that it performs at its best. Additionally, information is provided for adding optional accessories as your printing needs evolve.

This is an electronic document stored on the manuals CD.

- > **Technical Reference Guide:** to provide detailed technical information for programmers and more technical users.

This is an electronic document available on the web site www.okiprintingsolutions.com.

- > **Installation Guides:** accompany consumable items and optional accessories to describe how to install them.

These are paper documents that are packaged with the consumables and optional accessories.

- > **On-line Help:** on-line information accessible from the printer driver and utility software.

ON-LINE USAGE

This guide is intended to be read on screen using an Adobe Acrobat Reader. Use the navigation and viewing tools provided in Acrobat.

You can access specific information in two ways:


- > In the list of bookmarks down the left hand side of your screen, click on the topic of interest to jump to the required topic. (If the bookmarks are not available, use the ["Contents" on page 3.](#))
- > In the list of bookmarks, click on Index to jump to the Index. (If the bookmarks are not available, use the ["Contents" on page 3.](#)) Find the term of interest in the alphabetically arranged index and click on the associated page number to jump to the page containing the term.

PRINTING PAGES

The whole manual, individual pages, or sections may be printed. The procedure is:

1. From the toolbar, select File > Print (or press the Ctrl + P keys).

- 2.** Choose which pages you wish to print:
- (a) [All pages], (1), for the entire manual.
 - (b) [Current page], (2), for the page at which you are looking.
 - (c) [Pages from] and [to], (3), for the range of pages you specify by entering their page numbers.



- (c) [Pages from] and [to], (3), for the range of pages you specify by entering their page numbers.
- 3.** Click on OK.

GETTING STARTED

WARNING!

If you have not already done so, familiarise yourself with the content of the Installation Safety booklet supplied with your printer.


RETAINING PACKING MATERIALS

After setting up your printer according to the instructions in the Set-up Guide, retain your packing materials and container in case you ever need to ship or transport your printer.

IDENTIFYING COMPONENT PARTS

The main parts of your printer are identified and briefly explained below.


FRONT VIEW




1. Print Head: prints the characters on the paper.
2. Paper Type Lever: set according to the type of paper used – cut sheet or continuous forms.

3. Platen Knob: turn to move or eject the paper.
4. Paper Thickness Lever: set according to the thickness of the paper. There is also a setting to facilitate ribbon replacement.
5. Control Panel: contains button switches and indicators (described in detail later) that allow you to operate the printer.

ML1120 eco




ML1190 eco




6. Power Switch: to turn the printer power ON/OFF.
7. Ribbon Cartridge: holds the printer ribbon.
8. Pull Up Roller Assembly: aids paper exit.
9. Pull Up Guide: prevents paper skew.

REAR VIEW




1. Input Tray: insert cut sheet paper for use by the printer (one sheet at a time).
2. Power connector: connect to printer power cable.
3. Paper Guides: can be adjusted as required to locate the left edge of cut sheet paper.
4. Pin Tractor: to load and feed continuous forms.
5. Rear Cover.



6. Serial connector: connect to serial interface cable.
7. USB connector: connect to USB interface cable.
8. Parallel connector: connect to parallel interface connector.

LOCATING YOUR PRINTER


- > Select a firm, solid, level surface on which to site your printer.
- > Allow enough space around your printer (e.g. at least 60 cm from any wall) for easy access to the Platen Knob and the various paper feed paths.




- > Make sure a grounded power outlet is available nearby.

POWERING ON YOUR PRINTER

1. Ensure that your printer Power Switch is set to OFF.



- 2.** Connect the power cable (1) to the power connector (2) on the printer.



- 3.** Connect the power cable to a 220/240 V AC power outlet and switch on the outlet power.
- 4.** Turn the printer Power Switch to ON.



- 5.** Check that the SEL and STATUS indicators on the control panel illuminate.

PRODUCING A TEST PRINT

To check that your printer is operational, produce a test print on a sheet of 80 gsm A4 paper (for example) as follows:

CAUTION!

Allow at least 5 seconds between turning the printer ON after turning it OFF. A shorter time interval between turning ON/OFF operations may cause printer power failure.

Do not turn the printer OFF while it is printing as this may result in damage to the print head.

1. Turn the printer Power Switch to OFF.
2. Set the Paper Type Lever to cut sheet.
3. Remove the Access Cover and set the Paper Thickness Lever to position 1.
4. Press and hold the LF/FF and the LOAD/EJECT buttons and turn the Power Switch to ON. The ALARM indicator should be illuminated to indicate that there is no paper in the printer.
5. With the long side of the paper against the paper guide, insert the paper carefully into the printer. The printer will automatically grip the paper and start the test print.

NOTE

If required, you can pause the test print by pressing the SEL button and then resume the test print by again pressing the SEL button.

-
6. When the test print has completed, the paper is automatically ejected.

NOTE

If you want to stop the test print for any reason, press the SEL button followed by the LOAD/EJECT button to eject the paper. Turn the printer Power Switch to OFF.

CONNECTING TO A COMPUTER

In this section you will interconnect your printer and computer, install the printer driver in your computer and print a test page.

INTERFACES

Your printer is equipped with three data interfaces:

CAUTION!

Do not use more than one of the following data interface methods to connect to your PC.

- > Parallel: for direct connection to a PC. This port requires a bi-directional (IEEE 1284 compliant) parallel cable.
- > Serial: for direct connection to a PC. This port requires a bi-directional RS232C serial interface cable.
- > USB: for connection to a PC running Windows 98 or above. This port requires a shielded cable less than 5m long conforming to USB version 2.0.


NOTE

Interface cables are not supplied with your printer.

INTERCONNECTION

1. Ensure that both printer and computer are turned OFF.
2. Connect the required interface cable, serial (1), USB (2), or parallel (3), to the printer and then to the computer.

Break off the tabs (4) to allow the cables to sit neatly underneath the printer.



3. Turn ON the printer.
4. Turn ON the computer.

INSTALLING THE PRINTER DRIVER

Insert the Drivers CD into your computer and follow the on-screen instructions to install the printer driver for use with your printer.

PRINTING A TEST PAGE

As an example, using Windows XP:

1. Use Start > Printers and Faxes to show the Printers and Faxes window.
2. Highlight the driver for your printer.
3. Use File > Properties to show the Properties window.
4. On the General tab, click the Print Test Page button.
5. Ensure that a test page has printed, verifying your printer – computer setup.

PRINTING FROM A COMPUTER

When printing to your printer from, for example, a Windows application on your computer, make your printing selections from the driver windows that appear on screen. These driver windows have been designed to be easy to use and intuitive while supplementary on-line help is available by clicking each window Help button.

PAPER HANDLING

This section describes how to use cut sheet paper and continuous forms in your printer.


LOADING CUT SHEET PAPER

1. Ensure that the printer is switched ON.


NOTE

If there are any continuous forms in the printer, eject them as described in "[Removing continuous forms](#)" on page 37.


2. Ensure that the Pin Tractor covers are closed to avoid the possibility of paper jams.




3. Ensure the Paper Type Lever (1) is set to Cut Sheet. 



4. Set the left paper margin by adjusting the Paper Guide (1). Position the edge of the Paper Guide (1) at the tip of the Printed Line Marker arrow (2) on the Paper Tray.



5. Remove the Access Cover and set the Paper Thickness Lever (1) to suit the paper. See ["Setting the paper thickness lever"](#) on page 40.




CAUTION!

If the Paper Thickness Lever setting does not match the paper being used, paper feeding and printing may not work properly.

6. With the printing side facing downwards and the left edge aligned with the Paper Guide (1), carefully insert the

paper on the Input Tray (2) into the printer until it is gripped.



NOTE

Ensure that the paper is accurately aligned along the Paper Guide to avoid the possibility of skew printing.

When printing an envelope, do not fold up the flap. A flap aligned along the Paper Guide can lead to skew printing.

EJECTING CUT SHEET PAPER

When the printer reaches the end of the cut sheet page it automatically ejects the page. If required, add another sheet for the printer to continue printing from where it left off.

To eject a cut sheet left in the printer, carry out the following:

- 1.** Press the SEL button to put the printer off-line.
- 2.** Press the LOAD/EJECT button and the paper is ejected to the Paper Tray.


NOTE

Paper longer than A4 length (297 mm) may overlap and possibly fall off the Paper Tray.

LOADING CONTINUOUS FORMS

SETTING UP CONTINUOUS FORMS

To avoid paper feeding problems, carry out the following:



1. Check your printer is on a surface approximately 75 cm above the floor.
2. Position the continuous forms supply directly below the printer, no more than 3 cm left or right of the printer paper path.
3. Ensure the rear of the printer is close to and parallel with the edge of the surface and at least 60 cm from any wall.

FEEDING CONTINUOUS FORMS (REAR FEED)


1. Ensure that the printer is turned ON.

NOTE

If there is a cut sheet in the printer, eject it as described in ["Ejecting cut sheet paper" on page 20](#).

2. Set the Paper Type Lever to Continuous Forms 


3. Remove the Access Cover and set the Paper Thickness Lever (1) to suit the paper. See ["Setting the paper thickness lever" on page 40.](#)




NOTE

If the Paper Thickness Lever setting does not match the paper being used, paper feeding and printing may not work properly.

4. Remove the Input Tray and Rear Cover together by gripping the Input Tray at both sides and pulling it up and away from the printer.




- 5.** Lift the locking lever (1) of the left Pin Tractor and slide the Pin Tractor as required to adjust the paper position.




Press the locking lever back down to lock the Pin Tractor in the desired position.

- 6.** Lift the locking lever (1) of the right Pin Tractor and slide the Pin Tractor to the required position to accommodate the width of the continuous forms to be used. Move the rear paper guide (2) to midway between the left (3) and right (4) Pin Tractors.




- 7.** Open the left and right Pin Tractor covers and feed the continuous forms in the direction of the arrows, locating the sprocket holes in the forms onto the sprocket pins.

Ensure that the forms are properly aligned on the sprocket pins, then close the Pin Tractor covers.




- 8.** Adjust the right Pin Tractor to accommodate the width of the continuous forms, taking care that the forms are held neither too loosely nor too tightly between the Pin Tractors. Press the locking lever down to lock the right Pin Tractor in the desired position.



- 9.** Replace the Input Tray and Rear Cover by fitting the Rear Cover into the grooves at the back of the printer and

pushing gently forward until the Input Tray clips into place.



10. Replace the Access Cover.
11. Press the LOAD/EJECT button. The continuous forms will be taken into the printer and positioned at the first line print position.


FEEDING CONTINUOUS FORMS (BOTTOM FEED)

NOTE


If there is a cut sheet in the printer, eject it as described in ["Ejecting cut sheet paper" on page 20](#).

Moving tractor assembly

1. Ensure that the printer is switched OFF.




2. Disconnect the power cord.
3. Remove the Access Cover.




WARNING!

Be careful as the printhead may be hot after operation. Allow it to cool before touching it.


4. Move the printhead assembly to the left.




5. Push up the Pull Up Roller Assembly with the thumbs and release one side. Then, release the other side and remove the Pull Up Roller Assembly. The Pull Up Guide may become detached.




6. If necessary, replace the Pull Up Guide.
7. Turn the printer, so that the back of the printer is facing you.




- 8.** Remove the Input Tray and Rear Cover together by gripping the Input Tray at both sides and pulling it back and up from the printer.




- 9.** Remove the tractor assembly. Squeeze the handles to release the clamps on both sides. Continue to squeeze and rotate and lift the assembly out of the printer.




- 10.** Position the tractor assembly as shown. The gear assembly is on the left.




- 11.** Locate the arms over the pivot points and rotate the unit backwards until the clamps close over the back pins.
- 12.** Turn the printer so that the front of the printer is facing you.




- 13.** Turn the Platen Knob. If the tractor assembly is correctly installed, the gear will turn. If the gear does not turn as you turn the Platen Knob, repeat steps 10 to 12.



- 14.** Replace the Input Tray and Rear Cover by fitting the Rear Cover into the grooves at the back of the printer and pulling gently forward until the Input Tray clips into place.




- 15.** Replace the Access Cover.




Loading continuous forms (bottom feed)


- 1.** Ensure the printer is turned off.




- 2.** Remove the Access Cover.



- 3.** Set the Paper Type Lever to Continuous Forms 




- 4.** Place the stack of continuous forms paper below the printer. Bring the paper up through the slot in the base of the printer.




- 5.** Lift the locking lever (1) of the left Pin Tractor and slide the Pin Tractor as required (2) to adjust the paper position


then press the locking lever (3) back down to lock the Pin Tractor in the desired position.




- 6.** Lift the locking lever (1) of the right Pin Tractor and slide the Pin Tractor to the required position (2) to accommodate the width of the continuous forms to be used. Move the rear paper guide (3) to midway between the left and right Pin Tractors.



- 7.** Open the left and right Pin Tractor covers (1) and feed the continuous forms (2) in the direction of the arrow, locating the sprocket holes in the forms onto the sprocket pins.




- 8.** Ensure that the forms are properly aligned on the sprocket pins, then close the Pin Tractor covers.




- 9.** Adjust the right Pin Tractor (1) to accommodate the width of the continuous forms, taking care that the forms are held neither too loosely nor too tightly between the Pin

Tractors. Press the locking lever down (2) to lock the right Pin Tractor in the desired position.



10. Replace the Access Cover.

11. Turn ON the printer.



TEARING OFF CONTINUOUS FORMS


- 1.** With the SEL indicator illuminated, press and hold the LF/FF button to move the continuous form to the next page.
- 2.** Press TEAR to align the tear-off perforations on the form with the paper cutter on the printer.
- 3.** Carefully tear off the forms along the tear-off perforations using the paper cutter as a guide. Using excessive force may result in tearing at a position other than the tear-off perforations.
- 4.** Press the TEAR button to reposition the continuous forms in the printer back to the first line print position.

ALIGNING THE TEAR-OFF PERFORATIONS

If the tear-off perforations are not aligned with the paper cutter, align them as follows:

- 1.** Remove the Access Cover of your printer.
- 2.** With the SEL indicator illuminated, press and hold the TEAR button to move the tear-off perforations to the paper cutter.

3. Check the position of the tear-off perforations (1) relative to the paper cutter (2).



- (a) To advance the forms, continue to hold down the TEAR button and then the SEL button.
- (b) To retract the forms, continue to hold down the TEAR button and the LF/FF button.

NOTE

If the specified correction range is more than ± 3.53 mm (20/144 in) for ML1120 eco and ± 4.23 mm (30/180 in) for ML1190 eco, the paper cannot be removed.

4. Release the buttons after the tear-off perforations have been aligned with the paper cutter.


REMOVING CONTINUOUS FORMS

1. Tear off the continuous forms. [See "Tearing off continuous forms" on page 36.](#)
2. Press the SEL button to set the printer off-line and reposition the continuous forms in the printer.
3. Press the LOAD/EJECT button to move the front edge of the continuous forms backwards to the Pin Tractors.


NOTE

If sprocket holes of the last page of the forms disengage from the sprocket pins, do not attempt to eject the paper to avoid the possibility of a paper jam.

4. Remove the Input Tray and Rear Cover together by gripping the Input Tray at both sides and pulling it up and away from the printer.




5. Lift the Pin Tractor covers and remove the forms.



6. Close the Pin Tractor covers.
7. Replace the Input Tray and Rear Cover by fitting the Rear Cover into the grooves at the back of the printer and

pushing gently forward until the Input Tray clips into place.



SETTING THE PAPER THICKNESS LEVER

There are 6 lever positions, the first 5 for printing purposes and the sixth to facilitate ribbon replacement.:

Set the Paper Thickness lever for different paper types as follows:

PAPER TYPE	LEVER POSITION				
	1	2	3	4	5 - 6
Cut sheet paper					See below
52 – 80 gsm	X				
81 – 127 gsm		X			
Envelope				X	
Carbon paper or Pressure-sensitive paper (40 gsm)					See below
2 part		X			
3 part		X			
4 part			X		
5 part			X		
6 part				X	

Set the Paper Thickness lever for overall paper thickness as follows:

OVERALL PAPER THICKNESS	LEVER POSITION
0.06 – 0.10 mm	1
0.11 – 0.18 mm	2
0.19 – 0.25 mm	3
0.26 – 0.32 mm	4
0.33 – 0.39 mm	5
0.40 – 0.46 mm	6

NOTE

Printing with lever positions 5 – 6 is not guaranteed.

If the lever position does not suit the paper thickness, paper feeding and printing may not work properly.

Do not print bankbooks to avoid possible pin breakage/ribbon snagging.


Printing can be carried out with the lever position set to 4 for paper thickness up to 0.32 mm.

When lever positions 5-6 are selected, printing quality for carbon paper may decline resulting in illegible characters for example.

OPERATING INSTRUCTIONS

CONTROL PANEL

ML1120 eco




The status/alarm indicators and button switches on the control panel allow you to check printer status and control the printer.

Indicators

INDICATOR	STATUS	MEANING
SEL	ON	Printer is on-line i.e. is available to print
	OFF	Printer is off-line i.e. is not available to print
	Flashing	Print Suppress status
		Head Thermal Alarm status
		Power Save mode (long-cycle flashing)
		When flashing together with the ALARM indicator, printing cannot be resumed at this stage. Turn the power OFF, verify that the carriage moves properly, then turn the power ON again. If the problem is still there after you turn the power ON again, contact your dealer.
ALARM	ON	If printing, indicates lack of paper, i.e. no paper present.
	OFF	Paper present status
	Flashing	Paper jam alarm status
		Media switch alarm status
		When flashing together with the SEL indicator, printing cannot be resumed at this stage. Turn the power OFF, verify that the carriage moves properly, then turn the power ON again. If the problem is still there after you turn the power ON again, contact your dealer.
	STATUS	
1	ON	Menu printing mode
	OFF	Normal printing mode
	Flashing	High temperature indication
2	ON	Quiet print mode
	OFF	Normal speed printing mode
	Flashing	High multipart printing mode

ML1190 eco



The status/alarm indicators and button switches on the control panel allow you to check printer status and control the printer.

Indicators

INDICATOR	STATUS	MEANING
SEL	ON	Printer is on-line i.e. is available to print
	OFF	Printer is off-line i.e. is not available to print
	Flashing	Print Suppress status
		Head Thermal Alarm status
		Power Save mode (long cycle flashing)
When flashing together with the ALARM indicator, printing cannot be resumed at this stage. Turn the power OFF, verify that the carriage moves properly, then turn the power ON again. If the problem is still there after you turn the power ON again, contact your dealer.		
ALARM	ON	Paper end status i.e. no paper present
	OFF	Paper present status
	Flashing	Paper jam alarm status
		Media switch alarm status
		When flashing together with the SEL indicator, printing cannot be resumed at this stage. Turn the power OFF, verify that the carriage moves properly, then turn the power ON again. If the problem is still there after you turn the power ON again, contact your dealer.
STATUS		
1	ON	Menu printing mode
	OFF	Normal printing mode
	Flashing	High temperature indication
2	ON	Quiet print mode
	OFF	Normal speed printing mode
	Flashing	High multipart printing mode

INDICATOR	STATUS	MEANING
3	ON	Printer power is ON
	OFF	Printer power is OFF
	Flashing	Low power consumption mode

BUTTONS

BUTTON	STATUS	FUNCTION
SEL	On-line	Sets the printer to off-line.
	Off-line	Sets the printer to on-line and disarms the printer.
LF/FF	On-line	Feeds paper by one line. Holding the button down results in continuous line feeding.
	Off-line	Performs continuous line feeding. Ejects the cut sheet.
LOAD/EJECT	On-line and off-line Continuous Forms mode	Continuous form fed until first line of next page If the continuous form is in position, press to retract the form to the Pin Tractors. (If the sprocket holes of the last page of the form disengage from the sprocket pins, do not attempt to eject the paper as a paper jam may result.)
	On-line and off-line Cut sheet manual mode	Ejects the cut sheet
TEAR	On-line Continuous Forms mode	Delivers the continuous form to the cut position. If the button is pressed again or data is received, the original form position is restored.
	On-line Cut sheet manual mode	Ineffective
	Off-line	Ineffective


BUTTON	STATUS	FUNCTION
SEL+POWER ON Switch		Enters menu mode.
LOAD/EJECT+SEL	On-line and off-line	ML1120 eco: Microfeed down 0.176 mm (1/144 in) step. ML1190 eco: Microfeed down 0.141 mm (1/180 in) step.
LOAD/EJECT+LF/FF	On-line and off-line	ML1120 eco: Microfeed down 0.176 mm (1/144 in) step. ML1190 eco: Microfeed down 0.141 mm (1/180 in) step.
TEAR+SEL	On-line and off-line	ML1120 eco: Microfeed down 0.176 mm (1/144 in) step at tear of position only. ML1190 eco: Microfeed down 0.141 mm (1/180 in) step at tear of position only.
TEAR+LF/FF	On-line and off-line	ML1120 eco: Microfeed down 0.176 mm (1/144 in) step at tear of position only. ML1190 eco: Microfeed down 0.141 mm (1/180 in) step at tear of position only.
SEL+TEAR	On-line	Quieter print mode Each press of the button pair progresses the printer through Quieter print mode > High multipart print mode > Normal print mode
	Off-line	Ineffective

CHANGE PRINT MODE

You can change print modes directly from the front panel. Hold down the SEL button and press the button indicated below. The printer will cycle through the choices as indicated by the two STATUS lights. When you release the buttons the selection is set.

NOTE
During normal operation, the status lights show the font selection.

ML1120 eco




SWITCH COMBINATION	PRINTING STYLE	STATUS LIGHT	
		Left	Right
SEL + LF/FF	Font		
	Near Letter Quality		On
	Utility	On	
	High Speed Draft		Flashing
	Super Speed Draft	Flashing	

SEL + LOAD/EJECT	Character Pitch		
	10CPI		On
	12CPI	On	
	15CPI		Flashing
	17CPI	Flashing	
	20CPI	On	On
	Proportional		
SEL + TEAR	Print Speed		
	Normal		On
	High Speed	On	
	Quiet	On	On

SWITCH COMBINATION	PRINTING STYLE	STATUS LIGHT	
		LEFT	RIGHT
SEL + LF/FF	Near Letter Quality		On
	Utility	On	
	High Speed Draft		Flashing
	Super Speed Draft	Flashing	
SEL + LOAD/EJECT	Character Pitch		
	10CPI		On
	12CPI	On	
	15CPI		Flashing
	17CPI	Flashing	
	20CPI	On	On
	Proportional		

SWITCH COMBINATION	PRINTING STYLE	STATUS LIGHT	
		LEFT	RIGHT
SEL + TEAR	Print Speed		
	Normal		On
	High Speed	On	
	Quiet	On	On

ML1190 ECO



SWITCH COMBINATION	PRINTING STYLE	STATUS LIGHT		
		LEFT	CENTRE	RIGHT
SEL + LF/FF	Font			
	LQ Courier			On
	LQ Roman		On	
	LQ Swiss	On		
	LQ Swiss Bold			Flashing
	LQ Orator		Flashing	
	LQ Gothic	Flashing		
	LQ Prestige		On	On
	LQ OCR-A	On		On
	LQ OCR-B	On	On	
	Utility		Flashing	Flashing
	HSD	Flashing		Flashing
SEL + LOAD/EJECT	Character Pitch			
	10CPI			On
	12CPI		On	
	15CPI			Flashing
	17CPI		Flashing	
	20CPI		On	On
	Proportional		Flashing	Flashing

SWITCH COMBINATION	PRINTING STYLE	STATUS LIGHT		
		Left	Center	Right
SEL + LF/FF	Font			
	LQ Courier			On
	LQ Roman		On	
	LQ Swiss	On		
	LQ Swiss Bold			Flashing
	LQ Orator		Flashing	
	LQ Gothic	Flashing		
	LQ Prestige		On	On
	LQ OCR-A	On		On
	LQ OCR-B	On	On	
	Utility		Flashing	Flashing
	HSD	Flashing		Flashing
SEL + LOAD/EJECT	Character Pitch			
	10CPI			On
	12CPI		On	
	15CPI			Flashing
	17CPI		Flashing	
	20CPI		On	On
	Proportional		Flashing	Flashing

SETTING MENU VALUES

The following information explains the printer settings and how you can change them. Printer items and their values are printed for reference.

CONFIRMING CURRENT SETTINGS

To print the current menu settings, use a cut sheet of A4 paper or continuous forms of width at least 254 mm. In this example, a sheet of A4 paper is used.

1. Set the Paper Type lever to cut sheet mode.
2. To activate menu mode:
 - (a) Ensure that the printer is powered OFF.
 - (b) While holding down the SEL button set the printer Power Switch to ON.
3. Place the cut sheet on the Paper Tray. The printer prints the firmware details.
4. Press the TEAR button to print out the current menu settings.
5. Exit or proceed to change menu settings:
 - (a) To exit menu settings confirmation, save the current settings and eject the paper, press and hold TEAR, then press LOAD/EJECT and then LF/FF.
 - (b) To change menu settings, see ["Menu setting" on page 53](#).

MENU SETTING

NOTE

Before changing menu settings, you may wish to print the current menu settings as in ["Confirming current settings" on page 53](#).

Set menu item values (printed out for reference as you proceed) as follows:

1. While holding down the SEL button set the printer Power Switch to ON.
2. Place the cut sheet on the Paper Tray.
3. Press SEL (or TEAR and SEL together) to step forward (backward) through the main menu.

- 4.** Press LF/FF (or TEAR and LF/FF together) to step forward (backward) through the sub-menus.
- 5.** Press LOAD/EJECT (or TEAR and LOAD/EJECT together) to step forward (backward) through the settings for each menu item.
- 6.** Repeat steps 3 to 5 as required to change settings for other menu items.
- 7.** To exit menu settings confirmation, save the current settings and eject the paper, press and hold TEAR, then press LOAD/EJECT and then LF/FF.

NOTE

Switching the printer OFF does not save the new settings.

MENU ITEMS AND SETTINGS

In the menu settings tables below, factory default settings are shown in bold.

ML1120 eco

MENU	ITEM	FUNCTION	SETTING
Printer control menu	Emulation Mode	Select EPSON mode, IBM mode, or ML mode.	IBM EPSON ML
Font menu	Print Mode	Select quality of ANK characters.	NLQ Courier NLQ Gothic NLQ OCR-B DRAFT Utility
	Draft Mode	Select HSD or SSD.	HSD IBM SSD
	Pitch	Select character pitch.	10 CPI , 12 CPI, 15 CPI, 17.1 CPI, 20 CPI
	Proportional Spacing	Select whether to use proportional spacing or not.	Yes No
	Style	Select either font style.	Normal , Italics
	Size	Select the character scale size.	Single , Double

MENU	ITEM	FUNCTION	SETTING
Symbol sets menu	Character Set	Select either ANK character code table.	Standard Line Graphics Block Graphics (displayed for ML emulation only) Set I Set II (displayed for IBM and EPSON emulation only)
	Language Set	Select a language character set.	ASCII , French, German, British, Danish I, Swedish I, Italian, Spanish I, Japanese, Norwegian, Danish II, Spanish II, Latin American, French Canadian, Dutch, TSR80, Swedish II, Swedish III, Swedish IV, Turkish, Swiss I, Swiss II, Publisher
	Zero Character	Select either print font pattern to receive a zero character located at 30H in ANK code or at AA30H in a single-byte code.	Unslashed Slashed

MENU	ITEM	FUNCTION	SETTING
Symbol sets menu	Code Page	Select a code page.	USA Canada French Multilingual Portugal Norway Turkey Greek_437 Greek_869 Greek_928 Grk_437 CYPRUS Polska Mazovia Serbo Croatic I Serbo Croatic II ECMA-94 Hungarian CWI Windows Greek Windows East Europe Windows Cyrillic East Europe Latin II-852 Cyrillic I-855 Cyrillic II-866 Kamenicky(MJK) ISO Latin 2 Hebrew NC (862) Hebrew OC Turkey_857 Latin 5 (Windows Turkey) Windows Hebrew Ukrainian Bulgarian ISO Latin 6 (8859/10) Windows Baltic Baltic_774 KBL-Lithuanian Cyrillic Latvian Roman-8 Icelandic-861 Multilingual 858 ISO 8859-15 Greek_737 POL 1 Macedonia
	Slashed Letter 0	Set whether to convert slashed 0 located at 9BH and 9DH in USA code page or not.	Yes No

MENU	ITEM	FUNCTION	SETTING
Rear feed menu	Line Spacing	Select line feed pitch.	6 LPI 8 LPI
	Form Tear-Off	Select manual or auto as the method to advance a continuous form to the form tear-off position.	Manual 500 ms 1 sec 2 sec
	Skip Over Perforation	Select whether to skip over perforation or not. (When a skip over perforation setup command is received, the received command is given priority.)	Yes (25.4 mm/ 1 in) No
	Page Length	Select the length of a continuous form.	279.4 mm(11 in) 296.3 mm (11 2/3 in) 304.8 mm (12 in) 355.6 mm(14 in) 431.8 mm(17 in) 76.2 mm(3 in) 82.6 mm(3.25 in) 84.7 mm(10/3 in) 88.9 mm(3.5 in) 93.1 mm(11/3 in) 101.6 mm(4 in) 127.0 mm(5 in) 139.7 mm(5.5 in) 152.4 mm(6 in) 177.8 mm(7 in) 203.2 mm(8 in) 215.9 mm(8.5 in)
	Cut position adjust	Select an adjustment value for the position to cut the end of a continuous form. (In 1/144 in increments)	-20 - -1 0 +20 - +1

MENU	ITEM	FUNCTION	SETTING
Rear feed menu	TOF adjustment (continuous)	Select an adjustment value for the reference position in regard to the TOF position of a continuous form. The position moves to the rear of the form by [+] and to the top of the form by [-] in 1/144 in increments.	-20 – -1 0 +20 – +1
	TOF (continuous)	Select the reference position for the TOF position when auto loading continuous form paper from the rear of the printer. (Up to the mid-section of characters in the first line.)	2.12 mm (1/12 in) 4.23 mm (1/6 in) 6.35 mm (1/4 in) 8.47 mm (1/3 in) 10.58 mm (5/12 in) 12.7 mm (1/2 in) 14.82 mm (7/12 in) 16.93 mm (2/3 in) 19.05 mm (3/4 in) 21.17 mm (5/6 in) 23.28 mm (11/12 in) 25.4 mm (1 in) 27.52 mm (13/12 in) Use top of form
Bottom feed menu	Line Spacing	Select line feed pitch.	6 LPI 8 LPI
	Skip Over Perforation	Select whether to skip over perforation or not. (When a skip over perforation setup command is received, the received command is given priority.)	Yes (25.4 mm/1 in) No

MENU	ITEM	FUNCTION	SETTING
Bottom feed menu	Page Length	Select the length of a continuous form.	279.4 mm(11 in) 296.3 mm (11 2/3 in) 304.8 mm (12 in) 355.6 mm(14 in) 431.8 mm(17 in) 76.2 mm(3 in) 82.6 mm(3.25 in) 84.7 mm(10/3 in) 88.9 mm(3.5 in) 93.1mm(11/3 in) 101.6 mm(4 in) 127.0 mm(5 in) 139.7 mm(5.5 in) 152.4 mm(6 in) 177.8 mm(7 in) 203.2 mm(8 in) 215.9 mm(8.5 in)
	Line Spacing	Select line feed pitch.	6 LPI 8 LPI
	Page Length	Select the page length of cut paper.	279.4 mm(11 in); 296.3 mm (11 2/3 in) 304.8 mm (12 in) 355.6 mm(14 in) 420.9 mm(16.57 in) 76.2 mm(3 in) 82.6 mm(3.25 in) 84.7 mm(10/3 in) 88.9 mm(3.5 in) 93.1 mm(11/3 in) 101.6 mm(4 in) 127.0 mm(5 in) 139.7 mm(5.5 in) 152.4 mm(6 in) 177.8 mm(7 in) 203.2 mm(8 in) 215.9 mm(8.5 in)
	Top feed wait time	Select the waiting time between setting paper on the tray and feeding it while the printer is waiting for paper to be fed in cut-paper manual feed mode.	Invalid 500 ms 1 sec 2 sec

MENU	ITEM	FUNCTION	SETTING
Top feed menu	Page length control	Control the page length of cut paper.	by MENU setting by Actual page length
	Cut sheet auto eject Position	Select a printable area at the bottom of cut sheets of paper in cut-paper mode (the character centre position).	6.35 mm (1/4 in) 12.70 mm (6/12 in) 14.82 mm (7/12 in)
	TOF Adjustment (Cut Sheet)	Select an adjustment value for the reference position in regard to the TOF position of cut-paper/passbooks. The position moves to the rear of the form by [+] and to the top of the form by [-] in 1/144 in increments.	-20 - -1 0 +20 - +1
	TOF (cut sheet top of form)	Select the reference position for the TOF position when feeding cut-paper in manual mode. (Up to the mid-section of characters in the first line.)	2.12 mm (1/12 in) 4.23 mm (1/6 in) 6.35 mm (1/4 in) 8.47 mm (1/3 in) 10.58 mm (5/12 in) 12.7 mm (1/2 in) 14.82 mm (7/12 in) 16.93 mm (2/3 in) 19.05 mm (3/4 in) 21.17 mm (5/6 in) 23.28 mm (11/12 in) 25.4 mm (1 in) 27.52 mm (13/12 in) Use top of form
	Cut sheet LF adjustment	Adjust a line feed amount in cut-paper mode.	-14 - -1 0 +14 - +1
Set-up menu	Graphics	Select the printing direction when double-height print data exists in a line.	Bi-directional Uni-directional
	Receive buffer size	Select size of the received buffer.	1line 32 K 64 K

MENU	ITEM	FUNCTION	SETTING
Set-up menu	Paper out override	Select whether to detect paper end or not.	No Yes
	Print Registration 1	Adjust the print starting position on printing in the reverse direction. (The position moves to the right or left in 1/720 in increments.)	-10 - -1 0 +10 - +1
	Print Registration 2	Adjust the print starting position on printing in the reverse direction. (The position moves to the right or left in 1/720 in increments.)	-10 - -1 0 +10 - +1
	-Print Registration 3	Adjust the print starting position on printing in the reverse direction. (The position moves to the right or left in 1/720 in increments.)	-10 - -1 0 +10 - +1
	7 or 8 Bits Data Word	Set the character code and graphics data units to 7 or 8 bits. (ML emulation only)	8 7
	Operator panel function	Select full or limited operation.	Full operation Limited operation
	Reset inhibit	Set whether to enable or disable an initial command.	No Yes
	Print suppress effective	Set whether to enable or disable a print suppress setup command.	Yes No

MENU	ITEM	FUNCTION	SETTING
Set-up menu	Auto LF	Select whether to perform auto LF operation or not upon receiving a CR code.	Yes No
	Auto CR	Select whether to perform auto CR operation upon receiving a carriage return command. (Display for IBM emulation only)	Yes No
	Print DEL Code	Set whether 7FH code is printed with DEL mark or not. (ML emulation only)	No Yes
	SI select pitch (10 CPI)	Set how to handle an SI command received in 10 CPI mode. (IBM emulation only)	15 CPI 17.1 CPI
	SI select pitch (12CPI)	Set how to handle an SI command received in 12 CPI mode. (IBM emulation only)	12 CPI 20 CPI
	Time out print	Select valid or invalid.	Valid Invalid
	Auto Select	Select whether to automatically set Select Mode after paper feeding mode or not.	Yes No

MENU	ITEM	FUNCTION	SETTING
Set-up Menu	Host Interface	Select interface settings.	Auto Interface Parallel USB Serial
	I/F Time out	Select timeout time for auto interfacing.	15 sec 30 sec 45 sec 1 min 2 min 3 min 4 min 5 min
	ESC SI Pitch	Set the contents of ESC SI commands. (IBM emulation only)	17.1 CPI 20 CPI
	Select Language Set	Sets the valid/invalid for combination of code page set and language conversion. (Epson emulation only)	Combined Code Page Only
	Print Style	Set quiet printing and print speed.	Normal High Speed Quiet
	Select quiet mode	Select the type of quiet mode.	Mode 1 Mode 2
	Reverse Feed Control	Set reverse feeding.	TOF stop TOF over
	Centering Positon (Continuous)	Set the centering position for the print head by the number of characters of 10CPI ANK.	Default Mode 1 Mode 2
	Centering Position (Cut Sheet)	Set the centering position for the print head by the number of characters of 10CPI ANK.	Default Mode 1 Mode 2

MENU	ITEM	FUNCTION	SETTING
Set-up Menu	Power Save Time	Select the time to enter to enter the Power Save Mode.	5 min 10 min 15 min 30 min 60 min
	Paper End	Select whether a printer status where no paper is loaded is set to SEL or DESEL.	On-line Off-line
	Print Direction Command	Select the validity of a one-way print setup command.	Valid Invalid
	Print Speed Command	Select the validity of a print speed setup command.	Valid Invalid
	Page Length Command	Select the validity of a page length command.	Valid Invalid
	LF Pitch Command	Select the validity of a linefeed pitch command.	Valid Invalid
	Font Command	Select the validity of a font command.	Valid Invalid
	Pitch Command	Select the validity of a character pitch command.	Valid Invalid
Parallel I/F	I-Prime	Set I-Prime signal control of the Centronics interface.	Invalid Buffer Print Buffer Clear
	Auto Feed XT	Set whether to enable or disable Auto Feed XT signal of the Centronics interface. (EPSON emulation only)	Valid Invalid
	Bi-Direction	Set whether to enable or disable Two-way communication of the Centronics interface.	Enable Disable

MENU	ITEM	FUNCTION	SETTING
Serial I/F	Parity	Set Parity.	None Odd Even Ignore
	Serial Data 7/8 Bits	Set serial data length.	8 bit 7 bit
	Protocol	Set protocols.	DTR X-ON/X-OFF DTR & X-ON/X-OFF
	Diagnostic Test	Set/Cancel loop testing of the serial interface.	No Yes
	Baud Rate	Set the transmission speed of the serial interface.	9,600 bps 4,800 bps 2,400 bps 1,200 bps 600 bps 300 bps 19,200 bps
	DTR Signal	Set whether to switch the DTR signal of the serial interface by Select/ Deselect or hold it after power-on.	Ready on Power UP Ready on Select
	Busy Time	Set the minimum time it takes to switch from a busy state to a ready state.	0.2 sec 1.0 sec

ML1190 eco

In the menu settings tables below, factory default settings are shown in bold.

MENU	ITEM	FUNTION	SETTING
Printer Control Menu	Emulation Mode	Select EPSON LQ mode, IBM PPR mode, or IBM AGM mode.	EPSON LQ IBM PPR IBM AGM
Font Menu	Print Mode	Select quality of ANK characters.	LQ Courier LQ Roman LQ Swiss LQ Swiss Bold LQ Orator LQ Gothic LQ Prestige LQ OCR-A LQ OCR-B Utility HSD
	Pitch	Select character pitch.	10 CPI 12 CPI 15 CPI 17.1 CPI 20 CPI
	Proportional Spacing	Select whether to use proportional spacing or not.	Yes No
	Style	Select font style.	Normal Italics

MENU	ITEM	FUNTION	SETTING
Symbol Sets Menu	Character Set	Select either ANK character code table.	Set I Set II
	Language Set	Select language character set.	ASCII French German British Danish I Swedish I Italian Spanish I Japanese Norwegian Danish II Spanish II Latin American French Canadian Dutch Swedish II Swedish III Swedish IV Turkish Swiss I Swiss II Publisher
	Zero Character	Select either print font pattern to receive a zero character located at 30H in ANK code or at AA30H in a single-byte code.	Unslashed Slashed
	Code Page	Select a code page.	USA Canadian French Multilinguall Portugal Norway Turkey Greek_437 Greek_869

MENU	ITEM	FUNTION	SETTING
Symbol Sets Menu	Slashed Letter 0	Set whether to convert slashed 0 located at 9BH and 9DH in USA code page or not.	Yes No
Rear Feed Menu	Line Spacing	Select line feed pitch.	6 LPI 8 LPI
	Form Tear-Off	Select manual or auto as the method to advance a continuous form to the form tear-off position.	Manual 500 ms 1 sec 2 sec
	Skip Over Perforation	Select whether to skip over perforation or not. (When a skip over perforation setup command is received, the received command is given priority.	Yes (25.4 mm/ 1 in) No
	Cut Position Adjust	Select an adjustment value for the position to cut the end of a continuous form. (In 1/180 in increments)	-20 - -1 0 +20 - +1
	TOF Adjustment (continuous)	Select an adjustment value for the reference position in regard to the TOF position of a continuous form. The position moves to the rear of the form by [+] and to the top of the form by [-] in 1/180 increments.	-20 - -1 0 +20 - +1

MENU	ITEM	FUNTION	SETTING
Rear Feed Menu	TOF (continuous)	Select the reference position for the TOF position when auto loading continuous form paper from the rear of the printer. (Up to the midsection of characters in the first line)	2.12 mm (1/12 in) 4.23 mm (2/12 in) 6.35 mm (3/12 in) 8.47 mm (4/12 in) 10.58 mm (5/12 in) 12.70 mm (6/12 in) 14.82 mm (7/12 in) 16.93 mm (8/12 in) 19.05 mm (9/12 in) 21.17 mm (10/12 in) 23.28 mm (11/12 in) 25.40 mm (12/12 in) 27.52 mm (13/12 in) User top of form
Bottom Feed Menu	Line Spacing	Select line feed pitch.	6 LPI 8 LPI
	Skip Over Perforation	Select whether to skip over perforation or not. (When a skip over perforation setup command is received, the received command is given priority.)	Yes (25.4 mm/1 in) No

MENU	ITEM	FUNTION	SETTING
Bottom Feed Menu	Page Length	Select the length of a continuous form.	279.4 mm (11 in) 296.3 mm (11 2/3 in) 304.8 mm (12 in) 355.6 mm (14 in) 431.8 mm (17 in) 76.2 mm (3 in) 82.6 mm (3.25 in) 84.7 mm (10/3 in) 88.9 mm (3.5 in) 93.1 mm (11/3 in) 101.6 mm (4 in) 127.0 mm (5 in) 139.7 mm (5.5 in) 152.4 mm (6 in) 177.8 mm (7 in) 203.2 mm (8 in) 215.9 mm (8.5 in)
	Line Spacing	Select line feed pitch.	6 LPI 8 LPI
Top Feed Menu	Page Length	Select the page length of cut paper	279.4 mm (11 in) 296.3 mm (11 2/3 in) 304.8 mm (12 in) 355.6 mm (14 in) 420.9 mm (16.57 in) 76.2 mm (3 in) 82.6 mm (3.25 in) 84.7 mm (10/3 in) 88.9 mm (3.5 in) 93.1 mm (11/3 in) 101.6 mm (4 in) 127.0 mm (5 in) 139.7 mm (5.5 in) 152.4 mm (6 in) 177.8 mm (7 in) 203.2 mm (8 in) 215.9 mm (8.5 in)

MENU	ITEM	FUNTION	SETTING
Top Feed Menu	Top Feed Wait Time	Select the waiting time between setting paper on the tray and feeding it while the printer is waiting for paper to be fed in cut-paper manual feed mode.	Invalid 0.5sec 1.0sec 2.0sec
	Page Length Control	Control the page length of cut paper.	by MENU setting by Actual page length
	Cut Sheet Auto Eject Position	Select a printable area at the bottom of cut sheets of paper in cut-paper mode (the character centre position).	6.35 mm (1/4 in) 12.70 mm(6/12 in) 14.82 mm (7/12 in)
	TOF Adjustment (Cut Sheet)	Select an adjustment value for the reference position in regard to the TOF position of cut-paper/ passbooks. The position moves to the rear of the form by [+] and to the top of the form by [-] in 1/180 in increments.	-30 - -1 0 +1 - +30

MENU	ITEM	FUNTION	SETTING
Top Feed Menu	TOF (Cut Sheet Top of Form)	Select the reference position for the TOF position when feeding cut-paper in manual mode. (Up to the mid-section of characters in the first line.)	2.12 mm (1/12 in) 4.23 mm (1/6 in) 6.35 mm (1/4 in) 8.47 mm (1/3 in) 10.58 mm (5/12 in) 12.7 mm (1/2 in) 14.82 mm (7/12 in) 16.93 mm (2/3 in) 19.05 mm (3/4 in) 21.17 mm (5/6 in) 23.28 mm (11/12 in) 25.4 mm (1 in) 27.52 mm (13/12 in) Use top of form
	Cut Sheet LF Adjustment	Adjust a line feed amount in cut-paper mode.	-14 - -1 0 +1 - +14
Set-up Menu	Graphics	Select the printing direction when double-height print data exists in a line.	Bi-directional Uni-directional
	Receive Buffer Size	Select size of the received buffer.	1line 32 K 64 K
	Paper Out Override	Select whether to detect paper end or not.	No Yes
	Print Registration 1	Adjust the print starting position on printing in the reverse direction. (The position moves to the right or left in 1/720 in increments.)	-10 - -1 0 +1 - +10

MENU	ITEM	FUNTION	SETTING
Set-up Menu	Print Registration 2	Adjust the print starting position on printing in the reverse direction. (The position moves to the right or left in 1/720 in increments.)	-10 - -1 0 +1 - +10
	Print Registration 3	Adjust the print starting position on printing in the reverse direction. (The position moves to the right or left in 1/720 in increments.)	-10 - -1 0 +1 - +10
	Print Registration 4	Adjust the print starting position on printing in the reverse direction. (The position moves to the right or left in 1/720 in increments.)	-10 - -1 0 +1 - +10
	Operator Panel Function	Select full or limited operation.	Full operation Limited operation
	Reset Inhibit	Set whether to enable or disable an initial command.	No Yes
	Print Suppress Effective	Set whether to enable or disable a print suppress setup command.	Yes No
	Auto LF	Set whether to enable or disable a print suppress setup command.	Yes No

MENU	ITEM	FUNTION	SETTING
Set-up Menu	Auto CR	Select whether to perform auto CR operation upon receiving a carriage return command. (IBM PPR and IBM AGM emulation only)	Yes No
	SI Select Pitch (10 CPI)	Set how to handle an SI command received in 10 CPI mode. (IBM PPR and IBM AGM emulation only)	15 CPI 17.1 CPI
	SI select Pitch (12 CPI)	Set how to handle an SI command received in 12 CPI mode. (IBM PPR and IBM AGM emulation only)	12 CPI 20 CPI
	Time out Print	Select valid or invalid.	Valid Invalid
	Auto Select	Select whether to automatically set Select Mode after paper feeding or not.	Yes No
	Host Interface	Select interface settings.	Auto Interface Parallel USB Serial
	I/F Time Out	Select timeout time for auto interfacing.	15 sec 30 sec 45 sec
	Select Language Set	Sets the valid/invalid for combination of code page set and language conversion. (Epson emulation only)	Combined Code Page Only

MENU	ITEM	FUNTION	SETTING
Set-up Menu	Print Style	Set quiet printing.	Normal Quiet
	Centering Position (continuous)	Set the centering position for the print head by the number of characters of 10CPI ANK.	Default Mode1 Mode2
	Centering Position (cut sheet)	Set the centering position for the print head by the number of characters of 10CPI ANK.	Default Mode1 Mode2
	Power Save Time	Select the time to enter the Power Save mode.	5 min 10 min 15 min 30 min 60 min
	Paper End	Select whether a printer status where no paper is loaded is set to SEL or DESEL.	On-line Off-line
	Print Direction Command	Select the validity of a one-way print setup command.	Valid Invalid
	Print Speed Command	Select the validity of a print speed setup command.	Valid Invalid
	Page Length Command	Select the validity of a page length command.	Valid Invalid
	LF Pitch Command	Select the validity of a linefeed pitch command.	Valid Invalid
	Font Command	Select the validity of a font command.	Valid Invalid
	Pitch Command	Select the validity of a character pitch command.	Valid Invalid

MENU	ITEM	FUNTION	SETTING
Parallel I/F	I-Prime	Set I-Prime signal control of the Centronics interface.	Invalid Buffer Print Buffer Clear
	Auto Feed XT	Set whether to enable or disable Auto Feed XT signal of the Centronics interface. (EPSON emulation only)	Valid Invalid
	Bi-Direction	Set whether to enable or disable Two-way communication of the Centronics interface.	Enable Disable
Serial I/F Menu	Parity	Set parity.	None Odd Even Ignore
	Serial Data 7/8 Bits	Set serial data length.	8 bit 7 bit
	Protocol	Set protocols.	DTR X-ON/X-OFF DTR & X-ON/X-OFF
	Diagnostic Test	Set/Cancel loop testing of the serial interface.	No Yes
	Baud Rate	Set the transmission speed of the serial interface.	9,600 bps 4,800 bps 2,400 bps 1,200 bps 600 bps 300 bps 19,200 bps

MENU	ITEM	FUNTION	SETTING
Serial I/F Menu	DTR Signal	Set whether to switch the DTR signal of the serial interface by Select/ Deselect or hold it after power-on.	Ready on Power UP Ready on Select
	Busy Time	Set the minimum time it takes to switch from a busy state to a ready state.	0.2 sec 1.0 sec

INITIALISING MENU SETTINGS

To restore the menu settings to their initial values, carry out the steps below.

NOTE

The values adjusted by the Adjustment menus are not initialised by the following procedure.

1. Set the Power Switch to OFF.
2. Press and hold down the SEL and LF/FF buttons together and then set the Power Switch to ON.

ADJUSTING TOF POSITION

Use the following procedure to set TOF to accord with the reference position (23.28 mm (11/12 in)). The reference position refers to the first line of the paper i.e. the position to which the printer feeds the paper when automatically loading the paper.

NOTE

Adjusting of TOF can be done in cut sheet mode or continuous forms mode.

- 1.** Print out the menu settings of the printer as in ["Confirming current settings" on page 53](#) and confirm that the TOF (in cut sheet mode or continuous forms mode) is 23.28 mm (11/12 in).
- 2.** Set the Paper Type lever to the required paper type.
- 3.** When continuous forms are used, place the paper on the Pin Tractor.

For cut sheet mode, do not insert the paper at this stage.
- 4.** In continuous forms mode, press the LOAD/EJECT button.

In cut sheet mode, place the paper in the Paper Tray and press LOAD/EJECT.
- 5.** In off-line mode, press the following buttons to adjust the first printing line:

To feed the paper forward by a small amount, press and hold down the LOAD/EJECT button and then press the SEL button. To feed the paper backward by a small amount, press and hold down the LOAD/EJECT button and then press the LF/FF button.

NOTE

If the specified correction range is more than +- 3.53mm (20/144 in) for ML1120 eco and +- 4.23 mm (30/180 in) for ML1190 eco, the paper cannot be moved.

When the paper is positioned at the required TOF, release the buttons in Step [5](#) above.

PRINTER SPEED SETTINGS

PRINTER IMPACT MODE

When switched ON, the printer enters the impact mode selected in the menu. You can change this to normal speed, high speed and quiet printing without using the menus as follows.

(This function is enable for ML1120 eco.)

NORMAL SPEED PRINTING

Use this for standard file printing operations.

1. Ensure the SEL indicator is illuminated.
2. Hold down the SEL button and press the TEAR button.

Status Indicator 1 turns OFF and Status Indicator 2 illuminates.

HIGH SPEED PRINTING

Use this for high speed printing.

1. Ensure the SEL indicator is illuminated.
2. Hold down the SEL button and press the TEAR button.

Status Indicator 1 illuminates and Status Indicator 2 turns OFF.

(High speed printing is applied only to the print of NLQ.)

QUIET PRINTING

Use this for quieter printing.

1. Ensure the SEL indicator is illuminated.
2. Hold down the SEL button and press the TEAR button.

Status Indicator 1 and Status Indicator 2 illuminate.

SETTING TOF POSITION AT THE PLACE OF USER'S CHOICE

TOF position can be set at the user's choice. The reference position refers to the first line of the paper i.e. the position to which the printer feeds the paper when automatically loading paper.

NOTE

Adjusting of TOF can be done in cut sheet mode or continuous forms mode.

- 1.** Move paper level to the position of the paper to be set.
 - 2.** Continuous paper: Set the paper in Pin Tractor.
 - 3.** Continuous paper: Push the LOAD/EJECT button and the paper will be fed to the printer.

Single sheets: Set the paper in the tray and the paper will be fed to the printer.
 - 4.** Switch to off line.
 - 5.** Push the LOAD/EJECT button continuously and adjust the position of printing, start by combining the following buttons:

Forward (minute reline): LOAD/EJECT button = SEL button
Rear (minute reline): LOAD/EJECT button + LF/FF button
-

NOTE

The range set for TOF is between 2.12 mm (1/12 in) and 368/4 mm (14.5 in). Outside the range, the paper cannot be moved.

When the paper is positioned at the required TOF, release the buttons in Step 5 above.

To save this position as the TOF, press and hold down the LOAD/EJECT and the LF/FF buttons together for 3 seconds under the Select condition.

NOTE

Do not turn the Platen Knob or switch off the printer during the above procedure.

TROUBLESHOOTING


CLEARING PAPER JAMS

CUT SHEET PAPER JAMMED IN PRINTER

WARNING!

Do not carry out any operations inside the printer with the Power Switch set to ON.

1. Set the Power Switch to OFF.
2. Remove the Access Cover.




3. Set the Paper Thickness lever to the Replace Ribbon position (position 6).

WARNING!

The Print Head may be hot after printing. Allow it to cool before touching it.

4. Remove the ribbon cartridge. See ["Changing a ribbon cartridge" on page 95.](#)


- 5.** Move the Print Head away from the paper.



- 6.** Rotate the Platen Knob in the relevant direction and pull the cut sheet out from the top of the printer.
- 7.** If a paper fragment remains inside the printer:
- (a) use tweezers to grip and extract it or
 - (b) insert a triple folded sheet from the Paper Tray and turn the Platen Knob to pass the folded sheet through and push out the paper fragment.



8. When the paper jams are cleared, replace the ribbon cartridge and replace the printer Access Cover.



9. Set the Power Switch to ON.


CONTINUOUS FORMS JAMMED IN PRINTER

WARNING!


Do not carry out any operations inside the printer with the Power Switch set to ON.

1. Set the Power Switch to OFF.
2. Tear off any unprinted continuous forms.

3. Remove the Input Tray and Rear Cover together by gripping the Input Tray at both sides and pulling it up and away from the printer.




4. Raise each Pin Tractor cover and remove the continuous forms from the Pin Tractors.



5. Rotate the Platen Knob and remove the forms from the front of the printer.
6. If a form fragment remains inside the printer, place two or three forms in a stack on the Pin Tractors and turn the Platen Knob to push the fragment out of the printer.
7. When the paper jams are cleared, replace the Input Tray and Rear Cover by fitting the Rear Cover into the grooves

at the back of the printer and pushing gently forward until the Input Tray clips into place.



- 8. Set the Power Switch to ON.

RESPONDING TO ALARM CONDITIONS

Use the following table for guidance on how to respond to indicated alarm conditions.

INDICATOR		ALARM MEANINGS AND ACTIONS
SEL	ALARM	
OFF	ON	Paper has run out. Add paper and press the SEL button.
OFF	Flashing	The Paper Type lever is wrongly set for the type of paper in use. Press the SEL button and set the Paper Type lever to the correct position.
OFF	Flashing	Problem with cut sheet feeding. Remove the cut sheet.
Flashing	ON	Print data is received but printing does not start because no paper is being fed. Insert paper.
Flashing	OFF	Printing cannot be resumed at this stage. Turn the power OFF, verify that the carriage moves properly, then turn the power ON again. If the problem is still there after you turn the power ON again, contact your dealer.

RESPONDING TO GENERAL PROBLEMS

Use the following table to help you to identify symptoms with possible causes and take suggested remedial actions.

PROBLEM	CAUSE	ACTION
No power		
No power	The power cable is not properly connected.	Check the power cable is properly connected at both power outlet and printer.
	Power outlet problem or power outage.	Plug another appliance into this outlet to check if it works.

PROBLEM	CAUSE	ACTION
No printing takes place		
SEL indicator is unlit.	The printer driver is not installed properly.	Re-install the printer driver correctly.
	The printer has just stopped printing.	Press the SEL button.
	There is no paper in the printer.	Load paper.
SEL indicator is illuminated but no printing takes place.	Interface cable is disconnected.	Reconnect the interface cable.
	Wrong interface cable has been used.	Use correct interface cable.
The print head is moving but no printing takes place.	The ribbon cartridge has not been installed.	Install the ribbon cartridge.
Print position offset		
The horizontal printing position is offset.	The start position may change after the printer is powered on.	When the printer is powered ON, switch from off-line mode to on-line mode by pressing the SEL button. Reset the start position. You must set the Power Switch to OFF before you change the start position.
Printing slows down		
Print direction changes suddenly to unidirectional.	When the print head overheats, the printer automatically starts unidirectional split printing.	When the print head temperature drops sufficiently, the printer will return to its original operation.
PE warning		
The print carriage does not operate.	There is contamination on the carriage shaft.	Clean any paper dust and contamination from the carriage with a dry cloth.

PROBLEM	CAUSE	ACTION
Print blurring		
The characters are too pale to display properly on the paper.	The Paper Thickness lever position does not match the paper.	Correct the Paper Thickness lever setting.
	The printer is set to print at high speed.	Set the speed to normal.
	The ribbon has reached its end of life.	Replace the ribbon by a new one.
	The ribbon cartridge is not installed correctly.	Reinstall the ribbon cartridge correctly.
	The ribbon has been wound incorrectly.	Replace the ribbon cartridge by a new one.
	The ribbon is not transferring properly.	Replace the ribbon cartridge by a new one.
A line of print is missing.	Broken wire pins.	Contact your dealer.
The printout differs from the screen display.		
Printout of completely different characters or symbols.	Incorrect print setup for the user application.	Reselect print setup for the applications according to priority.
	The application control codes for the previous print operation are still enabled.	Initialise the printer.
	The input application control signal is not correct.	Print in hex dump mode and verify the data content. Make corrections in the application.
	The interface cable is not properly connected.	Reconnect the cable correctly.

PROBLEM	CAUSE	ACTION
Too high or too low TOF (where printing starts).	The TOF is not correctly selected.	Initialise the printer.
		Select correct TOF for cut sheet and continuous forms.
		Select the first-line print position and adjust the paper top position.
		Reselect the margin correctly in the application.
Too large or small left and/or right margins.	The left or right margin is not correctly selected.	Incorrect positions of the Paper Guide or Pin Tractors. Select and adjust the position again depending on the paper type.
		Reselect the left and right margins correctly in the application.
When continuous forms are used, the content of a single form is printed on two forms.	The paper length selected in the application does not match the physical paper length.	Match the paper length selected in the application with the physical paper length in use.
When cut sheets are used, the content of a single sheet is printed on two sheets.	The paper setting selected in the application does not match the physical paper size.	Match the paper setting selected in the application with the physical paper in use.
	It does not match the lines per page as the printer automatically detected.	Leave enough top and bottom margin in the application.
		Correct the cut sheet LF adjustment.
The content of a single line is printed in two lines.	The left and/or right margins are not correctly selected.	Reselect the left and right margins correctly in the application.
When continuous forms are used, several blank lines appear in the printout.	Tear-off perforation spacing is selected.	Cancel tear-off perforation spacing.

PROBLEM	CAUSE	ACTION
Broken and uneven vertical lines.	This may happen in bidirectional printing.	Use Print Registration in the adjustment mode to adjust.
Too large or small line spacing.	Line spacing is not selected correctly.	Reselect line spacing correctly in the application.
Split print		
Blanks appear in graphic printout.	This is a paper feed error, which is especially notable in printing regular characters.	This is not a failure.
Blanks or deformed characters appear in double height type or other extended types.	This is a paper feed error due to line feeding in printing a single character.	This is not a failure. Use the printer's built-in fonts when you print important documents or bills.
Improper cut sheet feed		
No paper feed.	Sheets are located off the paper guide.	Load sheets with their left edges against the paper guide.
	Sheets are not loaded to the end.	Load sheets to the end.
The platen rotates without paper feed, or continuous forms instead of cut sheets are fed.	Sheets are not loaded to the end.	Load sheets to the end.
	The printer is in the continuous forms mode.	Eject the continuous forms and select cut sheet mode for the printer.
Paper distortion.	Sheets are not loaded to the end, or they are not inserted straight.	Load sheets to the end.
	Paper with wrinkles folds or other defects.	Change paper.
	Paper not specified for the printer.	Use paper types specified for the printer.
Unable to eject.	The LF/FF button is pressed.	Press the LOAD/EJECT button.

PROBLEM	CAUSE	ACTION
Improper continuous forms feed.		
No line feed, and no paper feed.	Paper is off the Pin Tractors.	Reload paper correctly.
	The adjust lever position does not match the paper type.	Set the adjust lever to the correct position.
Paper distortion or jam.	Forms are loaded with their left holes out of line with the right ones.	Load forms with their left holes in line with the right ones.
	Inadequate distance between the left and right Pin Tractors, making for loose paper.	Relocate the Pin Tractors to tighten the paper.
	Paper movement is blocked.	Remove the blockage.
	Paper source is too far from the printer.	Move the paper source nearer to the printer.
	Paper not specified for the printer.	Use paper types specified for this printer.
Several blank lines appear in the printout.	Skip over perforation spacing is selected.	Cancel the skip over perforation spacing.
The selected skip over perforation spacing does not match the physical tear-off perforation positions.	The paper length selected in the application does not match the physical paper length.	Match the paper length selected in the application with the physical paper length in use. Select the paper length in number of lines in the application.
Abnormal switchover between cut sheet and continuous forms modes.		
No cut sheet feed.	The printer is in continuous forms mode.	Set the Paper Type lever to cut sheet mode.
No continuous forms feed.	The printer is in cut sheet mode.	Set the Paper Type lever to continuous forms mode.
Paper feed operations for both cut sheets and continuous forms are actuated.	The cut sheet is not ejected.	Eject the cut sheet.

CLEANING YOUR PRINTER

To keep your printer in good operating condition, you are advised to clean it regularly.

WARNING!

Set the printer Power Switch to OFF and disconnect the power cable from the printer before cleaning the printer.

PRINTER EXTERIOR

CAUTION!

Keep the Access Cover closed to avoid the possibility of detergent entering the printer.

Clean the exterior of the printer as required, but at least every six months or 300 hours of operation, whichever comes first:

Moisten a piece of cotton cloth with diluted neutral detergent and carefully wipe the printer exterior.

PRINTER INTERIOR

WARNING!

As the print head becomes hot during printing, allow it to cool before carrying out any cleaning inside the printer.

Do not use any flammable solvents for cleaning the printer to avoid any risk of fire or electric shock.

Clean the interior of the printer every 6 months or 300 hours of operation, whichever comes first.

Using a soft cloth, cotton swabs and a vacuum cleaner, clean the interior of the printer as follows:

WHERE TO CLEAN	WHAT TO CLEAN
The carriage and the area around it	Clean and remove paper waste, dirt, dust and ribbon shreds.
The paper travel surface	

CAUTION!

When you clean the interior of the printer with a vacuum cleaner, do not attempt to clean any parts smaller than the suction nozzle.

Do not clean any interior working parts with the suction nozzle to avoid possible damage to the printer.

CONSUMABLES AND ACCESSORIES

CONSUMABLES

When the printed image becomes faint or incomplete, replace the ribbon cartridge.

CHANGING A RIBBON CARTRIDGE


CAUTION!

Only use genuine Oki Original consumables to ensure the best quality and performance from your hardware. Non-Oki Original products may damage your printer's performance and invalidate your warranty.

WARNING!

Do not change the ribbon cartridge with the Power Switch set to ON.


1. Set the Power Switch to OFF.
2. Set the Paper Thickness lever to Replace Ribbon (position 6).
3. Remove the Access Cover.




WARNING!

The print head and area around it may be hot after printing. Allow it to cool down before touching it.


4. Grip the ribbon cartridge with your fingers at each end and slope it up and out to remove it from the carriage.



5. Dispose of the cartridge in accordance with your local guidelines.
6. Remove the new ribbon cartridge from its wrapping and note the position of the Ribbon Guide (1), blue Knob (2) and Pin (3).



7. In the direction indicated by the arrows, insert the pins at both ends of the ribbon cartridge into the U grooves in the printer until the ribbon cartridge is fully locked.



NOTE


It may be easier to mount the ribbon cartridge in place if you align it with the topside of the grooves. Also, a slightly loose ribbon may make it easier to mount the ribbon cartridge.

8. Hold the ribbon cartridge with your fingers pressing on its ribbon guide and slope it upward and inward along the guide rails until the ribbon guide comes in line with the U slot at the top of the cartridge.
9. Move the print head to position the ribbon then turn the knob anticlockwise (in the direction of the arrow) to wind up the ribbon.


CAUTION!

Do not turn the knob clockwise as the ribbon might jam.

Make sure that the ribbon is not twisted or damaged when it goes through the gap between the Print Head and the ribbon guide.



- 10.** Replace the Access Cover.



- 11.** Set the Paper Thickness lever to match the paper being used. ([See "Setting the paper thickness lever" on page 40.](#))
- 12.** Set the printer Power Switch to ON.

CONSUMABLE ORDER INFORMATION

ITEM	LIFE	ORDER NO.
Ribbon cartridge (Black)	4 million characters	43571082 (EU) 43571803 (Non- EU)

SPECIFICATIONS

ML1120 ECO

ITEM	SPECIFICATION
Product Name	ML1120 eco
Model No.	D22400B
Print method	Impact dot matrix
Print head	9 pins, 0.3mm (0.012 in) diameter
Print direction	Bi-directional, short-line-seeking printing
Print speed High Speed Draft (HSD) Near Letter Quality (NLQ) Utility	333cps @ 10 cpi 62.5 cps @ 10 cpi 250 cps @ 10 cpi
Line Feed (LF) time	Approximately 52 ms per line for LF of 4.23 mm (1/6 in)
Form Feed (FF) speed	Approximately 101.6 mm/s (4 in/s)
Paper feed control	Paper feed: yes Vertical tab: yes Direct line feed: yes
Duplication capability	Continuous forms: the original page +4 more pages (total maximum paper thickness less than 0.325 mm) Cut sheet: the original page +4 more pages (total maximum paper thickness less than 0.325 mm)
Feeding direction	Feed forward Feed backward Feed upward
Feeding mode	Friction feed mode (top) Pin tractor feed mode (rear) Pin tractor feed mode (bottom)
Continuous forms tape tail detection method	Detected when remaining paper is approximately 46 mm long. It can, however, print till about 6 mm from the paper bottom (measured at the centre of the characters). (The print accuracy of the last page cannot be guaranteed.)

ITEM	SPECIFICATION
Character sets	Standard ASCII Epson (Italics/Graphics) IBM (Set1/Set2) ML Foreign Code Page
Media	See "Setting the paper thickness lever" on page 40.
Original OKI cartridge ribbon Ink color Ribbon life	Black 4 million characters (Utility mode)
Print head life	200 million characters
Dimensions	349 mm (W) x 150 mm (H) x 232 mm (D) with platen knob installed
Weight	Approximately 4.2 kg
Power rating Voltage Frequency	220 – 240V ± 10% 50/60 Hz ± 1 Hz
Power consumption Operation Standby mode Sleep mode	33W or less (ISO letter pattern) 5.8 W 1.6 W
Power cable	3 - core AC power cable, approximately 1.8 m length
Interfaces	Bi-directional parallel, IEEE1284-1994 USB 2.0 (full speed) RS-232C
Dust and corrosion	Use the printer in a general office environment.
Environmental conditions Operating Storage	5°C – 35°C, 20% – 80% RH (Testing condition for print precision: 15°C – 30°C, 40% – 70%RH) -10°C – 50°C, 5% – 95% RH When the printer is stored, it should be in its original packaging, with no moisture formation.
Standard usage Average power on time Average printing time	200 h/month 50 h/month (text density on page: 35%)

ITEM	SPECIFICATION
Noise level	The acoustic noise of this product is less than 53 dB (A) as measured in accordance with EN ISO 7779.

ML1190eco

ITEM	SPECIFICATION
Product Name	ML1190 eco
Model No.	D22410B
Print method	Impact dot matrix
Print head	24 pins, 0.2 mm (0.0079 in) diameter
Print direction	Bi-directional, short-line-seeking printing
Print speed High Speed Draft (HSD) Letter Quality (LQ) Utility	333cps @ 10 cpi 83 cps @ 10 cpi 250 cps @ 10 cpi
Line Feed (LF) time	Approximately 47 ms per line for LF of 4.23 mm (1/6 in)
Form Feed (FF) speed	Approximately 109 mm/s (4.3 in/s)
Paper feed control	Paper feed: yes Vertical tab: yes Direct line feed: yes
Duplication capability	Continuous forms: the original page +4 more pages (total maximum paper thickness less than 0.325 mm) Cut sheet: the original page +4 more pages (total maximum paper thickness less than 0.325 mm)
Feeding direction	Feed forward Feed backward Feed upward
Feeding mode	Friction feed mode (top) Pin tractor feed mode (rear) Pin tractor feed mode (bottom)
Continuous forms tape tail detection method	Detected when remaining paper is approximately 46 mm long. It can, however, print till about 6 mm from the paper bottom (measured at the centre of the characters). (The print accuracy of the last page cannot be guaranteed.)
Character sets	Standard ASCII Epson (Italics/Graphics) IBM (Set1/Set2) Foreign Code Page

ITEM	SPECIFICATION
Media	See "Setting the paper thickness lever" on page 40.
Original OKI cartridge ribbon Ink color Ribbon life	Black 4 million characters (Utility mode)
Print head life	200 million characters
Dimensions	349 mm (W) x 150 mm (H) x 232 mm (D) with platen knob installed
Weight	Approximately 4.2 kg
Power rating Voltage Frequency	220 – 240V \pm 10% 50/60 Hz \pm 1 Hz
Power consumption Operation Standby mode Sleep mode	41 W or less (ISO 10561 letter pattern) 6.2 W W
Power cable	3 - core AC power cable, approximately 1.8 m length
Interfaces	Bi-directional parallel, IEEE1284-1994 USB 2.0 (full speed) RS-232C
Dust and corrosion	Use the printer in a general office environment.
Environmental conditions Operating Storage	5°C – 35°C, 20% – 80% RH (Testing condition for print precision: 15°C – 30°C, 40% – 70%RH) -10°C – 50°C, 5% – 95% RH When the printer is stored, it should be in its original packaging, with no moisture formation.
Standard usage Average power on time Average printing time	200 h/month 50 h/month (text density on page: 35%)
Noise level	The acoustic noise of this product is less than 53 dB (A) as measured in accordance with EN ISO 7779.

INDEX

A

alarm indications	86
aligning perforations	36

B

buttons	46
---------------	----

C

cleaning	
exterior	93
interior	93

D

drivers	16
---------------	----

E

ejecting paper	
continuous forms	36
cut sheet	20

F

fault finding	87
---------------------	----

I

indicators	43
interface	
parallel	15
serial	15
USB	15

L

loading paper	
continuous forms	21
cut sheet	18

M

menu settings	
changing	53
confirming	53
initialising	78
list	55
ML1120 eco	42

P

paper jams	
continuous forms	84
cut sheet	82
printer	
control panel	42
location	12
parts	9
test print	14
printing files	17

R

ribbon	
changing	95
ordering	98

S

setting paper thickness	40
specifications	99
switching ON	12

T

test page	16
TOF	
saving	79
setting	79

U

user guide	
list	6
printing	7

OKI CONTACT DETAILS

OKi Systems (UK) Limited

Blays House
Wick Road
Egham
Surrey
TW20 0HJ

Tel: +44 (0) 1784 274300
Fax: +44 (0) 1784 274301
<http://www.oki.co.uk>

OKi Systems Ireland Limited

The Square Industrial Complex
Tallaght
Dublin 24

Tel: +353 (0) 1 4049590
Fax: +353 (0) 1 4049591
<http://www.oki.ie>

OKi Systems Ireland Limited - Northern Ireland

19 Ferndale Avenue
Glengormley
BT36 5AL
Northern Ireland

Tel: +44 (0) 7767 271447
Fax: +44 (0) 1 404 9520
<http://www.oki.ie>

Technical Support for all Ireland:

Tel: +353 1 4049570
Fax: +353 1 4049555
E-mail: tech.support@oki.ie

OKI Systems (Czech and Slovak), s.r.o.

IBC – Pobřežní 3
186 00 Praha 8
Czech Republic

Tel: +420 224 890158
Fax: +420 22 232 6621
Website: www.oki.cz, www.oki.sk

OKi Systems (Deutschland) GmbH

Hansaallee 187
40549 Düsseldorf

Tel: 01805/6544357**
01805/OKIHELP**

Fax: +49 (0) 211 59 33 45
Website: www.okiprintingsolutions.de
info@oki.de

**0,14€/Minute aus dem dt. Festnetz
der T-Com (Stand 11.2008)

Διανομέας των συστημάτων OKI

CPI S.A1 Rafailidou str.
177 78 Tavros
Athens
Greece

Tel: +30 210 48 05 800
Fax: +30 210 48 05 801
E-Mail: sales@cpi.gr

OKi Systèmes (France) S.A.

44-50 Av. du Général de Gaulle
94246 L'Hay les Roses
Paris

Tel: +33 01 46 15 80 00
Télécopie: +33 01 46 15 80 60
Website: www.oki.fr

OKI Systems (Magyarország) Kft.

Capital Square
Tower 2
7th Floor
H-1133 Budapest,
Váci út 76
Hungary

Telefon: +36 1 814 8000
Telefax: +36 1 814 8009
Website: www.okihu.hu

OKI Systems (Italia) S.p.A.

via Milano, 11,
20084 Lacchiarella (MI)

Tel: +39 (0) 2 900261
Fax: +39 (0) 2 90026344
Website: www.oki.it

OKI Printing Solutions

Platinum Business Park II, 3rd Floor
ul. Domaniewska 42
02-672 Warsaw
Poland

Tel: +48 22 448 65 00
Fax: +48 22 448 65 01
Website: www.oki.com.pl
E-mail: oki@oki.com.pl
Hotline: 0800 120066
E-mail: tech@oki.com.pl

Oki Systems (Ibérica) S.A.

Sucursal Portugal
Edifício Prime -
Av. Quinta Grande 53
7º C Alfragide
2614-521 Amadora
Portugal

Tel: +351 21 470 4200
Fax: +351 21 470 4201
Website: www.oki.pt
E-mail : oki@oki.pt

Oki Service

Serviço de apoio técnico ao Cliente

Tel: 808 200 197
E-mail : okiserv@oki.pt

OKI Europe Ltd. (Russia)

Office 702, Bldg 1
Zagorodnoye shosse
117152, Moscow

Tel: +74 095 258 6065
Fax: +74 095 258 6070
e-mail: info@oki.ru
Website: www.oki.ru

Technical support:

Tel: +7 495 564 8421
e-mail: tech@oki.ru

Oki Systems (Österreich)

Campus 21
Businesszentrum Wien Sued
Liebermannstrasse A02 603
22345 Brun am Gebirge

Tel: +43 223 6677 110
Drucker Support:
+43 (0) 2236 677110-501
Fax Support:
+43 (0) 2236 677110-502
Website: www.oki.at

OKI Europe Ltd. (Ukraine)

Raisy Opkinoy Street,8
Building B, 2nd Floor,
Kiev 02002
Ukraine

Tel: +380 44 537 5288
e-mail: info@oki.ua
Website: www.oki.ua

**OKI Sistem ve Yazıcı Çözümleri Tic.
Ltd. Şti.**

Harman sok Duran Is Merkezi,
No:4, Kat:6,
34394, Levent
İstanbul

Tel: +90 212 279 2393
Faks: +90 212 279 2366
Web: www.oki.com.tr
www.okiprintingsolutions.com.tr

Oki Systems (Belgium)

Medialaan 24
1800 Vilvoorde

Helpdesk: 02-2574620

Fax: 02 2531848
Website: www.oki.be

AlphaLink Bulgaria Ltd.

2 Kukush Str.
Building "Antim Tower", fl. 6
1463 Sofia, Bulgaria

tel: +359 2 821 1160
fax: +359 2 821 1193
Website: http://bulgaria.oki.com

OKI Printing Solutions

Herstedøstervej 27
2620 Albertslund
Danmark

Adm.: +45 43 66 65 00
Hotline: +45 43 66 65 40
Salg: +45 43 66 65 30
Fax: +45 43 66 65 90
Website: www.oki.dk

Oki Systems (Finland) Oy

Polaris Capella
Vänrikinkuja 3
02600 Espoo

Tel: +358 (0) 207 900 800
Fax: +358 (0) 207 900 809
Website: www.oki.fi

Oki Systems (Holland) b.v.

Neptunustraat 27-29
2132 JA Hoofddorp

Helpdesk: 0800 5667654
Tel: +31 (0) 23 55 63 740
Fax: +31 (0) 23 55 63 750
Website: www.oki.nl

Oki Systems (Norway) AS

Tevlingveien 23
N-1081 Oslo

Tel: +47 (0) 63 89 36 00
Telefax: +47 (0) 63 89 36 01
Ordrefax: +47 (0) 63 89 36 02
Website: www.oki.no

General Systems S.R.L. (Romania)

Sos. Bucuresti-Ploiesti Nr. 135.

Bucharest 1
Romania

Tel: +40 21 303 3138
Fax: +40 21303 3150
Website: <http://romania.oki.com>

Var vänlig kontakta din Återförsäljare i första hand, för konsultation. I andra hand kontakta

Oki Systems (Sweden) AB

Borgafjordsgatan 7
Box 1191
164 26 Kista

Tel. +46 (0) 8 634 37 00

e-mail:

info@oki.se för allmänna frågor om Oki produkter

support@oki.se för teknisk support gällandes Oki produkter

Vardagar: 08.30 - 12.00,
13.00 - 16.00

Website: www.oki.se

Oki Systems (Schweiz)

Baslerstrasse 15
CH-4310 Rheinfelden

Support deutsch +41 61 827 94 81

Support français +41 61 827 94 82

Support italiano +41 061 827 9473

Tel: +41 61 827 9494

Website: www.oki.ch

.....

0 0