

# bizhub 423/363/283/223

# **User's Guide [Copy Operations]**



# **Table of contents**

1	Introd	luction	
	1.1	Welcome	1-2
	1.1.1	User's guides	1-2
	1.1.2	User's Guide	1-3
	1.2	Conventions used in this manual	1-4
	1.2.1	Symbols used in this manual	
		To use this machine safely	
		Procedural instruction	
	1.2.2	• •	
	1.2.2	Original and paper indications	
		Original and paper indications	
2	Part n	ames and their functions	
	2.1	Option configuration	2-2
	2.2	Main Body	
	2.2.1	Outside of main body (Front)	
	2.2.2	Outside of the main body (rear)	
	2.2.3	Internal main unit	
	2.2.4	Control Panel	
		Adjusting the angle of the Control Panel	
	2.2.5	Touch Panel	2-12
	2.3	Option	2-14
	2.3.1	Finisher FS-527/Saddle Stitcher SD-509/Punch Kit PK-517/Job Separator JS-603	2-14
	2.3.2	Finisher FS-529	2-16
	2.3.3	Job Separator JS-505	2-17
3	Using	this machine	
	3.1	Turning on or off the machine	3-2
	3.2	Basic copy operations	
	3.2.1	Placing originals	3-4
		Loading the original into the ADF	
		Placing the original on the Original Glass	
	3.2.2	Basic copy operations	
	3.2.3	Copy operations using multiple functions	
		Functions that cannot be combined	3-8
4	Contr	ol Panel Keys	
		Control Panel and functions	4-2
	4.1	About Start, Stop, and Interrupt	4-4
		Start	
		StopInterrupt	
		Reset	
	4.2	About Copy, Fax/Scan, and User Box	
	4.2	CopyCopy	
		Fax/Scan	
		User Box	4-5
	4.3	Utility/Counter	4-6
	4.4	Mode Memory	4-7

	4.5	Access	
		Controlling access to the machine by user/account (user authentication/account track) Using the machine during non-scheduled hours	
	4.6	Power Save	4-11
	4.7	Accessibility	
	4.8	Enlarge Display	4-14
	4.9	Guidance	4-15
	4.10	C (Clear)	4-17
	4.11	Proof Copy	4-18
		Printing one set to check the copy result (Proof Copy)	
5	Conv	Function	
5		Function	
	5.1	[Basic]	
	5.1.1	[Density/Background]	
	5.1.2	[Paper] Configuring a custom size	5-6
	5.1.3	[Zoom]	5-7
	5.1.4	[Duplex/Combine]	5-8
	5.1.5	[Finishing]	5-11
	5.1.6	[Separate Scan]	5-13
	5.1.7	[Auto Rotate OFF]	5-14
	5.2	[Original Setting]	
		Copying mixed originals	
		Copying Z-folded originals	
	5.3	[Original Type]	
	5.4	[Application]	
	5.4.1	[Sheet/Cover/Chapter Insert]	
		[Cover Sheet]	
		[Insert Sheet]	5-23
		[Insert Image]	
		[Chapters][Program Jobs]	
	F 4.0		
	5.4.2	[Edit Image][Neg./Pos. Reverse]	
		[Mirror Image]	
		[Image Adjustment]	
	5.4.3	[Book Copy/Repeat]	5-31
		[Book Copy]	
		[Image Repeat]	
		[Booklet Original]	
	5.4.4	[Page Margin]	
	5.4.5	[Image Adjust]	
	5.4.6	[Booklet]	
	5.4.7	[Erase][Frame Erase]	
		[Non-Image Area Erase]	
	5.4.8	[Stamp/Composition]	
	0.1.0	[Date/Time]	
		[Page Number]	
		[Stamp]	
		[Copy Protect][Copy Guard]	
		[Password Copy]	
		[Stamp Repeat]	
		[Header/Footer]	5-49
		[Watermark]	
		[Overlay]	5-50

		[Registered Overlay]	5-52
	5.4.9	[Card Shot]	5-54
	5.4.10	[Save in User Box]	
	5.5	Left panel display	5-56
	5.5.1	[Job List]	5-57
	5.5.2	[Check Job]	5-59
6	[User	Settings]	
	6.1	[System Settings]	6-3
	6.2	[Custom Display Settings]	
	6.3	[Copier Settings]	
	6.4	[Scan/Fax Settings]	
	6.5	[Printer Settings]	
	6.6	[Change Password]	
	6.7	[Change E-Mail Address]	
	6.8	[Change Icon]	
	6.9	[Register Authentication Information]	
	6.10	[Cellular Phone/PDA Setting]	
		32	
7	[Admi	nistrator Settings]	
	7.1	[System Settings]	7-3
	7.1.1	[Power Save Settings]	7-3
	7.1.2	[Output Settings]	7-4
	7.1.3	[Date/Time Settings]	7-5
	7.1.4	[Daylight Saving Time]	7-5
	7.1.5	[Weekly Timer Settings]	
	7.1.6	[Restrict User Access]	
	7.1.7	[Expert Adjustment]	
		[Leading Edge Adjustment][Centering]	
		[Media Adjustment]	
		[Center Staple Position]	
		[Half-Fold Position]	
		[Punch Horizontal Position Adjustment]	
		[Punch Regist Loop Size Adjustment][Paper Alignment Plate Settings]	
		[Maximum Density Adjustment]	
		[Gradation Adjustment]	
		[Initialize Adjustment Value]	7-16
	7.1.8	[List/Counter]	7-16
	7.1.9	[Reset Settings]	7-17
	7.1.10	[User Box Settings]	7-18
	7.1.11	[Standard Size Setting]	7-18
	7.1.12	[Stamp Settings]	7-19
	7.1.13	[Blank Page Print Settings]	7-20
	7.1.14	[Skip Job Operation Settings]	7-21
	7.1.15	[Default Bypass Paper Type Setting]	7-21
	7.1.16	[Page Number Print Position]	
	7.1.17	[Advanced Preview Setting]	
	7.2	[Administrator/Machine Settings]	
	7.3	[One-Touch/User Box Registration]	
	7.4	[User Authentication/Account Track]	
	7.4.1	[General Settings]	
	7.4.2	[User Authentication Settings]	
	7.4.3	[Account Track Settings]	
	7.4.4	[Print without Authentication]	7-31

7.4.5	[Print Counter List]	7-32
7.4.6	S [External Server Settings]	7-32
7.4.7	[Limiting Access to Destinations]	7-33
7.4.8	B [Authentication Device Settings]	7-33
7.4.9	User/Account Common Setting]	7-34
7.4.	0 [Scan to Home Settings]	7-35
7.4.	1 [Scan to Authorized Folder Settings]	7-35
7.5	[Network Settings]	7-36
7.6	[Copier Settings]	7-37
7.7	[Printer Settings]	7-39
7.8	[Fax Settings]	7-40
7.9	[System Connection]	7-41
7.10	[Security Settings]	7-43
7.10	.1 [Administrator Password]	7-43
7.10	.2 [User Box Administrator Setting]	7-43
7.10		
7.10	[]	
7.10		
	Required settings  Settings to forcibly changed	
7.40		
7.10	[	
7.10	[	
7.10 7.10	1- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1	
7.10 <b>7.11</b>	1 2 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3	
7.11 7.12		
8 Ma 8.1	intenance Paper	8-2
8.1.	•	
	Replenishment message	8-2
	Precautions regarding the use of paper	
	Paper storage	
8.1.2	2 Loading paperLoading paper in Tray 1, Tray 2, Tray 3, or Tray 44	
	Loading paper in LCT	
	Loading paper into the Bypass Tray	
8.2	Consumables	8-7
8.2.	Checking consumables	8-7
	Replacement message	
	Checking consumables status	
	Viewing counters	
8.3	Cleaning procedure	
0.3	Slit Scan Glass	
	Original Glass, Control Panel, Paper Take-Up Roller	
	Housing, Original Pad	8-12
9 Tro	ubleshooting	
9.1	When a problem is detected (call a service representative)  Problems that cannot be corrected by the user	
9.2	Troubleshooting table	
J.Z		
	Simple troubleshooting	9-4
	Simple troubleshooting	9-8

14.2	Index by button	14-5
14.1	Index by item	14-2
Index		
13.1		13-2
Appen	ndix	
	Authentication Unit (IC card type) AU-201	12-13
	Job Separator JS-505	12-12
	Finisher FS-527	12-7
12.3		
12.2		
40.0		
12.1		
Specif	fications	
	When [Odia Admentication + 1 assword] is eliabled	11-10
11.1.3		
	User registration	11-11
11.1.2	Registering a user	11-4
11.1.1		
11.1		11-2
Authe	ntication unit (IC card type)	
10.1.3		
	3	
	·	
10.1.2		
10.1.1		
10.1		
Autne	ntication unit (biometric type)	
	10.1 10.1.1 10.1.2  10.1.3  Authe 11.1 11.1.1 11.1.2  11.1.3  Specif 12.1 12.2  12.3  Apper 13.1 Index 14.1	10.1.1 Configuring this machine 10.1.2 Registering a user using the Control Panel of this machine Registering a user using Data Administrator Checking the version of the installed Data Administrator. Setup. User registration.  10.1.3 Logging in to this machine When [1-to-narry authentication] has been specified When [1-to-1 authentication] has been specified.  Authentication unit (IC card type)  11.1 Using authentication unit (IC card type)  11.1.2 Registering a user using the Control Panel of this machine Registering a user using Data Administrator Checking the version of the installed Data Administrator. Setup. User registration.  11.1.3 Logging in to this machine When [Card Authentication] is enabled. When [Card Authentication] is enabled. When [Card Authentication] + Password] is enabled When [Card Authentication] + Password] is enabled  Specifications  12.1 Paper Paper types and paper capacities  12.2 Machine specifications bixub 423/363/283/223 Auto Duplex Unit.  12.3 Options Reverse Automatic Document Feeder DF-621 Paper Feed Cabinet PC-109 Paper Feed Cabinet PC-208 Paper Feed Cabinet PC-309 Punch Kit PK-517 Separator JS-603 Finisher FS-529 Job Separator JS-603 Finisher FS-529 Authentication Unit (jornetric type) AU-102 Authentication Unit (jornetric type) AU-201.

# 1 Introduction

#### 1

## 1 Introduction

#### 1.1 Welcome

Thank you for purchasing this machine.

This User's Guide describes the functions, operating instructions, precautions for correct operation, and simple troubleshooting guidelines of this machine. In order to obtain maximum performance from this product and use it effectively, please read this User's Guide as necessary.

#### 1.1.1 User's guides

Printed manual	Overview
[Quick Guide Copy/Print/Fax/Scan/Box Operations]	This manual describes operating procedures and the functions that are most frequently used in order to enable you to begin using this machine immediately. This manual also contains notes and precautions that should be followed to ensure safe usage of this machine.  Please be sure to read this manual before using this machine.
User's guide CD manuals	Overview
[User's Guide Copy Operations]	This manual describes details on copy mode operations and the settings of this machine.  • Specifications of originals and copy paper  • Copy function  • Maintaining this machine  • Troubleshooting
[User's Guide Enlarge Display Operations]	This manual describes details on operating procedures of the enlarge display mode.  Copy function Scanning function G3 fax function Network fax function
[User's Guide Print Operations]	This manual describes details on printer functions.  Printer function  Setting the printer driver
[User's Guide Box Operations]	This manual describes details on User Box functions.  Saving data in user boxes  Retrieving data from user boxes  Transferring and printing data from user boxes
[User's Guide Network Scan/Fax/Network Fax Operations]	This manual describes details on transmitting scanned data.  • E-mail TX, FTP TX, SMB TX, Save in User Box, WebDAV TX, Web Services  • G3 fax  • IP Address Fax, Internet Fax
[User's Guide Fax Driver Operations]	This manual describes details on the fax driver function that transmits faxes directly from a computer.  • PC-FAX
[User's Guide Network Administrator]	This manual describes details on setting methods for each function using the network connection.  Network settings Settings using PageScope Web Connection

User's guide CD manuals	Overview	
[User's Guide Advanced Function Operations]	This manual describes details on functions that become available by registering the optional license kit and by connecting to an application.  • Web browser function  • Image panel  • PDF Processing Function  • Searchable PDF  • My panel and My address functions	
[Trademarks/Copyrights]	This manual describes details on trademarks and copyrights.  • Trademarks and copyrights	

#### 1.1.2 User's Guide

This User's Guide is intended for users ranging from those using this machine for the first time to administrators.

It describes basic operations, functions that enable more convenient operations, maintenance procedures, simple troubleshooting operations, and various setting methods of this machine.

Note that basic technical knowledge about the product is required to enable users to perform maintenance work or troubleshooting operations. Limit your maintenance and troubleshooting operations to the areas explained in this manual.

Should you experience any problems, please contact our service representative.



#### 1.2 Conventions used in this manual

#### 1.2.1 Symbols used in this manual

Symbols are used in this manual to express various types of information.

The following describes each symbol related to correct and safe usage of this machine.

#### To use this machine safely

#### **⚠ WARNING**

This symbol indicates that a failure to heed the instructions may lead to death or serious injury.

#### **⚠** CAUTION

 This symbol indicates that negligence of the instructions may lead to mishandling that may cause injury or property damage.

#### NOTICE

This symbol indicates a risk that may result in damage to this machine or documents. Follow the instructions to avoid property damage.

#### **Procedural instruction**

- This check mark indicates an option that is required in order to use conditions or functions that are prerequisite for a procedure.
- 1 This format number "1" represents the first step.
- 2 This format number represents the order of serial steps.
  - → This symbol indicates a supplementary explanation of a procedural instruction.

The operation procedures are described using illustrations.

This symbol indicates transition of the control panel to access a desired menu item.



This symbol indicates a desired page.



This symbol indicates a reference.

View the reference as required.

#### **Key symbols**

[]

Key names on the touch panel or computer screen, or a name of user's guide are indicated by these brackets.

Bold text


This presents a key name, part name, product name or option name on the control panel.

#### 1.2.2 Original and paper indications

#### Original and paper sizes


The following explains the indication for originals and paper described in this manual.

When indicating the original or paper size, the Y side represents the width and the X side the length.




#### Original and paper indications

 $\blacksquare$  indicates the paper size with the length (X) being longer than the width (Y).



 $\blacksquare$  indicates the paper size with the length (X) being shorter than the width (Y).




# Part names and their

# functions

# 2 Part names and their functions

# 2.1 Option configuration



No.	Name	Description
1	Main unit	The original is scanned by the scanner section, and the scanned image is printed by the printer section. The main unit is hereinafter referred to as "this machine", "main unit", or <b>bizhub 423/363/283/223</b> through the manual.



No.	Name	Description
2	Reverse Automatic Document Feeder DF-621	bizhub 283/223 is an option. Automatically feeds and scans originals by page. This unit automatically reverses and scans 2-sided originals. This unit is hereinafter referred to as the ADF through the manual.
3	Original Cover OC-509	Fixes the loaded originals. This unit is hereinafter referred to as the <b>Original Cover</b> through the manual.
4	Authentication Unit (biometric type) AU-102	Performs user authentication by scanning vein patterns in the finger.  The Working Table WT-506 is required to install the authentication unit (biometric type) AU-102.  This unit is hereinafter referred to as the Authentication Unit through the manual.
5	Authentication Unit (IC card type) AU-201	Performs user authentication by scanning information recorded on the IC card.  The Working Table WT-506 is required to install the authentication unit (IC card type) AU-201.  This unit is hereinafter referred to as the Authentication Unit through the manual.
6	Working Table WT-506	Provides an area to temporarily place an original or other materials. This is also used when the authentication unit is installed.
7	Keyboard Holder KH-101	Install this holder to use a compact keyboard. For details on compact keyboards, contact your service representative.
8	Desk DK-508	By using the <b>Desk</b> , you can install this machine on the floor.  This unit is hereinafter referred to as the <b>Desk</b> through the manual.  This option may not be available depending on the sales area.
9	Paper Feed Cabinet PC-109	Allows you to load up to 500 sheets in the top tray and use the bottom tray as a storage box. This unit is hereinafter referred to as the Single Paper Feed Cabinet through the manual.
10	Paper Feed Cabinet PC-208	Allows you to load up to 500 sheets respectively in the top and bottom trays.  This unit is hereinafter referred to as the <b>Double Paper Feed Cabinet</b> through the manual.
11	Paper Feed Cabinet PC-409	Allows you to load up to 2500 sheets. This unit is hereinafter referred to as the <b>LCT</b> through the manual.
12	Saddle Stitcher SD-509	Install this unit onto the <b>Finisher FS-527</b> to allow Fold/Bind. Referred to as the <b>Saddle Stitcher</b> throughout the manual.
13	Finisher FS-527	Sorts, groups and staples printed paper before feeding out.  To install the Finisher FS-527, the Desk DK-508, Paper Feed Cabinet PC-409, Paper Feed Cabinet PC-109, or Paper Feed Cabinet PC-208 must be installed onto this machine.
14	Punch Kit PK-517	Install this unit onto the <b>Finisher FS-527</b> to enable punching holes.
15	Job Separator JS-603	Install this unit onto the <b>Finisher FS-527</b> . Collects printed pages.
16	Finisher FS-529	Install this unit onto the output tray of the main unit to sort, group or staple printed paper before feeding out.




No.	Name	Description
17	Job Separator JS-505	Install this unit onto the output tray of the main unit to offset the printed papers. This unit is hereinafter referred to as the <b>Job Separator</b> through the manual.
The	following options are built inside this ma	chine and are not shown in the figure above.
18	Fax Kit FK-508	Allows this machine to function as a fax machine. Alternatively, it allows more telephone lines to be connected.
19	Mount Kit MK-726	Required when installing the Fax Kit FK-508.  This option may not be available depending on the sales area.
20	Stamp Unit SP-501	Applies a stamp to originals that have been scanned.
21	Spare TX Marker Stamp 2	A replacement stamp for the <b>Stamp Unit SP-501</b> .
22	Local Interface Kit EK-604	Install this holder to use a compact keyboard. For details on compact keyboards, contact your service representative.
23	Local Interface Kit EK-605	Install this kit when using the connection function with a compact keyboard or Bluetooth-compatible cellular phone or PDA. A receiving device for Bluetooth communication is built in to this kit.
24	Security Kit SC-507	Enables the copy guard or password copy function. This kit is used to prevent unauthorized copying.
25	Hard Disk HD-516	This is the <b>Hard Disk</b> to be installed in this machine. Some functions or options are available only when a <b>Hard Disk</b> is installed.
26	i-Option LK-101 v2	Enables a Web browser and the Image Panel function to be used on the control panel.
27	i-Option LK-102	Enables PDF document encryption with a digital ID, attaching of a digital signature, and property settings when distributing a PDF document using the scan or User Box function.
28	i-Option LK-103 v2	Provides both i-Option LK-101 v2 and i-Option LK-102.  This option may not be available depending on the sales area.
29	i-Option LK-105	Provides the searchable PDF function.
30	Upgrade Kit UK-203	Required when using Web browser, image panel, PDF processing, searchable PDF, My panel, or My address function.  If necessary, you can increase the number of languages, which can be displayed in the <b>Control Panel</b> of this machine, up to nine.

### 2.2 Main Body


### 2.2.1 Outside of main body (Front)

The illustration above shows the main unit with the optional **Original Cover OC-509** and **Paper Feed Cabinet PC-409**.



No.	Name
1	Original Pad
2	Control Panel
3	USB Port (Type A) USB2.0/1.1
4	USB Port (Type A) USB2.0/1.1 (For compact keyboard)
5	Bypass Tray
6	Paper-Empty Indicator
7	LCT
8	Tray Release Button
9	Tray 2
10	Tray 1
11	Front Door
12	Output Tray

The illustration above shows the main unit with the optional **Reverse Automatic Document Feeder DF-621** and **Paper Feed Cabinet PC-208**.




No.	Name
13	Left Cover Release Lever
14	Left Cover
15	Lateral Guide
16	Original Tray
17	Original Output Tray
18	Sub Power Switch
19	Auto Duplex Unit Lock Release Lever
20	Top Right Door
21	Auto Duplex Unit
22	Top Right Door Release Lever
23	Bottom Right Door
24	Bottom Right Door Release Lever
25	Tray 4/Storage Box
26	Tray 3
27	Status Indicator

2.2 Main Body


#### 2

#### 2.2.2 Outside of the main body (rear)

The illustration above shows the main unit with the optional **Reverse Automatic Document Feeder DF-621**, **Paper Feed Cabinet PC-208**, and **Fax Kit FK-508**.




The illustration above shows the main unit with the optional **Reverse Automatic Document Feeder DF-621**, and **Paper Feed Cabinet PC-208**.



No.	Name
1	Jack for connecting a telephone (TEL PORT2)
2	Telephone Jack 2 (LINE PORT2)
3	Jack for connecting a telephone (TEL PORT1)
4	Telephone Jack 1 (LINE PORT1)
5	USB Port (Type A) USB2.0/1.1
6	USB Port (Type B) USB2.0/1.1
7	Network Connector (10Base-T/100Base-TX/1000Base-T)
8	Power Code

#### 2.2.3 Internal main unit


The illustration above shows the main unit with the optional **Reverse Automatic Document Feeder DF-621** and **Paper Feed Cabinet PC-208**.



No.	Name
1	Original Glass
2	Fusing Unit Top Cover
3	Fusing Unit Cover Lever
4	Fusing Unit
5	Drum Unit
6	Toner Bottle
7	Main Power Switch
8	Total Counter
9	Slit Scan Glass
10	Original Scale
11	Jam Removal Dial

#### 2


#### 2.2.4 Control Panel



No.	Name
1	Stylus Pen
2	Touch Panel
3	Power Indicator
4	Sub Power Switch
5	Function key
6	Data Indicator
7	Keypad
8	Brightness adjustment dial


#### Adjusting the angle of the Control Panel

You can adjust the angle of the **Control Panel** to any of four different levels. You can also tilt the control pane to the left. Set it to your desired position.




#### **NOTICE**

When tilting the Control Panel, do not grab the Touch Panel.




Pull the **Control Panel Release Lever** toward you, and then pull the **Control Panel** up or down.

You can adjust the angle of the **Control Panel** to any of four different levels.



To tilt the **Control Panel** to the left or right, hold the bottom of the **Control Panel**, and then tilt the panel to the left or right.



#### 2.2.5 Touch Panel


When the machine has been turned on and is ready to begin the copy operation, the basic settings screen appears. To activate a function or to select a setting, lightly press the desired button appearing in the screen.

The basic settings screen can be switched between the Basic tab and Quick Copy tab. The arrangement of the buttons and screens differ with the Basic tab and Quick Copy tab; however, the functions that can be set are the same. This manual describes procedures for configuring settings from the Basic tab. The Quick Copy tab displays the setting items of the Basic tab on one screen, which is useful for configuring multiple settings.


#### NOTICE

Do not apply excessive pressure on the **Touch Panel**. Such impact may leave a flaw on the panel, inviting damage to the **Touch Panel**. When operating in the **Touch Panel**, never press down on the touch panel with force or with a pointed object such as a mechanical pencil.

Basic tab



Quick Copy tab



No.	Name
1	Message display area
2	Functions/settings display area
3	Icon/shortcut key display area
4	Toner supply indicators
5	Left panel
6	Check Job
7	Job List
8	Copier setting button (arrow)

No.	Name
9	Density/Background Removal
10	Finishing Program/Finishing

#### Reference

To switch the basic settings screen:


 $\textit{Press Utility/Counter} {\scriptstyle \blacktriangleright \blacktriangleright} [\textit{User Settings}] {\scriptstyle \blacktriangleright \blacktriangleright} [\textit{Custom Display Settings}] {\scriptstyle \blacktriangleright \blacktriangleright} [\textit{Copier Settings}] {\scriptstyle \blacktriangleright \blacktriangleright} [\textit{Default Tab}].$ 


To configure color selection settings for buttons and tabs:

 $\textit{Press Utility/Counter} \blacktriangleright [\textit{User Settings}] \blacktriangleright [\textit{Custom Display Settings}] \blacktriangleright [\textit{Color Selection Settings}].$ 

## 2.3 Option

# 2.3.1 Finisher FS-527/Saddle Stitcher SD-509/Punch Kit PK-517/Job Separator JS-603






No.	Name
1	Output Tray 2
2	Output Tray 1
3	Front Door
4	Horizontal Transport Unit Cover
5	Stapler
6	Guide Lever [FN3]
7	Jam Removal Dial [FN2]
8	Guide Lever [FN1]
9	Guide Lever [FN4]
10	Staple Holder
11	Punch Scrap Box

No.	Name
12	Saddle Stitcher
13	Jam Removal Dial [FN6]
14	Handle [FN5]
15	Transport Unit
16	Punch Kit
17	Job Separator
18	Staple Cartridge
19	Handle [FN7]
20	Folding Output Tray


#### 2.3.2 Finisher FS-529



No.	Name
1	Staple Holder
2	Jam Removal Dial
3	Lock Release Lever
4	Output Tray
5	Tray Extension

#### 2

#### 2.3.3 Job Separator JS-505



No.	Name
1	Jam Removal Dial
2	Assist Lever
3	Output Tray 2
4	Output Tray 1
5	Tray Extension

# 3 Using this machine

# 3 Using this machine


#### 3.1 Turning on or off the machine

This machine has two power controls: the Main Power Switch and Sub Power Switch.


The **Main Power Switch** turns on or off all functions of the machine. Normally, keep the **Main Power Switch** on.

The **Sub Power Switch** turns on and off machine operations, for example, for copying, printing or scanning. Turning **Sub Power Switch** off causes the machine to enter power-saving mode.

- When the **Sub Power Switch** is turned on, the indicator on the **Start** key lights up in orange, and a screen appears to indicate that the machine is starting up. After a few seconds, the message [Warming up. Ready to scan.] appears in the touch panel, and the indicator on the **Start** key lights up in blue, indicating that a job can now be queued.
- ✓ A job can also be queued while the machine is warming up after the Sub Power Switch is turned on. After the machine has finished warming up, the scanned image will be printed.
- The default settings are the settings that are selected immediately after the machine is turned on and before any settings are configured from the Control Panel or Touch Panel, and those that are selected when the Reset key is pressed to cancel all settings configured from the Control Panel or Touch Panel. The default settings can be changed.
- ✓ Do not turn off the Main Power Switch while a queued job or stored data is waiting to be printed. The jobs yet to be printed will be deleted.
- Settings that have not been registered and jobs in the printing queue are cleared when the Main Power Switch and Sub Power Switch are turned off.
- ✓ To turn the Main Power Switch on immediately after turning it off, wait for 10 or more seconds before turning it on again. Not doing so may result in an operation failure.
- ✓ Do not turn off the Main Power Switch or Sub Power Switch while images are being scanned, transmitted, or received. Data being scanned or communicated will be deleted.
- ✓ Do not turn off the Main Power Switch or Sub Power Switch during the copying or printing process. If you turn it off, a paper jam may occur.
- ✓ Do not connect or disconnect the USB cable of the compact keyboard while this machine is turned on. Do not also connect another medium to the USB port for the compact keyboard.
- 1 To turn the power on, open the **Front Door**, and press | on the **Main Power Switch**.



- 2 Close the Front Door.
- 3 Press the Sub Power Switch.
  Check that the Touch Panel is turned on.



To turn the power off, press the **Sub Power Switch**, then the **Main Power Switch**.

Reference
To change the default settings for Copy:

Press the **Utility/Counter** key **→** [User Settings] **→** [Copier Settings] **→** [Default Copy Settings].

3-3 bizhub 423/363/283/223

#### 3.2 Basic copy operations

The following procedures describe how to set the original and the basic copy operations.

#### 3.2.1 Placing originals

Place the original in the **ADF** or on the **Original Glass**. Select the optimal position for setting the original according to the type of the original to be copied.


- Using the **ADF**, a multi-page original can be fed and scanned automatically, one page at a time from the top. The ADF can also be used to automatically scan 2-sided originals.
- When using the Original Glass, place the original directly on the Original Glass for scanning. This
  method is suited for originals in the form of a book and the like that cannot be fed through the ADF.

Load the original, and configure settings for relevant functions as needed.


#### Loading the original into the ADF

The following types of originals should not be loaded into the **ADF**. If loaded, paper may be jammed or the original may be damaged.

- Wrinkled, folded, curled, or torn originals
- Highly translucent or transparent originals, such as OHP transparencies or diazo photosensitive paper
- Coated originals such as carbon-backed paper
- Originals printed on paper thicker than 34-1/16 (128 g/m²)
- Originals that are bound, for example, with staples or paper clips
- Originals that are bound in a book or booklet form
- Originals with pages bound together with glue
- Originals with pages that have had cutouts removed or are cutouts
- Label sheets
- Offset printing masters
- Originals with binder holes
- Originals that have just been printed with this machine
- 1 Slide the **Lateral Guide** to fit the size of the original.



- 2 Load the original face up in the **Original Tray** and arrange according to the scanning order. Load the original by placing it so that its top side faces the back of the machine.
  - → Do not load more than 100 sheets or up to the point where the top of the stack is higher than the ▼ mark. Such an action may cause an original paper jam or damage to the original. It may also invite machine failure. However, an original that exceeds 100 pages can be scanned in separate batches.
  - → If the original is not loaded correctly, it may not be fed in straight, causing it to jam or become damaged.
  - → If the original is loaded in any orientation other than with the top of the original toward the back of the machine, be sure to select the original orientation.
- 3 Slide the adjustable **Lateral Guide** against the edges of the original.



### 3


#### Placing the original on the Original Glass

- ✓ When placing an original, be sure to lift open the ADF or Original Coverat least 20 degrees. If the original is placed on the original glass without the ADF being lifted at least 20 degrees, the correct original size may not be detected.
- ✓ Do not place an original weighing more than 4-7/16 (2 kg) on the **Original Glass**. Furthermore, do not use a strong force to press down on a book or any other form of original that must be spread on the original glass. Otherwise, the machine may be damaged or a failure may occur.
- For thick books or large objects, perform scanning without closing the **ADF** or **Original Cover**. When a original is being scanned with the **ADF** or **Original Cover** open, do not look directly at the **Original Glass** surface where light may be emitted through. Note, however, that the light coming through the original glass is not a laser beam, and will not expose the user to the related hazards.
- ✓ When Non-Image Area Erase is selected, you do not have to close the ADF or Original Cover to copy the original. Place the original anywhere on the Original Glass. The area surrounding the original text will be excluded from the copy. For details, refer to page 5-39.
- 1 Lift open the ADF or Original Cover.
- Place the original face down on the Original Glass.
  - → Load the original by placing it so that its top side faces the back of the machine.
- 3 Align the original with the mark in the back-left corner of the Original Scale.
  - → For transparent or translucent originals, place a blank sheet of paper of the same size as the original over the original.
  - → For bound originals spread over two facing pages, such as a book or a magazine, position the top of the original toward the back of this machine and align the original with the mark in the back-left corner of the **Original Scale**.
  - → When Non-Image Area Erase is selected, the original can be placed anywhere on the **Original** Glass.
- 4 Close the ADF or Original Cover.

#### 3.2.2 Basic copy operations

The following procedure describes the basic copy operations.


- Arrange originals in the order you want them to be scanned and load them face up in the **ADF**.
  - → The original should be placed face down on the Original Glass.



- 2 Using the **Keypad**, enter a value for the number of copies you desire.
  - → If you have entered incorrect number of copies, press the C (clear) key on the keypad, and then reenter the correct number.
- 3 Press the Start key.

The original is scanned and copied.

- → To interrupt the copy operation being performed, press the **Stop** key.
- → A [Ready to accept another job.] message that appears during the current printing job indicates that the next original can be scanned.



- → If an original with copy guard patterns embedded is scanned, the copy operation is stopped and the job is discarded.
- → If an original with a password embedded by the password copy function is scanned, the copy operation starts after you enter the password.
- → If multiple originals with different passwords are scanned at the same time, you will need to enter a password for each original.


#### 3.2.3 Copy operations using multiple functions

This section describes copy operations using combination of functions.

- 1 Load the original.
- 2 Press [Original Setting].
  - → For details on [Original Setting], refer to page 5-15.



- 3 Press [Basic] **►►** [Duplex/Combine].
  - → For details on [Duplex/Combine], refer to page 5-8.



- 4 Press [Basic] and then configure settings for respective functions.
  - → For details on [Density/Background], refer to page 5-4.
  - → For details on [Paper], refer to page 5-5.
  - → For details on [Zoom], refer to page 5-7.
  - → For details on [Original Type], refer to page 5-18.
  - → For details on [Auto Rotate OFF], refer to page 5-14.



- 5 Press [Application] and then configure settings for respective functions.
  - → For details on [Application], refer to page 5-20.



- 6 Press [Basic] **►►** [Finishing].
  - → For details on [Finishing] or [Fold/Bind], refer to page 5-11.



- 7 Press [Check Job] → [Check Details].
  - → For details on [Check Job], refer to page 5-59.



- 8 Using the **Keypad**, enter a value for the number of copies you desire.
  - → If you have entered incorrect number of copies, press the C (clear) key on the keypad, and then reenter the correct number.
- 9 Press the **Start** key.

The original is scanned and copied.

- → To interrupt the copy operation being performed, press the **Stop** key.
- → A [Ready to accept another job.] message that appears during the current printing job indicates that the next original can be scanned.

#### Functions that cannot be combined

Some settings cannot be combined with each other. If they are combined improperly, the settings will be given priorities in either of the two ways described below.

- The setting configured last is given priority. (The setting specified first is canceled.)
- The setting configured first is given priority. (A warning message appears.)


# Control Panel Keys

# 4 Control Panel Keys

This section describes the functions of the keys on the **Control Panel**.

# **Control Panel and functions**

Press the keys on the **Control Panel** to use the Copy, Fax/Scan, User Box or other functions.



No.	Name	Description	Page
1	Touch Panel	Various screens and messages are displayed. You can configure various settings by directly pressing the <b>Touch Panel</b> .	_
2	Power Indicator	Lights up in blue when the machine is turned on with the <b>Main Power Switch</b> .	-
3	Sub Power Switch	Press this switch to turn on/off machine operations. When turned off, the machine enters an energy conservation state.	_
4	Power Save	Press this key to enter Power Save mode. While the machine is in Power Save mode, the indicator on the <b>Power Save</b> key lights up in green and the touch panel goes off. To exit from Power Save mode, press the <b>Power Save</b> key again.	p. 4-11
5	Mode Memory	Allows you to register (store) the desired copy/fax/scan settings as a program or to recall a registered program.	p. 4-7
6	Utility/Counter	Switches to the Utility screen or the Meter Count screen.	p. 4-6
7	Reset	Press this key to reset all settings (except programmed settings) entered using the <b>Control Panel</b> and <b>Touch Panel</b> .	p. 4-4

No.	Name	Description	Page
8	Interrupt	Press this key to enter Interrupt mode. While the machine is in Interrupt mode, the indicator on the Interrupt key lights up in green and the message [Now in Interrupt mode.] appears in the Touch Panel. To cancel Interrupt mode, press the Interrupt key again.	p. 4-4
9	Stop	Pressing this key while copying, scanning or printing temporarily stops the operation.	p. 4-4
10	Proof Copy	Press this key to print a single proof copy to be checked before printing a large number of copies. You can also display a finishing image using the current settings in the <b>Touch Panel</b> . (Only when a <b>Hard Disk</b> is installed.)	p. 4-18
11	Start	Press to start the copy, scan or fax operation.	p. 4-4
12	Data Indicator	Flashes in blue while a print job is being received. Lights up in blue when a print job is queued to be printed or while it is being printed. The indicator lights up in blue when there is saved fax data or unprinted fax data.	-
13	C (clear)	Clears a value (such as the number of copies, a zoom ratio and size) entered using the <b>Keypad</b> .	p. 4-17
14	Keypad	Allows you to specify the number of copies. Allows you to enter the magnification. Allows you to enter various settings.	_
15	Guidance	Switches to the Guidance screen. You can display descriptions of the functions and operating procedures.	p. 4-15
16	Enlarge Display	Enters Enlarge Display mode. If you use <b>PageScope Authentication Manager</b> for authentication, the Enlarge Display screen is not available.	p. 4-14
17	Accessibility	Press this key to display the screen for configuring settings for user accessibility functions.	p. 4-12
18	Access	If user authentication or account track settings have been applied, press the <b>Access</b> key after entering the user name and password (for user authentication) or the account name and password (for account track) in order to use this machine.	p. 4-8
19	Brightness dial	Allows you to adjust the brightness of the <b>Touch Panel</b> .	_
20	User Box	Press this key to enter User Box mode. While the machine is in User Box mode, the indicator on the <b>User Box</b> key lights up in green. For details on User Box functions, refer to the [User's Guide Box Operations].	p. 4-5
21	Fax/Scan	Enters Fax/Scan mode. While the machine is in Fax/Scan mode, the indicator on the <b>Fax/Scan</b> key lights up in green. For details on the fax/scan function, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].	p. 4-5
22	Сору	Press this key to enter Copy mode. (As a default, the machine is in Copy mode.) While the machine is in Copy mode, the indicator on the <b>Copy</b> key lights up in green.	p. 4-5

# 4.1 About Start, Stop, and Interrupt

### **Start**

Start the copy, scan or fax operation.

Press this key again to restart a suspended job.

→ When this machine is ready to begin the operation, the indicator on the **Start** key lights up in blue. If the indicator on the **Start** key lights up in orange, the copy operation cannot begin. (Check that no warning or message is displayed in the **Touch Panel**.)

## **Stop**

- Press the **Stop** key while copying to temporarily stop the scanning or printing operation.
  - → To resume a temporarily stopped job, press the **Start** key.
  - → To delete a temporarily stopped job, select a job in the suspended job list in the screen, and press the [Delete] key.

### Interrupt

Press this key to start a new copy job with different copy settings by suspending the current job in process. This is convenient when you need to make copies urgently.

- ✓ The Interrupt key cannot be operated while an original is being scanned.
- Pressing the Interrupt key restores the default settings.
- 1 Load the original.
- 2 Press the **Interrupt** key.

The indicator on the Interrupt key lights up in green and printing of the current job is suspended.

- 3 Configure the copy settings.
- 4 Press the Start key.
- 5 After the interrupting job has finished printing, press the **Interrupt** key.

The Interrupt indicator goes off and the interrupting copy settings are canceled.

The copy settings return to those specified before the interrupting copying job.

### Reset

Press this key to reset all settings (except programmed settings) entered using the **Control Panel** and **Touch Panel**.

Press the Reset key.

The basic settings screen appears.

# 4.2 About Copy, Fax/Scan, and User Box

This machine operates in Copy, Fax/Scan and User Box modes, from which the user can select a desired function. The indicator on the selected key lights up in green.

## Copy

Press this key to enter Copy mode.

The basic settings screen appears.



### Fax/Scan

Press this key to enter Fax/Scan mode.


For details on the fax/scan function, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].



# **User Box**

Press this key to enter User Box mode.

For details on User Box functions, refer to the [User's Guide Box Operations].



# 4.3 Utility/Counter

Press the **Utility/Counter** key to display the Utility screen. You can configure the machine settings and check its use status in the Utility menu screen.

Press the Utility/Counter key.



### **Settings**

[One-Touch/User Box Registration]	Allows you to register items related to the fax/scanner and User Boxes operations.  For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations] and [User's Guide Box Operations].
[User Settings]	Provides setting items that can be operated by the user.
[Administrator Settings]	Provides setting items that can only be operated by the administrator of the machine.
[Check Consumable Life]	Allows you to check the status (usage level) of consumables.
[Device Information]	Displays information about this machine. [Function Version]: Allows you to check the function version of the currently installed firmware. [IPv4 Address]: Allows you to check the currently specified IPv4 address. [IPv6 Address]: Allows you to check the currently specified IPv6 address.

# 4.4 Mode Memory

Combine frequently used copy settings into programs and register them with this machine. These programs can easily be recalled as programs.

- Up to 30 programs can be registered.
- ✓ To register a program, configure the copy settings to be registered before pressing the Mode Memory key.
- Press the Mode Memory key.



### **Settings**

[Recall Copy Program]	Select the key registered with the copy settings to be recalled.		
[Register Program]	<ul> <li>From the keys displayed in the screen, press the key you want to register copy settings with, and then press the [Register Program].</li> <li>Enter the registration name, and then press [OK].</li> </ul>		
[Check Job]	Press this button to check the copy settings registered with the selected key.		
[Edit Name]	Press this button to rename the registered name of the selected key. After enabling Copy Program Lock, [Edit Name] will not be displayed.		
[Delete]	Press this button to delete the selected key.  After enabling Copy Program Lock, [Delete] will not be displayed.		



To prohibit modification and deletion of programs:

Press the **Utility/Counter** key → [Administrator Settings] → [System Settings] → [Restrict User Access] → [Copy Program Lock Settings].

To delete a program:

Press the **Utility/Counter** key → [Administrator Settings] → [System Settings] → [Restrict User Access] → [Delete Saved Copy Program].

## 4.5 Access

If the administrator has configured user authentication settings/account track settings, only the users who have been registered or the users whose accounts have been registered can use this machine.

If the administrator has configured a usage schedule, a user can use the machine by entering a password for non-business hours.

# Controlling access to the machine by user/account (user authentication/account track)

- With the user authentication/account track functions enabled, only the users who enter passwords for users or for accounts can use this machine.
- ✓ Thus, the number of copies among others can be managed by user/account.
- Contact the administrator for information on the user name, account name, password and server name.
- ✓ The login page that appears may vary depending on the user authentication/account track settings.
- User Authentication can be used together with Account Track. If the User Authentication/Account Track is set to [Do Not Synchronize], complete user authentication, and then log in by using the Account Track screen.
- ✓ If MFP authentication or external server authentication has been set, a total of 1000 users and accounts can be registered.
- ✓ A total of 100 users and accounts can be registered when a Hard Disk is not installed.
- ✓ After copying is completed, press the Access key to log out from the machine.
- ✓ You can use the authentication unit for authentication to handle this machine. (This function is available only when a Hard Disk is installed.)
- ✓ The user, who sets the use of this machine to suspend in User Authentication Settings, cannot log in to this machine.
- ✓ The account, which sets the use of this machine to suspend in Account Track Settings, cannot log in to this machine. The users, who belong to the suspended account, cannot also log in to this machine.
- If authentication is performed with PageScope Authentication Manager, check with your server administrator for information on the login procedure.
- The authentication using PageScope Authentication Manager is available only when a Hard Disk is installed.
- Press the Access key.

Screen for user authentication



# Screen for account track



# Settings

User Authentication	Performs the user authentication procedure to use this machine.		
	[Public User Access]	Allows users who have no access to the [User Name] or [Password] to use this machine. This item is not displayed when [Public User Access] is set to [Restrict] in [General Settings] of [Administrator Settings]. If [Enhanced Security Mode] has been enabled, [Public User Access] is not displayed.	
	[User Name]	Enter the user name.	
	[User Name List]	<ul> <li>Select a user name from a displayed list.</li> <li>If [Enhanced Security Mode] has been enabled, [User Name List] is not displayed.</li> <li>The user, who has set the use of this machine to suspend in User Authentication Settings, is not displayed in the [User Name List].</li> </ul>	
	[Password]	Enter the password.	
	[Server Name]	Indicates the name of the default server. Press [Server Name] to display the names of the registered servers. Select the desired server.	
	[Login]	Displays the basic settings screen, enabling you to use this machine.	
Account Track	Performs the account track procedure to use this machine.		
	[Account Name]	Enter the account name.	
	[Password]	Enter the password. When the [Account Track Input Method] is set to [Password Only] in [Administrator Settings], the login screen displays only [Password]. The user can directly enter the password in the login screen from the keypad. For an all-number password, the user can log in without displaying the keyboard screen, simply by pressing [Login], or the Access key.  • For a password containing alphabets, numbers and/or symbol characters, press [Password] and then enter the password.  • After entering numbers from the keypad, press [Password] to enter alphabets and symbols in succession.	
	[Login]	Displays the basic settings screen, enabling you to use this machine.	



To configure user authentication/account track:

Press the Utility/Counter key >> [Administrator Settings] >> [User Authentication/ Account Track].

# Using the machine during non-scheduled hours

The machine can be set to automatically enter Sleep mode according to a usage schedule determined by the administrator so the use of the machine can be limited. This is referred to as Weekly Timer. Follow the procedure described below to use the machine while the Weekly Timer is being used.

- ✓ From the [Password for Non-Business Hours] screen (displayed from Administrator Settings mode), the machine can be set so that the screen for entering the password for non-business hours is not displayed.
- 1 Press the **Power Save** key.
- Enter the password for non-business hours.
- 3 Press [OK].
- 4 Using the keypad, enter the length of time to elapse before the machine enters Sleep mode again.



5 Press [OK].

The basic settings screen appears.



To configure Weekly Timer:

Press the **Utility/Counter** key → [Administrator Settings] → [System Settings] → [Weekly Timer Settings].

4.6 Power Save

# 4

## 4.6 Power Save

If no operation is performed for a specified length of time, the touch panel goes off and the machine automatically enters a mode where it conserves energy. This is referred to as Low Power or Sleep mode.

The following describes the procedure for returning from Low Power or Sleep mode.

- Although the machine conserves more energy in Sleep mode than in Low Power mode, the warm-up process for returning to ready-for-copy state from Sleep mode is more time-consuming.
- ✓ As the factory default, Low Power mode is set to restart after 15 minutes and Sleep mode after 20 minutes. In other words, the machine enters Low Power mode if no operation is performed for 15 minutes. Likewise, it enters Sleep mode after 20 minutes has elapsed.
- ✓ The machine can receive jobs even while it is in Low Power mode.
- Press the Power Save key.

The machine returns from Low Power mode when any other key on the **Control Panel** or the **Touch Panel** surface is pressed.



To enable Low Power mode:

Press the **Utility/Counter** key → [Administrator Settings] → [System Settings] → [Power Save Settings].


4.7 Accessibility

# 4.7 Accessibility


This section describes the procedures for configuring settings for the **Control Panel** and adjusting the **Touch Panel**.

- ✓ To return to the basic settings screen from the Accessibility Setting screen, press the Accessibility key, the Reset key or [Close].
- In the Enlarge Display screen, [Default Enlarge Display Settings] appears, enabling you to configure default settings for use in the Enlarge Display mode using the copy or fax/scan functions.
- Press the Accessibility key.

Page 1/2



Page 2/2



### **Settings**

[Touch Panel Adjustment]

If no normal reaction is returned after pressing a key on the **Touch Panel**, the key display position on the **Touch Panel** may not be correctly aligned with the actual position of the touch sensor.

Adjust the display position of the **Touch Panel**.

- The touch sensors are not aligned in the touch panel if pressing [Touch Panel Adjustment] does not activate any action. Press the 1 key on the Keypad.
- Press the four check point buttons ([+]) on the touch panel adjustment screen while listening on a buzzer sound each time. When the checking by pressing the check point buttons is completed successfully, the indicator on the **Start** key lights up in blue. Press the **Start** key.
- The check point buttons ([+]) can be pressed in any order.
- To perform adjustment again, press the C (Clear) key, and then press the four check point buttons ([+]) again.
- To cancel the Touch Panel adjustment process, press the Stop or Reset key.
- If the touch panel cannot be adjusted, contact your service representative.

4.7 Accessibility

Settings	
[Key Repeat Start/Interval Time]	Specify the length of time until the value begins to change after a <b>Touch Panel</b> button is held down, and also specify the length of time for the value to change to the next number.  The settings specified for Key Repeat Start/Interval Time are only applied in Enlarge Display mode.
[System Auto Reset Confirmation]	Specify whether to display a message when the system auto reset operation is performed in Enlarge Display mode, allowing the user to choose either to continue operating without exiting Enlarge Display mode or to exit Enlarge Display mode and return to the basic settings screen.  Also specify the duration of time for displaying the confirmation screen.
[Auto Reset Confirmation]	Specify whether to display a message when the automatic panel reset operation is performed in Enlarge Display mode, allowing the user to choose either to continue operating without resetting the current settings or to reset the settings.  Also specify the duration of time for displaying the confirmation screen.
[Enlarge Display Mode Confirmation]	Specify whether to display a message when the <b>Enlarge Display</b> key is pressed to change the display of the screen, requesting confirmation to cancel the settings that cannot be specified in Enlarge Display mode.
[Message Display Time]	Specify the duration of time for displaying warning messages, which appear, for example, when an incorrect operation is performed.
[Sound Setting]	<ul> <li>[Sound Setting]</li> <li>[Batch Output]: Specify [On] or [No] to output all sounds.</li> <li>[Confirmation Sound]: Select whether to output the operation confirmation sound.</li> <li>[Succesful Completion Sound]: Select whether to output the normal end sound.</li> <li>[Ready Sound]: Select whether to output the ready sound.</li> <li>[Warning Sound]: Select whether to output the caution sound. Configure the settings for sounding associated with key operations. The following sound setting functions are available. To produce a sound, press [Yes], and then select the volume from [Low], [Medium] and [High]. To not produce a sound, press [No].</li> <li>[Operation Confirmation Sound]: A sound produced when a key in the Control Panel or a button in the Touch Panel is pressed for an entry</li> <li>[Invalid Input Sound]: A sound produced for invalid button operation in the Control Panel or the Touch Panel</li> <li>[Basic Sound]: A sound produced when the default value item is selected for an option subject to rotational switching</li> <li>[Successful Completion Sound]: A sound produced when the operation has completed normally</li> <li>[Completed Operation Sound]: A sound produced when a communications-related operation is completed normally</li> <li>[Completed Preparation Sound]: A sound produced when a device is ready [Caution Sound]</li> <li>Simple Caution Sound (Level 1)]: A sound produced when the replacement time is nearing for supplies or a replaceable part and a message appears in the Touch Panel</li> <li>[Simple Caution Sound (Level 2)]: A sound produced when an error occurs that can be corrected by the user by referring to the message that appears or the User's Guide</li> <li>[Severe Caution Sound]: A sound produced when an error occurs that cannot be corrected by the user or requires action by a service representative</li> </ul>
[Default Enlarge Display Settings]	For details, refer to the [User's Guide Enlarge Display Operations].

4.8 Enlarge Display

# 4

# 4.8 Enlarge Display

Press this key to enter Enlarge Display mode and enable machine operation using a screen with a layout with larger-size characters.

For details on the Enlarge Display screen, refer to the [User's Guide Enlarge Display Operations].


- Press the Enlarge Display key to return to normal display.
- ✓ If PageScope Authentication Manager is used for authentication, the login screen cannot be switched to the enlarged display mode.
- The authentication using PageScope Authentication Manager is available only when a Hard Disk is installed.
- Press the Enlarge Display key.



# 4.9 Guidance

Press this key to view and check descriptions of various functions and operating procedures. When the **Guidance** key is pressed, the Guidance screen for the displayed screen appears.

- ✓ From the Help main menu screen, you can find the target Guidance screen based on the function or purpose.
- Refer to the left panel of the Guidance screen to check the position of the displayed Guidance screen in the menu structure.
- ✔ Press [Close] in the Guidance screen to move up one level in the menu structure. Press [Exit] to exit Guidance mode and return to the screen that was displayed before the **Guidance** key was pressed. Press [To Menu] to display the Help main menu.
- ✓ In the Main Menu and Guidance Menu screens, select items by pressing the button or by pressing the key in the keypad.
- ✓ The Guidance screens cannot be displayed when the following operations are being performed: Scanning, printing a proof copy, preview of a finished copy, operating in Enlarge Display mode, or operating in Accessibility mode
- While the Guidance screen is displayed, the following keys on the operation panel are disabled: Start, C(Clear), Interrupt, Proof Copy, Access, Mode Memory, and Enlarge Display
- Press the **Guidance** key.



### **Settings**

[Function]	Check descriptions by selecting a Guidance menu grouped by function type and name.
[Search by Operation]	<ul> <li>Check descriptions by selecting a Guidance menu grouped by operation type.</li> <li>With [Go to function] displayed, the function for the selected operation can be set. However, when the fax/scan function is used, for example, [Go to function] displayed on a Guidance screen for the copy function, for example, cannot be selected as it is a different function from the one in use.</li> <li>The [Go to function] to [Using the User Box] or [Checking a Job] is available only when a Hard Disk is installed.</li> <li>Select [Copying] and press [Copying Special Documents]; instructions and animation guidance are displayed to enable the user to view the procedure for placing an original. However, Start Guidance is not displayed in the animation guidance for placing an original.</li> </ul>
[Function Map]	Check descriptions from a navigation destination of the current screen or the menu structure it belongs to.
[Other Functions]	Check descriptions by selecting a Guidance menu grouped by useful function.
[Name and Function of Parts]	Check the description of the main unit and its options.
[Service/Admin. Information]	Check the [Admin. Name], [Extension No.], and [E-Mail].

# **Settings**

[Consumables Re-	Use the animation guidance to check the procedure to replenish staples or
place/Processing Proce-	throw punch scraps away from the punch scrap box. Press the target but-
dure]*	ton, and then press [Start Guidance].

 $<sup>^{\</sup>star}$  This item is displayed only when a  $\textbf{Hard}\ \textbf{Disk}$  is installed.

4.10 C (Clear)

# 4.10 C (Clear)

Clears a value (such as the number of copies, a zoom ratio and size) entered using the keypad.

→ Press **C** (Clear).

The value is deleted. Enter the correct value.

# 4.11 Proof Copy

# Printing one set to check the copy result (Proof Copy)

Print a single proof copy for checking before printing a large number of copies. This prevents copy errors from occurring.

- ✓ To perform Proof Copy, specify multiple copies.
- 1 Load the original.
- 2 Select the desired copy settings.
- 3 Press the **Proof Copy** key.
- 4 Press [Print] and then select the original direction.
  - → This item is displayed only when a **Hard Disk** is installed.
- 5 Press the **Start** key.

This prints one copy when the original has been loaded in the ADF.

- When it has been loaded on the **Original Glass**, press the [Finish], then the **Start** key. A single proof copy is printed.
- 7 Check the proof copy.
  - → If the proof copy is found all right, go to Step 10. To change the copy settings, go to Step 8.
- Press [Change Setting] in the proof copy screen.

After changing the copy settings in the Change Settings screen, press [OK]

- → [Number of Sets] in the proof copy screen indicates the number of sets printed in the proof copy mode/the number of sets specified to be printed, and [Total # of Pages Printed] indicates the number of sheets printed in the proof copy mode/the total number of sheets to be printed.
- → To stop copying while the screen for changing the settings is displayed, select the proof copy job to be stopped from the list of jobs in the left panel, and then press [Delete].
- → If no operation is performed for the specified length of time while this screen is displayed, the copy job for which proof copy has been completed is registered as a stored job and the basic settings screen appears again.
  - Stored job registration is performed when the System Auto Reset function is activated or one minute after (if System Auto Reset is set to [OFF]).



- 9 Press the **Proof Copy** key to repeat proof copy.
- 10 Press [Print].

The number of copies yet to be printed is registered as a copy job.

# Using a preview image to check the copy result (Advanced Preview)


Check the finishing image of a copy in the **Touch Panel** before printing. This prevents copy errors from occurring.

### Reference

- This function is available only when a **Hard Disk** is installed.
- ✓ When you scan the original using the [Program Jobs] function, scan all originals, press [Finish], and then check the [Advanced Preview].
- When you attempt to scan the original with an [Insert Image] specified, the machine scans the original first, and then the insert original. When this process is complete, you can check the [Advanced Preview].
- ✓ To use the [Book Copy] or [Booklet] function, no preview is available. Check the finishing state after printing.
- ✓ If [Copy Guard] is detected, you cannot check finishing.
- 1 Load the original.
- 2 Select the desired copy settings.
- 3 Press the **Proof Copy** key.
- 4 Press [Preview on Screen] for the proof copy method and then select the original direction.
- 5 Press the **Start** key.

The Preview (View Status) screen appears.

- 6 Check the preview image.
  - → To change the settings, press [View Pages]. Go to Step 7.
  - → To start printing, press the **Start** key.
  - → To scan another original, press [Finish], load the original, and then press the **Start** key.
- 7 Change the settings, and then press [View Status].



# **Settings**

[←Prev. Page]/ [Next Page →]	Switch from the current screen to either the previous or the next screen.
[Zoom]	Enlarge the preview image and check the details. Press [+] and [-] to change the zoom ratio from full size to 2, 4 or 8 times the normal size. To select a different area to be enlarged, touch the scroll bar arrows on the right and at the bottom side of the image.  The finishing state cannot be displayed if you change the display size.

Settings	
[Rotate Image]	Rotate the preview image 180 degrees in order to correct the orientation of the original if necessary.  Pressing rotates the currently displayed page.  Pressing [Rotate Pages] displays the Scanned Page List. Select the page to be rotated. Up to six scanned pages can be displayed. Press [↑] or [↓] to change the selection.
[View Finishing]	View the finishing settings using icons or in text on the preview screen, and check the finishing state.
[Change Setting]	Change the settings for the next original to be scanned.
[View Pages]/[View Status]	Switch between the [View Status] and [View Pages] tab in the Preview screen. Use [View Pages] to enable [Rotate Displayed Page] or [Change Setting], and stop scanning on [View Status].

# 8 Press the **Start** key.

Select this menu to start printing.

# Copy Function

# **5** Copy Function

You can configure the settings for multiple copy features by pressing buttons on the **Control Panel** or **Touch Panel**.

This chapter describes the functions that can be configured by pressing the buttons in the **Touch Panel**.



### Item

[Basic]	Configure the basic set	Configure the basic settings for making copies.		
[Original Setting]	Configure the type and	Configure the type and size of the original.		
[Original Type]	Configure the quality fo	Configure the quality for the original to optimize copy quality.		
[Application]	Configure the application settings for making copies.		p. 5-20	
Left panel	[Job List]	Check jobs currently being performed and jobs waiting to be performed.	p. 5-57	
	[Check Job]	Check the current settings and the result of the settings.	p. 5-59	

# 5.1 [Basic]

Configure the basic settings for making copies.



### Item

[Density/Background]	Press this button to specify the density for making copies.	p. 5-4
[Paper]	Press this button to configure the paper type and paper tray for making copies.	p. 5-5
[Zoom]	Press this button to select the zoom ratio of the image to be copied.	p. 5-7
[Duplex/ Combine]	Press this button to configure the double-sided copy and combined copy settings.	p. 5-8
[Finishing Program]	Configure frequently used offset and finishing settings in advance. You can activate preferred finishing functions by simply pressing this button.	p. 6-8
[Finishing]	Press this button to select the settings for sorting and the finishing state of copies.	p. 5-11
[Separate Scan]	Select this item to divide a large number of original and scan it in a number of batches.	p. 5-13
[Auto Rotate OFF]	Select this item to copy the original according to the paper orientation without rotating the image.	p. 5-14
[Language Selection]	Display the Language Selection screen to specify the language to be displayed on the <b>Touch Panel</b> . This item is not displayed when two shortcut keys are configured.	_
[Shortcut Key]	Allows you to arrange shortcut keys for the frequently used Application functions on the Basic screen.	_

# 5.1.1 [Density/Background]

Press this button to specify the density for making copies.

→ Press [Basic] → [Density/Background].



### **Settings**

[Density]	Adjust copy density.
[Background Removal Level]	Adjust the density of the background area for originals with colored background (newsprints, recycle paper, etc.) or originals on thin paper showing text or images from the back.  [Auto] can be specified only when the density is set to [Standard]. [Auto] is released if the density is not set to [Standard] even though [Background Removal Level] is set to [Auto].
[Background Removal]	Normally [Bleed Removal] is selected. However, when copying an original with colored background, select [Paper Discoloration Adj] to make adjustments for background removal for copying.

## 5.1.2 [Paper]

Select the paper type and size to be printed or change the paper size and paper type settings configured for each paper tray.

The paper size can be selected automatically according to the original size or it can be specified manually.

- The auto zoom setting and the auto paper setting cannot both be selected at the same time.
- ✔ If a setting for special paper is selected for a paper tray, that tray is not selected automatically with the Auto Paper setting. (However, a paper tray set to Single Side Only is given priority to be selected with 1-sided printing.) When setting special paper in the paper tray, be sure to set the paper type. For details on special paper, refer to page 12-2.
- → Press [Basic] → [Paper].



### **Settings**

[Auto]		Automatically se size.	Automatically selects the paper size according to the original size.				
1 to 4	Trays	Allows you to sp	Allows you to specify the paper manually.				
<b>@</b>	Bypass Tray						
[Change Tray Settings]		Specify the pape tray.	Specify the paper type and paper size for the selected paper tray.				
		[Paper Type]	Specify the paper type for the selected paper tray.				
		[Paper Size]	Specify the paper size for the selected paper tray. [Auto Detect]: Automatically detects the paper size. [Standard Size] (only for [Bypass Tray]): Specify a paper size to use the bypass tray as a paper tray dedicated to the paper size. [Custom Size] (only for [Bypass Tray]): Enter the paper size.				

# Configuring a custom size




# **Settings**

[X]/[Y]	Inch area: Press [+] or [ Metric area: Enter the	Inch area: Press [+] or [-] to specify the length [X] and width [Y] of the paper. Metric area: Enter the length [X] and width [Y] of the paper.			
[Store]	Register custom paper	Register custom paper sizes.			
	[memory1] to [memory5]	Select the memory button where the paper size is to be stored.			
	[Change Custom Size Name]	Rename memory button names.			

# 5.1.3 [Zoom]

Image size in the original can be enlarged or reduced.

- ✓ The auto zoom setting and the auto paper setting cannot both be selected at the same time.
- ✓ If the auto zoom setting is selected and an enlargement is to be copied on paper larger than the original, load the original with the same orientation as the paper.
- → Press [Basic] → [Zoom].



### **Settings**

[Auto]		The most appropriate zoom ratio is automatically selected based on the size of the loaded original and the specified paper size.			
[Full Size]	A copy that is the sa	A copy that is the same size as the original (100%) is produced.			
[Manual]	<ul> <li>Under [Set Individed</li> </ul>				
	[Set Zoom]	Enter the desired zoom and select the button to register the value with. [User Preset Zoom] indicates the registered zoom.			
[Minimal]	ified size. The image cutoff. Select this setting w	Copies an original image slightly smaller than the original size or the specified size. The image in the original is centered on the paper without any cutoff.  Select this setting when you want to copy the entire scope of the original within the paper used.			
[-]/[+]	Configure the zoom the aspect ratio.	Configure the zoom ratio (25.0% - 400.0%) of the copy without changing the aspect ratio.			
[Fixed Zoom]	Select a preset zoor size paper.	Select a preset zoom when copying from a fixed size original onto a fixed size paper.			
[User Preset Zoom]		Select a registered copy zoom value. To change the registered zoom values, use [Set Zoom].			



To set image rotation:

Press the **Utility/Counter** key → [User Settings] → [Copier Settings] → [Enlargement Rotation].

# 5.1.4 [Duplex/Combine]


Single-sided or double-sided for both the original and the copy can be specified. Multiple (2, 4 or 8) pages of original images can be reduced in size and printed on a single page.

Using the [Duplex/Combine] function, you can save paper sheets for copying.

→ Press [Basic] → [Duplex/Combine].




### **Settings**



Settings					
[Binding Position]	Without setting the [Bir you intended.	Configure the binding position of the original and copies to be output. Without setting the [Binding Position], the resulting copy may not be what you intended.  When [1-Sided > 1-Sided] is selected, the [Binding Position] cannot be set.			
	[Original Binding Position]	Select the original binding position from [Left Bind], [Right Bind], [Top] and [Auto].  If the binding position for the original is set t [Auto], the position of the binding margin is automatically selected. A page margin position along the long side of the paper is selected if the original length is 11-11/16 inches (297 mm) or less. A page margin along the short side of the paper is selected if the original length exceeds 11-11/16 inches (297 mm).  If [Auto] is selected for the original binding position, the binding margin is set at the top or on the left.			
	[Output Bind Position]	Select the output binding position from [Left Bind], [Right Bind], [Top] and [Auto].  If the binding position for the copy is set to [Auto], the binding position is automatically determined according to the orientation of the loaded original. If the original length is 11-11/16 inches (297 mm) or less, a binding position along the long side of the paper is selected. If the original length is more than 11-11/16 inches (297 mm), a binding position along the short side of the paper is selected.  If Output Binding Position is set to [Auto], the binding position is set at the top or on the left.			
[Original Direction]	Original Glass.	Without setting [Original Direction], the resulting copy may not be what you			
[No]	Disables combined cop	ру.			
[2in1]	Copies images on two	original pages on one sheet of paper.			
	Portrait original pages				
	Landscape original pag	Landscape original pages			

5

Setti	ngs
-------	-----



# 5.1.5 [Finishing]

Various settings can be selected for sorting and finishing copies fed into the copy output tray.

The number of punched holes varies depending on the country you are in.

- ✓ The staple function is available only if the optional Finisher FS-527 or Finisher FS-529 is installed.
- The Punch settings are available only if the Punch Kit PK-517 is installed on the optional Finisher FS-527.
- ✓ [Fold/Bind] is available only if the Saddle Stitcher SD-509 is installed on the optional Finisher FS-527.
- ✓ [Staple] cannot be used together with [Offset].
- [Half-Fold] and [Center Staple & Fold] cannot be used together with any of [Offset], [Staple], or [Punch].
- → Press [Basic] → [Finishing].



### **Settings**

[Sort] When multi-page originals are copied for multiple sets, copies can be fed out sorted by set of copies.

[Group] When multi-page originals are copied for multiple sets, copies can be fed out sorted by pages.

# 5

### **Settings**

### [Offset] [Yes]/[No]

Specify whether to separate each set of copies from another set in the output tray when copying multiple sets of multi-page originals.

When the Finisher FS-527, Finisher FS-529, or Job Separator JS-505 is not installed:

If the following conditions are met, printed copies are fed out and sorted in an alternating crisscross pattern.

- The 8-1/2×11, A4, or B5 size paper is used
- Paper of the same size and type is loaded with the □ orientation in one paper tray and with the □ orientation in another tray
- Auto paper selection is specified for the paper size setting




When the Finisher FS-527, Finisher FS-529, or Job Separator JS-505 is installed:

The copies are fed out and stacked on top of each other with each set shifted to separate it.



### [Fold/Bind]

Staples copy outputs in the center the paper or fold them in the center before discharging.



### [Staple]

Staples copies in corner or at two points before they are output.



### [Punch]

Punches holes in copies before they are output.



### [Position Setting]

Configure desired staple or hole-punch positions.


Select Auto, and the machine automatically judges the staple or punch positions for the paper relative to the original direction loaded.

- A staple or punch position along the long side of the paper is selected if the original length is 11-11/16 inches (297 mm) or less.
- A staple or punch position along the short side of the paper is selected if the original length exceeds 11-11/16 inches (297 mm).
- Staple or punching positions are set on the upper or left-side end.
- Be sure to load the original so that its top side is placed in the back.
- If desired, press [Original Direction], and then select the original direction.

# 5

# 5.1.6 [Separate Scan]

When the original contains pages exceeding the capacity of the **ADF**, you can divide the original into several batches to handle each lot as a single copy job. You can also use the copy function by switching between the **ADF** and the **Original Glass** for scanning the originals.



- Do not load original sheets beyond the upper limit for the ADF. It would cause jamming and/or spoiling of the original or failure of the machine.
- When making 2-sided or combined copies using the Original Glass, the machine can scan a number of original pages without enabling Separate Scan.
- 1 Load the original.
- 2 Press [Basic] → [Separate Scan].
- 3 Press the **Start** key.

The original is scanned.

- 4 Load the next batch of the original, and then press the **Start** key.
  - → To change the scanning settings, press [Change Setting].



- 5 Repeat Step 4 until all pages of the original are scanned.
- 6 After all original pages have been scanned, press [Finish].
- 7 Press the Start key.


# Reference

To set the Separate Scan output method:

Press the **Utility/Counter** key → [User Settings] → [Copier Settings] → [Separate Scan Output Method].

# 5.1.7 [Auto Rotate OFF]

Select this setting to copy the original according to the paper orientation without rotating the image.



- ✓ For some paper sizes or zoom values, part of the image may be cut off.
- → Press [Basic] → [Auto Rotate OFF].

# 5.2 [Original Setting]

Configure the original status or original direction for outputting desired copies.

Press [Original Setting].



# Settings

[Mixed Original]	Loads originals of different sizes into the ADF and scan them at a time.			
[Z-Folded Original]	Correctly detects the original size when folded originals are loaded into the <b>ADF</b> and copied.			
[Original Size]	Select [Auto] to detect the size of the original automatically. If the size of the original is not automatically detected, select the original size.			
	[Custom Size]	Enter the original size.		
	[Photo Size]	Select the photo size.		
[Binding Position]	Specify the original binding position (page margin) to prevent the copy from being printed upside-down when scanning a 2-sided original.			
	[Auto]	<ul> <li>Automatically configures the binding position of the original.</li> <li>A page margin position along the long side of the paper is selected if the original length is 11-11/16 inches (297 mm) or less.</li> <li>A page margin along the short side of the paper is selected if the original length exceeds 11-11/16 inches (297 mm).</li> </ul>		
[Original Direction]	When copying double-sided originals or making double-sided or combined copies, press this button to specify the direction in which the original is loaded into the <b>ADF</b> or placed on the <b>Original Glass</b> .			
[Despeckle]	Reduces the influence of a dirt of the <b>Slit Scan Glass</b> upon a copy output when loading an original in the <b>ADF</b> .			

# Copying mixed originals

Loads originals of different sizes into the ADF and scan them at a time.


To copy onto the same size as the original, select [Full Size] in [Zoom] and select [Auto] in [Paper]. To copy all original pages on paper of the same size, select [Auto] in [Zoom], and select the desired paper size in [Paper].

When [1-Sided > 2-Sided] is selected together with Auto Paper, the back side becomes blank if its paper size is different from that of the front side. For example, if a single-sided original is copied in the order of 11 x 17 (A3) and 8-1/2 x 11 (A4), it results in copying of the front side (11 x 17 (A3)) / back side (blank) and of the front side (8-1/2 x 11 (A4)) / back side (blank).

### NOTICE

Load all of the original pages into the ADF so that the top of the pages is toward the back or the left side of the machine.

- Slide the adjustable **Lateral Guide** of the **ADF** to fit the size of the largest original page.
- Arrange originals in the order you want them to be scanned and load them face up in the ADF.
- 3 Press [Original Setting].
- 4 Press [Mixed Original].
  - → To cancel the setting, press [Mixed Original] again to deselect it.



The following chart shows the possible combinations of standard-sized paper that can be used for the Mixed Original setting.

	Maximum Original Width							
Original Size	11 × 17 □ (A3□)	8-1/2 × 11 🖟 (A4🖟)	8-1/2 × 14 □ (B4□)	8-1/2 × 11 □ (A4□)	5-1/2 × 8-1/2 (A5 (A)	5-1/2 × 8-1/2□ (A5 □)	(B5 🖫)	(B5 <b>□</b> )
11 × 17 □ (A3□)	0	0	_	_	_	_	_	_
8-1/2 × 11 🖟 (A4🖟)	0	0	_	_	_	_	_	_
8-1/2 × 14 ☐ (B4☐)	0	0	0	-	-	_	0	_
8-1/2 × 11 ☐ (A4☐)	0	0	0	0	0	_	0	_
5-1/2 × 8-1/2 ☐ (A5 ☐)	_	-	0	0	0	_	0	_
5-1/2 × 8- 1/2 <b>□</b> (A5 <b>□</b> )	-	_	_	_	_	0	_	0
(B5 🖫)	0	0	0	_	_	_	0	_
(B5 🖃)	_	_	0	0	0	0	0	0

- O Possible to combine
- Not possible to combine

### **Copying Z-folded originals**


Correctly detects the original size when folded originals are loaded into the ADF and copied.

The length of the first page of the original is detected, and the subsequent pages are scanned as pages of the same size.

#### **NOTICE**

Unfold folded originals before loading them into the ADF. If the original is copied without being unfolded, a paper jam may occur.

- Load the original into the ADF.
- Press [Original Setting].
- 3 Press [Z-Folded Original].
  - → To cancel the setting, press [Z-Folded Original] again to dese-



5-17 bizhub 423/363/283/223

# 5.3 [Original Type]

Select the setting for the image type of the original to better adjust the copy quality.

→ Press [Original Type].



5.3 [Original Type]

### **Settings**

[Original Type]	Select the original type (text and image type) to obtain better copy quality.		
	[Text]	Copies originals containing only text. The edges of copied text are reproduced with sharpness, providing an image that is easy to read.	
	[Text/Photo]	[Photo Paper]: Select this setting to print photos from originals containing both text and images onto photographic paper. A smooth copy image is produced.  [Printed Photo]: Select this setting to copy printed originals containing both text and images, such as pamphlets or catalogs.	
	[Photo]	[Photo Paper]: Select this setting when the original photos are printed on photographic paper. Select this setting to produce better reproductions of halftone original images (photographs, etc.) that cannot be reproduced with the usual settings. A smooth copy image is produced.  [Printed Photo]: Select this setting to copy printed originals, such as pamphlets or catalogs. Halftone original images (photographs, etc.) that cannot be reproduced with the usual settings will be reproduced in as nearly an original state as possible.	
	[Dot Matrix Original]	Select this setting when copying originals containing only text that appears faint (such as that written with a pencil). The copied text is reproduced so that it is darker, making it easier to read.	
	[Copied Paper]	Select this setting to copy images (originals) printed using this machine.	
[Text Enhancement]	Adjust the text reproduction level for an original with a photo overlapping th text (background text) to clarify the text on the background.  To emphasize the text on the background, press [Darker Text] to adjust the setting toward +		

setting toward +.

To emphasize the background image, press [Lighter Text] to adjust the setting toward -.

[Text Enhancement] can be configured when an item other than [Photo] is selected.

5-19 bizhub 423/363/283/223

# 5.4 [Application]

Configure the application settings for making copies.



### Item


[Sheet/Cover/Chapter Insert]	Inserts another sheet of paper or adds a cover page to the paper for copying. You can also scan multiple copies of the original with different settings.	p. 5-21
[Edit Image]	Inverts the contrast or gradation of the original or prints the original in the mirror image. Click this button to adjust the image quality.	p. 5-29
[Book Copy/Repeat]	Configure the settings for a book or catalog. An original image can be repeatedly printed on a single sheet of paper.	p. 5-31
[Page Margin]	Select the binding margin (blank area) of the paper used for copying.	p. 5-35
[Image Adjust]	Configure the layout for the image when the paper is larger than the original.	p. 5-36
[Booklet]	Automatically arranges the page order of the scanned original and makes 2-sided 2 in 1 copies to produce a page layout for a center-bound book, such as a magazine.	p. 5-37
[Erase]	Erases unnecessary outside portion of the original body text or erases the area outside the original placed on the <b>Original Glass</b> .	p. 5-38
[Stamp/Composition]	Prints the date/time, page number or a stamp printed on copies. This function also allows you to embed information for preventing unauthorized copying in a document.	p. 5-40
[Card Shot]	Copies the contents of the front and back sides of a card-size original, for example, insurance card, driver's license, or business card, on one sheet.	p. 5-54
[Save in User Box] *	Saves the scanned original data in a User Box.	p. 5-55

<sup>\*</sup> This item is displayed only when a **Hard Disk** is installed.

### 5.4.1 [Sheet/Cover/Chapter Insert]

### [OHP Interleave]

Prevent copies printed onto OHP transparencies from sticking together because of the heat produced during copying by having paper (interleaves) inserted between the transparencies.



- Use interleaf paper with the same size as the OHP transparencies.
- ✓ The number of copies is fixed to one. The number value cannot be changed.
- ✓ The finishing function cannot be changed.
- ✓ Load transparencies into the Bypass Tray.
- ✓ Do not use a transparency that has been through the machine even once. It may lead to reduced print quality, a paper jam or a damage to the machine. (Even if a transparency has been discharged without printing, it cannot be reused.)
- 1 Load the original.
- 2 Load transparencies into the **Bypass Tray**. Load the interleave paper into the desired paper tray.
- 3 Set the [Paper Type] of the **Bypass Tray** to [Transparency] and press [OK].
- 4 Press [Application] → [Sheet/Cover/Chapter Insert] → [OHP Interleave].




#### **Settings**


[Interleave Paper]	Select the paper tray loaded with paper with a transparency interleaf.
[Transparency]	Indicates the paper size of the loaded transparency.

### [Cover Sheet]

Copies the front and back cover sheets onto separate paper when copying an original with a front/back cover sheet. When the original to copy does not have a front and back cover, you can insert blank sheets of paper as the front and back covers.



- Use paper of the same size for the body text and cover sheets, and ensure the same orientation of paper for both purposes.
- → Press [Application] → [Sheet/Cover/Chapter Insert] → [Cover Sheet].



#### **Settings**

[None]	Disables copying of the front/back cover and blank sheet insertion.		
[Front (Copy)]	For 1-sided copy: Copies the first page of the original onto paper for the front cover sheet. For 2-sided copy: Copies the second page of the original onto the back of the paper for the front cover sheet.		
[Front (Blank)]	Adds paper for the front cover sheet as the first page of the copy.		
[Back (Copy)]	For 1-sided copy: Copies the last page of the original onto the back cover page. For 2-sided copy: Copies the last two pages of the original the 2-sided copy mode onto both sides of the paper for the back cover when copying an original with an even number of pages.		
[Back (Blank)]	Add paper for the back cover sheet to the last page of the copy.		
[Paper]	Select the paper tray loaded with the paper for the front/back cover page or blank cover pages.		




To configure the 2-sided copy mode:

Press [Basic] ► [Duplex/Combine].

### [Insert Sheet]

A different sheet of paper (such as colored paper) can be inserted as specified pages in the copies. You can select from two options: [Copy] and [Blank] to enable or disable copying to the inserted sheet.

- You can specify up to 30 positions for insert sheets.
- Use paper of the same size for the sheets to be inserted and for the original copies, and ensure the same orientation of paper for both.
- Press [Application] → [Sheet/Cover/Chapter Insert] → [Insert Sheet].



Settings			
[P]	Specify where to insert sheets of a different paper type.		
[Sort]	Sorts specified pages in the ascending order.		
[Insert Paper]	Select the paper tray loaded with the paper to be inserted.		
[Copy]	Copies the original with the specified paper inserted for the specified pages. When setting the specified page to "2" For 1-sided copy: Inserts the specified paper as the second page of the copies, and copies the second page of the original onto it. For 2-sided copy: Leaves the back side of the first page of the copy blank, inserts the specified paper for the second page of the copy, and makes a 2-sided copy of the second and third pages of the original onto the inserted sheet.		
	REPORT 12 3 4 5 6 REPORT 1 1 2 4 6 REPORT 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		
[Blank]	Select this option to insert the specified paper sheet after the page you have		

specified.


When setting the specified page to "3"

For 1-sided copy:

Inserts the specified paper as the fourth page of the copy.

For 2-sided copy:

Leaves the back side of the second page of the copy blank, and inserts the specified paper for the third page of the copy.




### Reference

To configure the 2-sided copy mode:

Press [Basic] ► [Duplex/Combine].

### [Insert Image]

A multi-page original scanned on the **Original Glass** can be inserted at the pre-set location in an original first scanned with the **ADF**.



- With the Insert Image function, the inserted original is added after the specified page.
- ✓ You can specify up to 30 positions for the original to be inserted.
- ✓ If the original scanned on the Original Glass has more pages than the number of pages specified in the Insert Image screen, the remaining pages of the inserted original are printed at the end of the original.
- The original on the Original Glass is scanned with the same settings as for the original scanned in the ADF.
- ✓ If the original scanned on the Original Glass has fewer pages than the number of pages specified in the Insert Image screen, the missing insertion pages will not be printed.
- If the same page number is specified twice, two insertion original pages are added at the specified location.
- If the specified page number is greater than the total number of pages in the main original, the corresponding insertion original page is added at the end of the copy.
- 1 Load the original into the ADF.
- Press [Application] → [Sheet/Cover/Chapter Insert] → [Insert Image].




#### **Settings**

[P]	Specify the position to insert the page scanned through the <b>Original Glass</b> .	
[Sort]	Sorts specified pages in the ascending order.	

- 3 Press the Start key.
- 4 Place the original to be inserted on the **Original Glass**.


- 5 Press the **Start** key.
  - → To insert a multi-page original, repeat steps 4 and 5 until all pages of the insertion original are scanned in the order that they are to be inserted.



- 6 Press [Finish].
- 7 Press the **Start** key.
  Copying begins.

### [Chapters]

When making 2-sided copies, the pages specified as the first page of a chapter can be printed on the front side of the paper. If the document was arranged so that the specified page would be printed on the back side of a page, the page is left blank and the specified page is printed on the front side of the next page.



- ✓ You can set up to 30 positions for the first page of chapters.
- ✓ Enable the Chapters function to set [1-Sided > 2-Sided]. For a 2-sided original, select [2-Sided > 2-Sided].

  ed].
- Make sure that the paper loaded for the first page of the chapter and for text copies have the same size and orientation.

→ Press [Application] → [Sheet/Cover/Chapter Insert] → [Chapters].



#### **Settings**

[P]	Specify the first page of the chapters.
[Sort]	Sorts specified pages in the ascending order.
[Chapter Paper]	Specify the paper tray for paper to be inserted for the first page of the chapter.
[Copy Insert]	Makes copies of the first pages of the chapters on paper of a different type from that for the text pages.
[None]	Copies all pages with the same type of paper.

### Reference

To configure the 2-sided copy mode:

Press [Basic] ► [Duplex/Combine].


### [Program Jobs]

When the originals to be copied include different types of materials such as a 1-sided original for full size copying and a 2-sided original for enlarged copying among other things, you can use this setting for scanning various originals with different settings and then copy them all in a single copying job.

Different Zoom or Paper settings can be specified for a part of the original or Finishing settings or a numbering function can be set after the entire original is scanned, and then all copies can be printed together.


#### Reference

• This function is available only when a **Hard Disk** is installed.



- ✓ Up to 100 types of originals can be scanned.
- When configuring a program job, the [Group] setting cannot be selected in the [Finishing] screen. Instead, select [Sort].

- 1 Press [Application] → [Sheet/Cover/Chapter Insert] → [Program Jobs].
- 2 Select the desired copy settings, and then press the **Start** key.
- 3 Press [Fix].
  - → Press [Retry] to delete the scanned job. Press [Change Setting] to configure the copy settings.
  - → When the original has been loaded on the original glass, press [Finish].




- 4 Load the next original and press [Change Setting].
- 5 Select the desired copy settings, and then press the **Start** key.
  - → Repeat Steps 3 to 5 until all originals have been scanned.



6 After all original pages have been scanned, press [Finish].

7 Press [Yes].



8 Specify finish settings as needed.




9 Press [Start] or the **Start** key.

5.4 [Application]

## 5.4.2 [Edit Image]

### [Neg./Pos. Reverse]

Use this function to enable the original to be copied with the density and gradations of the image inversed. The images in the original are copied and output reversed like negative film of photographs.




- → Press [Application] → [Edit Image] → [Neg./Pos. Reverse].
  - → To cancel the Neg./Pos. Reverse function, press [Neg./Pos. Reverse] again.



### [Mirror Image]

Copy originals as mirror images.



→ Press [Application] → [Edit Image] → [Mirror Image].



#### **Settings**

[Original Size]	Select [Auto] to detect the size of the original automatically. If the size of the original is not automatically detected, select the original size.	
	[Custom Size]	Enter the original size.
	[Photo Size]	Select the photo size.

### [Image Adjustment]

Adjusts the image quality that meets an image based on the copied original.

1 Press [Application] → [Edit Image] → [Image Adjustment].



### **Settings**

[Contrast]	Adjust the copy density balance.
[Copy Density]	Adjust copy density (lighter or darker).

#### **Settings**

[Sharpness]

Adjust the sharpness to emphasize the edges of text so that copied text can be read more easily. You can make an overly sharp original image softer or a blurry image clearer.

### 2 Configure respective functions.

→ Press [Sample Copy] to see how it will appear with the currently specified quality adjustment settings.




## 5.4.3 [Book Copy/Repeat]

### [Book Copy]

Divides or does not divide page spreads (such as a book or catalog) into left and right pages to copy data.

This function enables copying with the **ADF** open by placing the original on the **Original Glass**. If necessary, you can place an original image at the center of the paper to copy.



- Place the original on the Original Glass.
- ✓ If [Book Copy] is selected, [Image Adjust] is set to [Centering] and [Erase] is set to [Non-Image Area Erase] automatically. For details on [Centering], refer to page 5-36. For details on [Non-Image Area Erase], refer to page 5-38. The automatically set [Centering] or [Non-Image Area Erase] can be cancelled.
- ✓ When [Book Spread] or [Separation] is selected, pressing the Start key starts printing.
- ✓ When [Front and Back Cover] is selected, the scanning operation starts with the front cover followed by scanning of the back cover, and ends with scanning of all two-page spreads of the body text in the order of the page numbers.
- When [Front Cover] is selected, all two-page spreads are scanned in order after the front cover.
- ✓ When [Front and Back Cover] or [Front Cover] is selected, wait until all pages in the original are scanned and then press [Finish] and then the Start key to start printing.

→ Press [Application] → [Book Copy/Repeat] → [Book Copy].




### **Settings**


[Book Spread]	Copies both pages of a two-page spread original as a one page original.		
[Separation]	Copies the right and left pages of two-page spreads separately in the order of the page numbers.		
[Front Cover]	Copies the front cover, the right and left pages of two-page spreads separately in the order of the page numbers, and the back cover in this order.		
[Front and Back Cover]	Copies the front cover, separate copies of each page in the page spreads and the back cover in the original page order.		
[Frame Erase]	Erases projection of the dark shadow around the book.		
	[Frame]	Configure the width of the area around the entire frame to be erased.	
	[Top],[Right], [Bot-tom], [Left]	Configure the width of the top, right side, bottom and left side of the frame to be erased.	
	[None]	Select this settings to not erase the frame.	
[Center Erase]	Erases projection of the dark shadow at the center of the book.		
[Binding Position]	Select the binding position of the original. To indicate it, select [Separation], [Front Cover], and [Front and Back Cover].		

### [Image Repeat]

An original image can be repeatedly printed on a single sheet of paper. Specify the original and paper sizes or the zoom to automatically calculate the number of images to be copied accordingly. Alternatively, specify the desired number of repetitions.



→ Press [Application] → [Book Copy/Repeat] → [Image Repeat].




#### **Settings**

001111190			
[With Margin]	Repeats copying of the scanned area of the original so that the copy area of the sheet is filled with the copied image. If the entire image does not fit into the copy area, the extra range is not copied.		
[Without Margin]	Repeats copying of the scanned area of the original so that the sheet is filled with the copied image. However, some parts of the image may be lost.		
[Auto Detect]	Automatically detects the area to be scanned.		
[Set Range]	Select [Auto] to detect the size of the original automatically.  If the size of the original is not automatically detected, or the reading range must be specified, select the original size.		
	[Custom Size]	Enter the original size.	
	[Photo Size]	Select the photo size.	
[2/4/8 Repeat]	[2 Repeat] [4 Repeat] [8 Repeat]	Repeats copying of the scanned area of the original as many times as specified. Note, however, that an image that does not fit within the size of the paper used is copied with partial cutoff. [Repeat Interval Settings] can be configured only for [2 Repeat].	
	[Repeat Interval Set- tings]	Specify the clearance between copied images.	

### [Booklet Original]

A catalog with its staples removed can be copied and bound with staples at the center to create copies of the original catalog.




- 1. Staples
- ✓ This item is available if the Saddle Stitcher SD-509 is installed in the optional Finisher FS-527.


#### NOTICE

Load a catalog with the staples removed.

- 1 Load the original.
  - → To use the **Original Glass**, position the pages in order, starting with the side that includes the first page, then the side that includes the second page, then the side that includes the third page.



→ To use the ADF, load the pages with the side that includes the first page on top.




- 2 Press [Application] → [Book Copy/Repeat] → [Booklet Original].
- 3 Press the Start key.
- 4 After all original pages have been scanned, press [Finish] and the **Start** key.


### 5.4.4 [Page Margin]

Copies can be printed with a binding margin so that the pages can easily be filed. When scanning a 2-sided original, you can specify the paper binding position (binding margin for the paper) to prevent the copy from being printed upside-down.


[Left]



[Top]



[Right]



- ✓ You can specify the binding position without creating a binding margin.
- ✓ For 2-sided copy, you need to set the paper binding position and the original direction. Otherwise, the original image may be copied up-side-down.
- ✓ If the positions of the staples or punched holes are different from the binding position, the positions of the staples or punched holes are given priority.
- ✓ If part of the image is lost when copied with the specified binding margin settings, reduce the zoom and perform copying.
- → Press [Application] → [Page Margin].



Se		

[Margin Position]	<ul> <li>Select an option from [Auto], [Left], [Top] and [Right].</li> <li>When Auto is selected, the binding position is automatically set.</li> <li>This function automatically determines the binding position according to the orientation of the loaded original. If the original length is 11-11/16 inches (297 mm) or less, a binding position along the long side of the paper is selected. If the original length is more than 11-11/16 inches (297 mm), a binding position along the short side of the paper is selected.</li> <li>The binding position is set on the upper or left-side end.</li> <li>Be sure to load the original so that its top side is placed in the back. If the original is loaded in any other orientation, this setting fails.</li> </ul>	
[Image Shift]	Adjust the image position according to the binding margin.	
	[Change Back Shift]	Adjust the image position on the back side of the paper in the 2-sided copy mode.
[Adjust Value]	<ul> <li>Inch area: Press [+] or [-] to specify the binding margin width (1/16 to 3/4 inch). When [None] is selected, the binding margin width is set to 0 inches.</li> <li>Metric area: Enter the binding margin width (0.1 to 20.0 mm). When [None] is selected, the binding margin width is set to 0 mm.</li> </ul>	
[Original Direction]	Select the orientation of the original loaded into the <b>ADF</b> or placed on the <b>Original Glass</b> .	




To set the zoom:

Press [Basic] → [Zoom].

# 5.4.5 [Image Adjust]

Copies the original image at the center of the paper when the paper is larger than the original.



→ Press [Application] → [Image Adjust].



### **Settings**


[Centering] Copies the original image at the center of the paper without enlarging it.

[Original Size]		Select [Auto] to detect the size of the original automatically.  If the size of the original is not automatically detected, select the original size.	
	[Custom Size]	Enter the original size.	
	[Photo Size]	Select the photo size.	


### 5.4.6 [Booklet]

The page order of the scanned original is automatically arranged to produce 2-sided 2 in 1 copies in a page layout for center binding, such as for a magazine.


#### [Left Bind]



#### [Right Bind]



- Center Staple & Fold or Half-Fold is available if the Saddle Stitcher SD-509 is installed in the optional Finisher FS-527.
- ✓ Generally, a multiple of 4 pages is required with a 1-sided original, and a multiple of 2 pages is required with a 2-sided original. If there are not enough pages, blank pages are automatically added at the end.
- ✓ If a booklet is selected with the Auto Paper Select enabled, the zoom is automatically set at 70.7%.
- → Press [Application] → [Booklet].



#### **Settings**

[Left Bind]/[Right Bind]	Select the output binding position for copies to be output.	
[Center Staple & Fold]	Staples copies at two places along the center, then folds the copies in half before feeding them out.	

•		•	
	≥tt		

[Half-Fold]	Feeds out a copied sheet by folding it in two.
[No]	This setting feeds out a copied sheet without Center Staple & Fold or Half-Fold.
[Paper]	Select the paper tray loaded with the desired paper.
[Cover Sheet]	Copies the front and back cover sheets onto separate paper when copying an original with a front/back cover sheet. When the original to copy does not have a front and back cover, you can insert blank sheets of paper as the front and back covers.

# Reference


To specify Auto Display Zoom Ratio:

Press the **Utility/Counter** key → [User Settings] → [Copier Settings] → [Auto Zoom for Combine/Booklet].

### 5.4.7 [Erase]

### [Frame Erase]

Copies can be produced by erasing shadows of punched holes, unnecessary areas around the original text, such as the transmission information on received faxes and the shadows of punched holes. All four sides around the original can be erased in the same width or in a different width for each side.



→ Press [Application] → [Erase] → [Frame Erase].



#### **Settings**

[Frame]	Erases the four sides of the original in the same width.
[Top] [Right] [Bottom] [Left]	Erases each frame side in a different width.
[+]/[-]	Press [+] or [-] to set the erasing width between 1/16 inch (0.1 mm) and 2 inches (50.0 mm). The erasing width can also be entered using the keypad.
[None]	Sets the erasing width to 0 inches (0 mm).

### [Non-Image Area Erase]


This function enables copying with the **ADF** open while having an original that cannot be loaded in the **ADF** placed at a desired position on the **Original Glass**.

The original is automatically detected and the area outside the original text is erased.


Erase methods include [Bevel] and [Rectangular]. [Bevel] is used when the background of the original is thin and [Rectangular] is used when it is dark.

You can place the original on any position without opening or closing the **ADF** so that you can make copies promptly. In addition, toner consumption will be reduced as the area outside the original text is erased.

[Rectangular]



#### [Bevel]



- If erasing is not performed as desired, set [Erase Operation] under [Erase Adjustment] in Administrator Settings.
- ✓ The size of the original automatically detected is 3/8 × 3/8 inch (10 × 10 mm) or larger. If the detection fails, a blank sheet of paper is output.
- ✓ You cannot make copies with the ADF closed.
- ✓ The original image may be defected at its top or end.
- → Press [Application] → [Erase] → [Non-Image Area Erase].



# Reference

To set Erase Operation:

Press the **Utility/Counter** key → [Administrator Settings] → [System Settings] → [Expert Adjustment] → [Erase Adjustment].

### 5.4.8 [Stamp/Composition]

Add date and time, page number, stamp, image, or header or footer to make copies.




#### Item

[Date/Time]	Adds date and time to copies.		
[Page Number]	Adds page numbers or chapter numbers to copies.		
[Stamp]	Adds preset or registered stamps to copies.		
[Copy Security]	Adds a hidden text for preventing unauthorized copying in a document when copying. This function also allows you to copy a text with copy inhibit information or password embedded.		
[Stamp Repeat]	Repeats copying of a stamp or the date and time onto the paper.		
[Header/Footer]	Adds date and time to the top or bottom of the paper to print copies.		
[Watermark]	Adds a watermark (watery text) to the center of the copied pages.		
[Overlay] *	Makes copies with the image of the first scanned original page overlapping the subsequent original images.		
[Registered Overlay]*	Saves an image of the scanned original as a registered overlay in the hard disk and later overlay the registered image on the copy of another original.		

<sup>\*</sup> This item is displayed only when a **Hard Disk** is installed.

### [Date/Time]

You can select the print position and notation format to print the date and time. Specify whether to print on all pages or only on the first page.



- ✓ The date/time stamp cannot be printed on blank pages inserted using the Cover Sheet, Insert Sheet
  and Chapters functions. Change the setting for printing on blank pages in Administrator Settings to enable blank page printing.
- ✓ The date/time as of scanning the original is stamped on the paper.

→ Press [Application] → [Stamp/Composition] → [Date/Time].



#### **Settings**

[Date Format]	Select the type (form	Select the type (format) of date and time notation.	
[Time Format]	<b>31</b> (	Select the type (format) of date and time notation. When [None] is selected, the time is not printed.	
[Pages]	Select to print the da	Select to print the date/time on all pages or only on the first page.	
[Print Position]	Select a position from	Select a position from the nine print position options.	
	[Adjust Position]	Adjust horizontal and vertical positions to be between 1/16 inch (0.1 mm) and 1-15/16 inch (50.0 mm).	
[Text Details]	Set the text size and	Set the text size and type.	




To enable printing on blank pages:

Press the Utility/Counter key -> [Administrator Settings] -> [System Settings] -> [Blank Page Print Settings].


## [Page Number]

You can select the print position and notation format to print page numbers and chapter numbers. Page and chapter numbers are printed on all pages.



✓ Page numbers cannot be printed on blank pages inserted using the Cover Sheet, Insert Sheet and
Chapters functions. Change the setting for printing on blank pages in Administrator Settings to enable
blank page printing.

→ Press [Application] → [Stamp/Composition] → [Page Number].



### **Settings**

[Starting Page Number]	Set [Page Number]	between -00000 and 00000 and set [Chapter] ha	
[Starting Page Number] [Starting Chapter Number]	<ul> <li>Set [Page Number] between -99999 and 99999, and set [Chapter] between -100 and 100.</li> <li>Press [*] to switch over the signs (+ and -) of the setting.</li> <li>If a negative value is specified, the numbers are not printed until the numbering reaches 1. For example, if "-1" was specified, the numbers are printed starting with "1" on the third copied page.</li> <li>The entered chapter number is printed if [1-1, 1-2] is selected under [Page Number Type].</li> </ul>		
[Page Number Type]	Select the type (format) of the page.		
[Insert Sheet Setting]	Set this parameter who functions together.	en using the Cover Sheet, Insert Sheet and Chapters	
	[Cover Sheet]	[Print on Front and Back Cover]: Prints on the front and back covers. [Print on Back Cover only]: Prints a page number on the back cover but not on the front cover. Page number printing starts with "2" for 1-sided copy and with "3" for 2-sided copy. [Do not print Page Number]: Disables printing on the front or back cover. Page number printing starts with "2" for 1-sided copy and with "3" for 2-sided copy.	
	[Insert Sheet (Copy)]	[Print Page #]: Prints on inserted pages. [Do Not Print #]: Counts but not prints on inserted pages. [Skip the Page(s)]: Disables counting and printing on inserted pages.	
	[Insert (Blank)]	[Do Not Print #]: Counts but not prints on inserted pages. [Skip the Page(s)]: Disables counting and printing on inserted pages.	
[Print Position]	Select a position from the nine print position options.		
	[Adjust Position]	Adjust horizontal and vertical positions to be between 1/16 inch (0.1 mm) and 1-15/16 inch (50.0 mm).	
[Text Details]	Set the text size and type.		

## Reference

To configure the settings for the Cover Sheet, Insert Sheet and Chapters functions:

Press [Application] ► [Sheet/Cover/Chapter Insert].

To configure the settings for the Chapters function:


Press [Application] → [Sheet/Cover/Chapter Insert] → [Chapters].

To enable printing on blank pages:

Press the Utility/Counter key -> [Administrator Settings] -> [System Settings] -> [Blank Page Print Settings].

### [Stamp]

You can select the print position and notation format to print the stamp. Select printing on all pages or only on the first page.



- A stamp refers to text with printing contents fixed and preset. You can also select a stamp registered with Copy Protection Utility.
- Stamps cannot be printed on blank pages inserted using the Cover Sheet, Insert Sheet and Chapters functions. Change the setting for printing on blank pages in Administrator Settings to enable blank page printing.
- → Press [Application] → [Stamp/Composition] → [Stamp].



### **Settings**

[Stamp Type/Preset Stamps]	Select a stamp to be p	rinted from the eight types available.	
[Pages]	Select to print the stamp on all pages or only on the first page.		
[Text Size]	Select the character size used for the stamp.		
[Print Position]	Select a position from the nine print position options.		
	[Adjust Position]	Adjust horizontal and vertical positions to be between 1/16 inch (0.1 mm) and 1-15/16 inch (50.0 mm).	




To enable printing on blank pages:

Press the Utility/Counter key → [Administrator Settings] → [System Settings] → [Blank Page Print Settings].

### [Copy Protect]

This function allows you to print a hidden text for preventing unauthorized copying, for example, a preset stamp such as Private or date, in the background without particular distinction. If you copy a document with Copy Protect printed, a text is highlighted on the entire sheet of paper to be printed, enabling you to know that the copy is not authorized.



- The copy protection text is printed on all pages. The page to start with cannot be specified.
- ✓ The selected copy protection text formats appear in the order they are placed, and can be used in combination for up to eight text lines.
- ✓ Use PageScope Web Connection or Copy Protection Utility to register a registered stamp.
- ✓ Multiple registered stamps or preset stamps cannot be selected.
- Press [Application] → [Stamp/Composition] → [Copy Security] → [Copy Protect].



#### **Settings**

[Registered Stamp]	Select one from registered stamps.	
[Preset Stamp]	Select a stamp to be printed from the eight types available.	
[Date/Time]	Select the type of date and time notation. When [None] is selected for Time Format, the time is not printed.  The date/time as of scanning the original is stamped on the paper.	
[Other]	[Job Number]	Select Yes to print the copy job number.
	[Serial Number]	Select Yes to print the serial number of this machine. For details on setting for the serial number, contact your service representative.
	[Distribution Control Number]	Prints the distribution control number.  Specify the distribution control number using a value between 1 and 99999999.
[Detail Settings]	Specify [Text Size], [Density], [Copy Protect Pattern], [Pattern Overwrite], and [Background Pattern].	

5.4 [Application]

#### **Settings**

[Position]

The angle can be changed when there are no more than four lines in the selected copy protection text.

[Change Pos./Delete]

Change the arrangement order. Select the target copy protection text and press [Up] or [Down]. To add a space to the copy protection text, press [Insert Space]. Press either [Up] or [Down] to move O that appears beside the specified copy protection text type, and then press [Insert]. To delete the copy protection text, press [Delete], and then press the button for the copy protection text to be deleted.




To delete a registered stamp:

Press the **Utility/Counter** key → [Administrator Settings] → [Security Settings] → [Stamp Settings] → [Delete Registered Stamp].

### [Copy Guard]

This function prints a document, embedding a Copy Guard pattern in a copy protect text, for example, a preset stamp such as Private or date.

If an attempt is made to copy copy-guarded sheets, the machine that supports this function scans a Copy Guard pattern, stops copying, and discards the currently running job.



- ✓ For a text, specify the desired one from [Preset Stamp] that is registered in advance.
- ✓ A copy guard is printed on all pages. The page to start with cannot be specified.
- ✓ The selected copy guards appear in the order they are placed, and can be used in combination for up to six text lines.
- ✓ [Preset Stamp], [Date/Time], and [Other] can be selected together.
- ✓ In [Preset Stamp], multiple copy guards cannot be selected.
- ✓ A copy guard cannot be printed on a colored paper, envelope, or transparency film.

→ Press [Application] → [Stamp/Composition] → [Copy Security] → [Copy Guard].



#### **Settings**

[Copy Guard Type]	[Preset Stamp]	Select a stamp to be printed from the eight types available.	
	[Date/Time]	Specify the type of the date or time to be printed on paper. The date/time as of scanning the original is stamped on the paper.	
	[Other]	Specify [Job Number], [Serial Number], and [Distribution Control Number] to be printed on paper. [Serial Number] is assigned at the time of shipment of this machine. For details on settings, contact your service representative.	
[Detail Settings]	Specify [Text Size], printed on paper.	Specify [Text Size], [Copy Guard Pattern], and [Background Pattern] to be printed on paper.	




To specify and detect a copy guard:

Press the **Utility/Counter** key → [Administrator Settings] → [Security Settings] → [Security Details] → [Copy Guard].

### [Password Copy]

This function prints a document, embedding a copy protect text, for example, a preset stamp such as Private or date, and a password for Password Copy.

If an attempt is made to copy password-copied sheets, the machine that supports this function scans a Password Copy pattern and prompts you to enter the password. When the correct password is entered, copying will start.



- For a text, specify the desired one from [Preset Stamp] that is registered in advance.
- ✓ A password copy is printed on all pages. The page to start with cannot be specified.
- The selected password copies appear in the order they are placed, and can be used in combination for up to six text lines.
- ✓ [Preset Stamp], [Date/Time], and [Other] can be selected together.
- ✓ In [Preset Stamp], multiple passwords cannot be selected.
- ✓ A password copy cannot be printed on a colored paper, envelope, or transparency film.
- ✓ If you fail to enter a password three times, the currently processed copy job will be erased.

- ✓ If a password is detected on copies with Zoom, Image Adjustment, Colored Paper, Envelope, or Transparency specified, the currently processed copy job will be erased.
- ✓ If multiple originals with different passwords are scanned, you will need to enter a password for each original.
- → Press [Application] → [Stamp/Composition] → [Copy Security] → [Password Copy].



#### **Settings**

[Stamp Type]	[Preset Stamp]	Select a stamp to be printed from the eight types available.
	[Date/Time]	Specify the type of the date or time to be printed on paper. The date/time as of scanning the original is stamped on the paper.
	[Other]	Specify [Job Number], [Serial Number], and [Distribution Control Number] to be printed on paper. [Serial Number] is assigned at the time of shipment of this machine. For details on settings, contact your service representative.
[Detail Settings]	Specify [Text Size], [Password Copy Pattern], and [Background Pattern] to be printed on paper.	


### Reference

To specify and detect a password copy:

Press the **Utility/Counter** key → [Administrator Settings] → [Security Settings] → [Security Details] → [Password Copy].


#### [Stamp Repeat]

You can print a stamp, the date and time, or other specified items on all pages of the copy.



- ✓ The printing contents of the Stamp Repeat function are printed on all pages.
- ✓ The selected stamps appear in the order they are placed, and can be used in combination for up to eight text lines.
- ✓ Use PageScope Web Connection or Copy Protection Utility to register a registered stamp.
- Multiple registered stamps or preset stamps cannot be selected.

→ Press [Application] → [Stamp/Composition] → [Stamp Repeat].



### **Settings**

[Registered Stamp]	Select one from registered stamps.	
[Preset Stamp]	Select a stamp to be printed from the eight types available.	
[Date/Time]	Select the type of date and time notation. When [None] is selected for Time Format, the time is not printed. The date/time as of scanning the original is stamped on the paper.	
[Other]	[Job Number]	Select Yes to print the copy job number.
	[Serial Number]	Select Yes to print the serial number of this machine. For details on setting for the serial number, contact your service representative.
	[Distribution Control Number]	Prints the distribution control number. Specify the distribution control number using a value between 1 and 99999999.
[Detail Settings]	Select [Text Size], [Density], or [Pattern Overwrite].	
[Position]	Change the angle as required when there are no more than four lines in the selected repeating stamp.	
	[Change Pos./Delete]	Change the arrangement order. Select the target Stamp Repeat and press [Up] or [Down]. To add a space to repeated stamps, press [Insert Space]. Press either [Up] or [Down] to move () that appears beside the specified Stamp Repeat, and then press [Insert]. To delete the Stamp Repeat text, press [Delete], and then press the button for the Stamp Repeat text to be deleted.




To delete a registered stamp:


Press the **Utility/Counter** key → [Administrator Settings] → [Security Settings] → [Stamp Settings] → [Delete Registered Stamp].

### [Header/Footer]

This setting enables printing the date/time and text at the top or the bottom of the paper. The date/time or a distribution number can be printed on each page. The header and footer can contain predetermined contents, but you can also temporarily change the contents.



- ✓ In order to use the Header/Footer function, a header/footer must be registered in advance in Administrator Settings. If no header/footer is registered in Administrator Settings, the [Header/Footer] menu does not appear.
- → Press [Application] → [Stamp/Composition] → [Header/Footer].



#### Settings

	0 1 1 1 1 16 1	
[Recall Header/Footer]	Select a header/footer to be used.	
[Check/Change Temporar-ily]	Check or temporarily change the contents of the registered header/footer.	
	[Header Settings]	Select to enable or disable printing of a head-
	[Footer Settings]	er/footer. To print a header/footer, configure the following settings: [Text]: Enter the text for the header/footer. [Date/Time]: Select the type of date and time notation. [Other]: Select to print or not to print the distribution control number, job number, or serial number.
	[Pages]	Select to print the header/footer on all pages or only on the first page.
	[Text Details]	Select [Text Size] and [Text Type].
[Reset]	Reset the settings to the initial contents.	

# Reference


To register a header/footer:

Press the **Utility/Counter** key → [Administrator Settings] → [System Settings] → [Stamp Settings] → [Head-er/Footer Settings].

### [Watermark]

You can print a watermark (light text) at the center of the paper. Select fixed preset text to be printed such as [Invalid Copy] and [Private].

Copying with a watermark enables explicit indication of the use of the copied paper. It also helps prevent unauthorized copy from the copied paper.



- The watermark is printed on all pages at an angle of 45 degrees. It is printed once per page.
- ✓ In case other settings affect the watermark printing to cause partial loss, the Watermark function is canceled upon copying.
- → Press [Application] → [Stamp/Composition] → [Watermark].



#### Settings

[Watermark Type]

Select a watermark from the eight types available. The watermark selected is printed over the original image.


### [Overlay]

Makes copies with the image of the first scanned original page overlapping the subsequent original images. For example, if you set Overlay to copy three original pages, two pages are output, including "a merged image of the first and second pages" and "a merged images of the first and the third pages".


The Overlay function is useful for overlay of text, pictures or figures not prepared in other Stamp/Composition functions on the original.

#### Reference

This function is available only when a Hard Disk is installed.



→ Press [Application] → [Stamp/Composition] → [Overlay].



### **Settings**


[Pages]	Select to print the overlay image on all pages or only on the first page. Selecting [1st Page Only] prints only on the second page of the original.		
[Original Size]	Select [Auto] to detect the size of the original automatically. If the size of the original is not automatically detected, select the original size.		
	[Custom Size]	Enter the original size.	
	[Photo Size]	Select the photo size.	
[Density]	Use the keypad to enter the density of an overlay image. (using a value between 20 to 100%)		
[Composition]	[Transparent]	Composes overlay image to be superimposed and increases the brightness of the image. This setting prevents an original from being hidden by the composed overlay image.	
	[Background Composition (Original)]	Composes the original as the background. The overlay image is superimposed on the original when they are printed.	
	[Back]	Composes the overlay image as the background. The original is superimposed on the overlay image when they are printed.	

### [Registered Overlay]

This function enables storing of an image from the scanned original as a registered overlay on the hard disk for later use in copying another original. It is useful to register frequently used overlay images.

#### Reference

• This function is available only when a **Hard Disk** is installed.



→ Press [Application] → [Stamp/Composition] → [Registered Overlay].



### **Settings**

[Recall Overlay Image]	Specify whether to print a registered overlay image on the front or back side.  Press an item to select an overlay image and configures its setting.  • You cannot select an overlay image when no overlay has been registered.	
	[Thumbnail View]/[Display Name]	In the thumb-nail view, you can check overlay images. In the Display Name mode, you can check overlay images using their file names. Select the desired overlay image.
	[Detail Settings]	<ul> <li>[Density]: Use the keypad to enter the density of an overlay image. (using a value between 20 to 100%)</li> <li>[Composition]: <ul> <li>[Transparent]</li> <li>Increases the brightness of the overlay image to be superimposed. This setting prevents an original from being hidden by the composed overlay image.</li> <li>[Background Composition (Original)]</li> <li>Composes the original as the background. The overlay image is superimposed on the original when they are printed.</li> <li>[Back]</li> <li>Composes the overlay image as the background. The original is superimposed on the overlay image when they are printed.</li> </ul> </li> </ul>
	[Image Details]	Check the [Name], [Registered Date], and [Image Size] of the overlay image. To confirm the enlarged overlay image, press [Preview].
[Register Overlay Image]	[New]	Enter the name of the overlay image to be registered.  Load the overlay image original on the original glass and press the <b>Start</b> key to have the overlay image registered.
	[Overwrite]	Select an overlay image to use for overwrite and press [Overwrite]. Load the overlay image original on the original glass and press the <b>Start</b> key to have the overlay image overwritten.
	[Delete]	Select an overlay image to be deleted and press [Delete].
	[Detail Settings]	[Density]: Specify the density of an overlay to be registered between 20% and 100%.
[Pages]	Select to print the overlay image on all pages or only on the first page.	
[Original Size]		the size of the original automatically. al is not automatically detected, select the original
	[Custom Size]	Enter the original size.
	[Photo Size]	Select the photo size.



To prohibit changing the overlay registration:


Press the **Utility/Counter** key → [Administrator Settings] → [System Settings] → [Restrict User Access] → [Restrict Access to Job Settings] → [Change Registered Overlay].

### **5.4.9** [Card Shot]


Separately scans the contents of the front and back sides of a card, for example, insurance card, driver's license, or business card, and copies them together on one sheet.

You can copy a card with the full size or enlarge an image to fit paper.

Using the card copy function, you can save the number of sheets to be used.



- ✓ A card must be placed in the erect mode on the original glass.
- ✓ The card copy function and the auto paper function cannot be selected at the same time.
- ✓ For some zoom values, part of the image may be cut off.
- → Press [Application] → [Card Shot].



### **Settings**

[Original Size]	Press [X] and [Y], and enter the size of the card to be copied. Also select the pre-specified size from [size1] to [size4].
[Layout]	Specify where to place the front and back sides of a card.
[Zoom]	You can copy a card with the full size or enlarge an image to fit paper.



To specify the default of Card Copy:

 $\textit{Press the \textit{Utility/Counter} key} \implies [\textit{Administrator Settings}] \implies [\textit{Copier Settings}] \implies [\textit{Card Shot Settings}].$ 

5.4 [Application]

# 5


## 5.4.10 [Save in User Box]

This function enables saving of data from the scanned originals on the hard disk (in the User Box) built in the machine. Documents saved in User Boxes can be printed when necessary.

For details on using documents saved in User Boxes, refer to the [User's Guide Box Operations].

### Reference

• This function is available only when a **Hard Disk** is installed.



→ Press [Application] → [Save in User Box].



### **Settings**

[User Box]	Select the destination User Box.
[Document Name]	Specify a document name for the read original. A name automatically assigned to the document appears. You can change the file name.
[Save & Print]	[Yes]: Select to copy the scanned original and save it in the specified User Box. [No]: Select to save the data of the scanned original in the specified User Box.

## 5.5 Left panel display

In the left panel of the basic settings screen, you can view the job list and the job status information.

You can also view the result of the settings being configured.







Job List

Check Job

### **Settings**

[Job List]	If the Left Panel Disp	Lists jobs currently being performed or waiting to be performed. If the Left Panel Display Default is set to [Status Display] in User Settings, the job status is displayed.	
	[Delete]	To delete a job, select the job from the job list, and then press [Delete].	
	[Job Details]	Opens the Job List screen.	
[Check Job]	Displays the result	of the settings being configured.	
	[Check Details]	Check or change the current copy settings.	

# Reference

To configure settings displayed as the default in the left panel:

Press the Utility/Counter key -> [User Settings] -> [Custom Display Settings] -> [Left Panel Display Default].

To prohibit other users from deleting jobs or to give permission to do so:

Press the **Utility/Counter** key → [Administrator Settings] → [System Settings] → [Restrict User Access] → [Restrict Access to Job Settings] → [Delete Other User Jobs].

To prohibit or permit change if the print priority of jobs:

Press the **Utility/Counter** key → [Administrator Settings] → [System Settings] → [Restrict User Access] → [Restrict Access to Job Settings] → [Changing Job Priority].

To hide the file name and destination in the job log:

Press the **Utility/Counter** key → [Administrator Settings] → [Security Settings] → [Security Details] → [Hide Personal Information].


To delete all job logs:

Press the **Utility/Counter** key → [Administrator Settings] → [Security Settings] → [Security Details] → [Initialize] → [Job History].

### 5.5.1 [Job List]

From the Job List screen, lists of jobs being performed by this machine and the jobs that have been performed in addition to the job details can be viewed, and the job settings can be changed.

- ✓ If user authentication settings have been applied and the machine is set so that jobs cannot be deleted by other users, the job is not deleted.
- If an Administrator Settings parameter was set so that the output priority of jobs cannot be changed, [Increase Priority] does not appear and the output priority of the jobs cannot be specified.
- ✓ When there is a job being printed, another job can be registered. Up to 251 jobs can be registered in total.
- ✓ If the authentication method is changed in Administrator Settings and all management data is cleared, the jobs in the [Job History] are deleted.
- → Press [Job List] → [Job Details] → [Print].



### **Settings**

[Print]	Opens the screen for checking print jobs.
[Send]	Opens the screen for checking fax and scan transmission jobs. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].
[Receive]	Opens the screen for checking fax reception jobs. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].
[Save]	Opens the screen for saving jobs. For details, refer to the [User's Guide Box Operations].

Ę

### **Settings**

[Current Jobs]	Lists the jobs currently	Lists the jobs currently processed. Check the current status.	
	[Delete]	Deletes a job.	
	[Increase Priority] (Displayed for the list of print jobs in process)	The currently processed print job is interrupted and printing of the job given priority begins. Printing of the interrupted job is automatically restarted once printing for the job given priority is finished. If the currently processed print job cannot be interrupted because it contains Fold or Staple, the job given priority is executed after the currently processed print job has been completed.	
	[Release Held Job] (Displayed for the list of print jobs in process)	Select to switch to the held job list and change the settings of, print, or delete a held job.  The held job list contains jobs that could not be printed because, for example, system auto reset was activated during the proof copy.  If desired, press [Change Setting] to change the copy settings.  For confirmation, press the <b>Preview</b> key to print a copy from a stored job.	
	[Check Job Set.]	Check job settings for stored jobs, jobs being printed, jobs queued to be printed, and held jobs.	
	[Detail]	Check the status, results, error details, user name, queued time, completed time, number of original pages and number of copies for jobs in process.  To delete the job, press [Delete] in the Detail screen.	
[Job History]	Lists completed jobs.  This list includes jobs that failed because of an error.  You can check the job logs and results.  Scanned Image] in the left panel displays the first page of lected job with a thumbnail. To display thumbnails in [Scanage], set [Job History Thumbnail Display] in [Administrator Settings] to [ON]. For details, refer to page 7-45.		
	[Deleted Jobs]	Displays only jobs that were deleted before they were finished.	
	[Finished Jobs]	Displays only jobs that were completed normally.	
	[All Jobs]	Displays all jobs.	
	[Detail]	Check the status, results, error details, user name, queued time, completed time, number of original pages and number of copies for jobs in the Job History list.	

## 5.5.2 [Check Job]

From the Check Job Settings screens, the current copy settings can be checked and changed if desired.

1 Press [Check Job] → [Check Details].




- 2 Check the copy settings. To change the copy settings, press the relevant button.
- 3 After checking the settings, press [Close].

# 6 [User Settings]

# 6 [User Settings]

[User Settings] are for setting items that a user can adjust as appropriate.

The contents of these setting items depend upon how the [Administrator Settings] are configured. [User Settings] cannot be initialized all at once. To initialize all settings, either manually reset them one by one or contact your service representative.



### **Settings**


[System Settings]	Configure the basic functions of this machine.
[Custom Display Settings]	Change the touch panel display to the convenience of the user.
[Copier Settings]	Configure the settings for copy functions to be used in copy operations.
[Scan/Fax Settings]	Configure setting for fax and scan operations.
[Printer Settings]	Configure setting is for the printer operations.
[Change Password]	Change the password for the user who is currently logged in.
[Change E-Mail Address]	Change the E-mail addresses specified for registered users.
[Change Icon]	Change the icons specified for registered users.
[Register Authentication Information] *	Register or delete the biometric authentication information or IC card authentication information of the current login user.
[Cellular Phone/PDA Set-ting]	Configure settings to print data from a cellular phone or PDA.

<sup>\*</sup> This item is displayed only when a **Hard Disk** is installed.

# 6.1 [System Settings]

Configure the basic functions of this machine.

→ Press the Utility/Counter key →[User Settings] → [System Settings].



### **Settings**

[Language Selection]	Select the language for display in the touch panel.	
[Measurement Unit Set- tings]	Select the units for the values displayed in the touch panel.	
[Paper Tray Settings]	[Auto Tray Selection Settings]	Select the trays to be selected automatically when the Auto Paper Select function is enabled. Also configure the priority for the auto tray switch operation to switch paper trays when it is enabled.  • Configure [Auto Paper Selection Setting] to use paper types other than plain paper as plain paper in a regular auto paper selection mode.
	[Auto Tray Switch ON/OFF]	Select whether a paper tray loaded with paper of the same size is selected automatically when a paper tray that was selected manually becomes empty while printing copies.
	[No Matching Paper in Tray Setting]	<ul> <li>Specify the action to be taken when the matching paper is not loaded into the specified paper tray.</li> <li>[Stop Printing (Tray Fixed)]     Printing stops.</li> <li>[Switch Trays (Tray Priority)]     Whether the matching paper is loaded into the specified paper tray is determined first. And if not, another tray that has the matching paper loaded (if any) is selected.</li> </ul>
	[Print Lists]	Select the paper tray used for printing lists, such as the sales counter and consumables indicators. Also select whether to print lists in 1-Sided or 2-Sided mode.
[Auto Color Level Adjust.]	Adjusts the criteria leve	el of an original in color or black and white.
[Power Save Settings]	Refer to page 7-3.	Appears when user access is permitted under [Ad-
[Output Settings]	Refer to page 7-4.	ministrator Settings].
[AE Level Adjustment]	Refer to page 7-8.	



### **Settings**

[Auto Paper Select for Small Original]	Specify the paper size to be used for a case where the original placed on the <b>Original Glass</b> is too small to be detected in Auto Paper mode.	
	[Copy on Small Size]	Prints on 5-1/2 × 8-1/2 (A5) size paper.  If 5-1/2 × 8-1/2 (A5) size paper is not loaded in the tray, a message appears instructing you to load 5-1/2 × 8-1/2 (A5) size paper in the bypass tray.
	[Copy on Let- ter][Copy on A4]	Prints on 8-1/2 × 11 (A4) size paper.
	[Prohibit Copy]	Starts printing when a paper tray is selected manually and the <b>Start</b> key is pressed.
[Blank Page Print Settings]	Appears when user access is permitted under [Administrator Settings]. For details, refer to page 7-20.	
[Page Number Print Position]	Specify a page number print position when printing page numbers after configuring 2-sided print or booklet settings. Select whether to print the page numbers on a same position on all pages or on positions symmetric with respect to the stapling position.	
[Select Keyboard]	Select the keyboard type displayed by default in the <b>Touch Panel</b> .	

### **Factory default**

ractory default	
[Language Selection]	[English]
[Measurement Unit Set- tings]	This value varies depending on the area.
[Auto Tray Selection Settings]	[Tray Priority] [Tray 1] ►► [Tray 2] ►► [Tray 3] ►► [Tray 4] When the optional paper tray is installed, [Tray 3] or [Tray 4] is displayed.
[Auto Tray Switch ON/OFF]	[Restrict]
[No Matching Paper in Tray Setting]	[Stop Printing (Tray Fixed)]
[Print Lists]	<ul><li>Tray 1</li><li>[1-Sided]</li></ul>
[Auto Color Level Adjust.]	Standard (3)
[Low Power Mode Set- tings]	15 min.
[Sleep Mode Settings]	20 min.
[Print/Fax Output Settings]	[Print]: [Page Print] [Fax]: [Batch Print]
[Output Tray Settings]	<ul> <li>[Copy]: [Tray 2]</li> <li>[Print]: [Tray 2]</li> <li>[Print Reports]: [Tray 1]</li> <li>[Fax]: [Tray 1]</li> <li>[Output Tray Settings] is displayed when the Finisher FS-527 or Job Separator JS-505 is installed.</li> <li>[Tray 3] is displayed when the Job Separator JS-603 is installed in the Finisher FS-527.</li> </ul>
[AE Level Adjustment]	Standard (2)
[Auto Paper Select for Small Original]	[Prohibit Copy]
[Blank Page Print Settings]	[Do Not Print]
[Page Number Print Position]	[Left & Right Bind: All the Same Top & Bottom Bind: All the Same]
[Select Keyboard]	[Local Keyboard]

# Reference

To enable Auto Paper:

Press [Basic] ►► [Paper] ►► [Auto].

To configure Background Removal to Auto:

Press [Basic] → [Density/Background] → [Auto].

# 6.2 [Custom Display Settings]

Change the touch panel display to the convenience of the user.

→ Press the **Utility/Counter** key **→**[User Settings] **→** [Custom Display Settings].



### **Settings**

[Copier Settings]	[Default Tab]	Select either the standard Basic tab or the Quick Copy tab as the basic settings screen in Copy mode.
	[Shortcut Key 1]	Allows you to allocate shortcut keys for frequently
	[Shortcut Key 2]	used Application functions to be added to the basic settings screen.  Pressing a shortcut key displays the desired setting screen.
	[Quick Settings 1]	Allows you to register setting conditions for fre-
	[Quick Settings 2]	quently used copy functions and place them on the basic settings screen.
	[Quick Settings 3]	The registered setting condition can be invoked
	[Quick Settings 4]	by only pressing the corresponding easy setting key.
	[Default Tab Density Settings]	Specify whether to display the copy density setting in the basic settings screen. If [ON] is selected, you can press [Dark] or [Light] in the basic settings screen to adjust the copy density.  If [ON] is selected, [Quick Settings 3] and [Quick Settings 4] cannot be specified.
[Scan/Fax Settings]	This setting is for the network scan, fax, and network fax operations. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].	
[User Box Settings]	Configure settings for the User Box operations. For details, refer to the [User's Guide Box Operations].	
[Copy Screen]	Configure whether to display the [Next Box Job], [Next Scan/Fax Job], or [Next Copy Job] button or messages when you program the next job during the printing operation.	
[FAX Active Screen]	This setting is for the fax and network fax operations. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].	
[Color Selection Settings]	Select the color used for indicating that the button is selected.	
[Left Panel Display Default]	[Left Panel Display Default]	Configure whether to display a list of jobs in process and in queue or to display the contents of the current Copy settings as the default display of the left panel.
	[Job Display Setting]	Configure whether to display a list of jobs in process and in queue or to display the progress of the current job in process, when the default display of the left panel set to [Job List].

# Settings

6.2

[Search Option Settings]	This setting is for the network scan, fax, and network fax operations. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations]
	tions].

### **Factory default**

1 dotory doladit	
[Default Tab]	[Basic]
[Shortcut Key 1]/[Shortcut Key 2]/[Quick Settings 1]/[Quick Settings 2]/[Quick Settings 3]/[Quick Settings 4]	[OFF]
[Default Tab Density Settings]	[OFF]
[Default Tab] (Fax/Scan Settings)	[Address Book]
[Program Default] (Fax/Scan Settings)	[PAGE1]
[Address Book Index Default] (Fax/Scan Settings)	[Favorites]
[Shortcut Key 1]/[Shortcut Key 2] (Fax/Scan Settings)	[OFF]
[Default Address Book] (Fax/Scan Settings)	[Index]
[Default Address Type] (Fax/Scan Settings)	[Group]
[Default Tab] (User Box Settings) *	[Sharing]
[Shortcut Key 1]/[Shortcut Key 2] (User Box Settings)	[OFF]
[Copy Operating Screen]	[No]
[TX Display]	[No]
[RX Display]	[No]
[Color Selection Settings]	[Green]
[Left Panel Display Default]	[Job List]
[Job Display Setting]	[List Display]
[Uppercase and Lower-case Letters]	[Differentiate]
[Search Option Screen]	[OFF]

<sup>\*</sup> This item is displayed only when a **Hard Disk** is installed.

# 6.3 [Copier Settings]

Configure the settings used by the copy functions.

→ Press the **Utility/Counter** key → [User Settings] → [Copier Settings].



### **Settings**

Configure whether to automatically specify Booklet when Center Staple and Fold is selected.  This item is displayed if the <b>Saddle Stitcher SD-509</b> is installed in the <b>Finisher FS-527</b> .	
Configure whether the preset zoom ratios are automatically selected when Combine or Booklet is selected in Auto Paper mode.  • Select the recommended zoom ratios for the following zoom settings: 2 in 1, Booklet: 70.7% 4 in 1: 50.0% 8 in 1: 35.3%	
Configure whether to output the copied pages automatically in Sort mode when copying multiple-page original using the <b>ADF</b> .	
Configure the initial values for the Copy function to be displayed when the power in turned on or the <b>Reset</b> key is pressed.	
[Current Setting]	The current settings are used as the default settings.
[Factory Default]	The factory settings are used as the default settings.
This setting is for the enlarged display screen operations. For details, refer to the [User's Guide Enlarge Display Operations].	
Configure whether to print or discard the job when the original orientation does not match that of paper in Auto Zoom mode.	
Configure the output for divided original loaded in the <b>ADF</b> or for multip pages of the original scanned on the <b>Original Glass</b> .	
[Page Print]	Printing of copies that can be printed begins while the original is being scanned.
[Batch Print]	Printing begins after all pages of the original have been scanned.
Configure whether to rotate and print a large-size original image when the original orientation does not match that of paper.	
Appears when user access is permitted under [Administrator Settings]. For details, refer to page 7-37.	
	and Fold is selected. This item is displayed if isher FS-527.  Configure whether the process of the recommendation of the select the



ttı		

[Half-Fold Specification]	Specify whether to apply Half-Fold together for all pages or for each page when handling a job containing multiple pages.  When Half-Hold is selected with Booklet, all pages are half-held together even if [One Sheet at a Time] is selected.  This item is displayed if the <b>Saddle Stitcher SD-509</b> is installed in the <b>Finisher FS-527</b> .  If the number of folded sheets exceeds three while [Multiple Sheets] is selected, a warning message is displayed prompting the user to cancel the setting.  When this item is specified from the printer driver, [Half-Fold] is released automatically for printing if the number of folded sheets exceeds three.
[Print Jobs During Copy Operation]	Appears when user access is permitted under [Administrator Settings]. For details, refer to page 7-37.
[Automatic Image Rotation]	
[Finishing Program]	Configure whether to display the Finishing Program button in the basic settings screen. To display the button, register the contents of the finishing program.  Register frequently used finishing functions so that you can set them at once by using the button that appears in the basic settings screen.  This item is available if the <b>Finisher FS-527</b> or <b>Finisher FS-529</b> is installed.
[Card Shot Settings]	Appears when user access is permitted under [Administrator Settings]. For details, refer to page 7-37.

# Factory default

[Auto Booklet ON when Fold & Staple]	[Auto Select Booklet]
[Auto Zoom for Com- bine/Booklet]	[Auto Display Zoom Ratio]
[Auto Sort/Group Selection]	[Yes]
[Default Copy Settings]	[Factory Default]
[When AMS Direction is Incorrect]	[Print]
[Separate Scan Output Method]	[Page Print]
[Enlargement Rotation]	[Allow]
[Auto Zoom (Platen)]	[OFF]
[Auto Zoom (ADF)]	[ON]
[Specify Default Tray when APS Off]	[Tray Before APS ON]
[Select Tray for Insert Sheet]	[Tray 2]
[Half-Fold Specification]	[Multiple Sheets]
[Print Jobs During Copy Operation]	[Accept]
[Automatic Image Rotation]	[When Auto Paper/Auto Zoom is set]
[Finishing Program]	[ON]
[Card Shot Settings]	- [Layout]: [Top/Bottom] - [Zoom]: [Full Size]

6.4 [Scan/Fax Settings]

# 6

# 6.4 [Scan/Fax Settings]

This setting is for the network scan, fax, and network fax operations. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].

# 6.5 [Printer Settings]

This setting is for the printer operations. For details, refer to the [User's Guide Print Operations].

# 6.6 [Change Password]

Change the password for the user who is currently logged in.

- A public user cannot use this function.
- Press the **Utility/Counter** key **→** [User Settings] **→** [Change Password].




- 2 Enter the previous password, and then press [OK].
- 3 Enter a new password.
- 4 Press [Password Confirmation], and enter the password again.
- 5 Press [OK].

The new password is registered.

# 6.7 [Change E-Mail Address]

Change the E-mail addresses specified as registered user information.

- ✓ When logged in as a registered user, you can change the E-mail address.
- ✓ Appears when user access is permitted under [Administrator Settings]. For details, refer to page 7-44.
- Press the **Utility/Counter** key **→** [User Settings] **→** [Change E-Mail Address].



- 2 Press [E-Mail Address].
- 3 Change the E-mail address.
- 4 Press [OK].

# 6.8 [Change Icon]

Change the icon specified as registered user information.

- ✓ When logged in as a registered user, you can change the icon.
- Press the **Utility/Counter** key **→** [User Settings] **→** [Change Icon].



2 Select the icon and press [OK].

# 6.9 [Register Authentication Information]

Register or delete the biometric authentication information or IC card authentication information about the registered users.

You can register or delete authentication information when performing the following operations.

- Select Utility/Counter→ [Administrator Settings]→ [System Settings]→ [Restrict User Access]→ [Restrict Access to Job Settings]→ [Biometric/IC Card Info. Registration]→ [Allow].
- Select **Utility/Counter→** [Administrator Settings]**→** [User Authentication/Account Track]**→** [User Authentication Settings]**→** [User Registration]**→** [Function Permission]**→** [Biometric/IC Card Info. Registration]**→** [Allow].
- Log in as a registered user.
- Press the **Utility/Counter** key **→**[ User Settings ]**→**[ Register Authentication Information].
- 2 Press [Edit].
  - → To delete authentication information, press [Delete]. For biometric authentication



For IC card authentication



3 Register authentication information.

For biometric authentication, place your finger on the authentication unit to scan the finger vein pattern.



- → Scan the finger vein pattern three times; reset the same finger each time and then press [Scan] for each scanning.
- → After scanning the finger vein patterns, place the same finger on the authentication unit, and press [Authentication Test].
- → If your finger vein patterns have been authenticated in the authentication test, press [New]. If authentication has failed, retry scanning the finger.

For IC card authentication, place your IC card on the authentication unit, and press [OK].



4 Press [Close].


# 6.10 [Cellular Phone/PDA Setting]

Configure settings to print data in a cellular phone or PDA through this machine. For details, refer to the [User's Guide Box Operations] or [User's Guide Print Operations].

# [Administrator Settings]

# 7 [Administrator Settings]

[Administrator Settings] are used only by the administrator to adjust the settings. Logging on to Administrator Settings requires the administrator password.



### **Settings**

_	
[System Settings]	Configure the basic functions of this machine.
[Administrator/Machine Settings]	Register administrator information and E-mail address of this machine.
[One-Touch/User Box Registration]	Configure settings for the User Box, network scan, fax, and network fax operations.
[User Authentication/Account Track]	Configure the authentication settings to restrict the functions of this machine.
[Network Settings]	Configure network settings.
[Copier Settings]	Configure the settings for copy functions to be used in copy operations.
[Printer Settings]	Configure settings for the print operations.
[Fax Settings]	Configure settings for the fax and network fax operations.
[System Connection]	Configure settings for the software, cellular phone, or PDA that can be accessed with this machine.
[Security Settings]	Configure settings to restrict the functions of this machine for processing secret data.
[License Settings] *	Enable an optional i-Option function.
[OpenAPI Authentication Management Setting] *	Configure settings to prevent our deprecated OpenAPI connection application from being registered in this machine.

<sup>\*</sup> This item is displayed only when a **Hard Disk** is installed.

# 7.1 [System Settings]

Configure the basic functions of this machine.

## 7.1.1 [Power Save Settings]

Configure the settings for the power-saving mode.

→ Press the **Utility/Counter** key **►** [Administrator Settings] **►** [System Settings] **ト** [Power Save Settings].



### **Settings**

[Low Power Mode Set- tings]	Enter a time period before switching to the lower power mode when this machine is not being operated.	
[Sleep Mode Settings]	Enter a time period before switching to the sleep mode when this machine is not being operated.	
[Power Save Key]	Configure the type of the power save function to be started when you press the <b>Power Save</b> key.	
	[Low Power]	Provides power-saving effect higher than normal.
	[Sleep]	Provides power-saving effect higher than the low power mode. However, the machine must be warm-up when restarting operations, therefore taking more preparation time than the low power mode.
[Enter Power Save Mode]	Configure settings for switching to the power save mode after printing documents from computers or receiving faxes.	
	[Normal]	Enters the power save mode when the time specified in Low Power Mode Settings has elapsed.
	[Immediately]	Enters the power save mode in a short time.
[Fax Board Power Save]	Specify whether to enable power save mode. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].	

### **Factory default**

[Low Power Mode Settings]	15 min.
[Sleep Mode Settings]	20 min.
[Power Save Key]	[Low Power]
[Enter Power Save Mode]	[Immediately]
[Fax Board Power Save]	[Yes]

## 7.1.2 [Output Settings]

Configure the settings for the output functions.

→ Utility/Counter key → [Administrator Settings] → [System Settings] → [Output Settings].



### **Settings**

[Print/Fax Output Settings]	This setting is for the print and fax operations. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations] and [User's Guide Print Operations].
[Output Tray Settings]	Configure an output tray given priority for outputting by function. This item is displayed if the <b>Finisher FS-527</b> or <b>Job Separator JS-505</b> is installed.
[Shift Output Each Job]	Select whether to shift the output paper for each job. This item is displayed if the <b>Finisher FS-527</b> , <b>Finisher FS-529</b> , or <b>Job Separator JS-505</b> is installed:


### **Factory default**

[Print/Fax Output Settings]	[Print]: [Page Print] [Fax]: [Batch Print]
[Output Tray Settings]	<ul> <li>[Copy]: [Tray 2]</li> <li>[Print]: [Tray 2]</li> <li>[Print Reports]: [Tray 1]</li> <li>[Fax]: [Tray 1]</li> <li>[Tray 3] is displayed if the Job Separator JS-603 is installed in the Finisher FS-527.</li> </ul>
[Shift Output Each Job]	[Yes]

## 7.1.3 [Date/Time Settings]

Configure the current date and time and the time zone.

→ Press the **Utility/Counter** key → [Administrator Settings] → [System Settings] → [Date/Time Settings].



### **Settings**

[Year]	Configure the current date and time.
[Monthly]	
[Daily]	
[Hour]	
[Minute]	
[Time Zone]	Configure the UTC (Coordinate Universal Time) related time zone.

## **Factory default**

[Time Zone] +00:	00
------------------	----



To cancel the current settings:

Press C (Clear).

## 7.1.4 [Daylight Saving Time]

Configure daylight saving time settings.

→ Press the **Utility/Counter** key → [Administrator Settings] → [System Settings] → [Daylight Saving Time].



### **Settings**

Specify whether to apply daylight saving time in the time display on this machine. If [Yes] is selected, this item displays the time that is ahead of the current time by the specified number of minutes. Specify a length of time between 1 and 150 minutes on a 1-minute basis to apply daylight saving time.

### **Factory default**

[Daylight Saving Time] [No]

## 7.1.5 [Weekly Timer Settings]

Configure the weekly timer in order to allow you to turn on and off this machine at the specified date and time.

- ✓ An exact date/time setting must be performed in advance.
- → Press the Utility/Counter key → [Administrator Settings] → [System Settings] → [Weekly Timer Settings].



### **Settings**

[Weekly Timer ON/OFF Settings]	Configure whether to use the weekly timer function.	
[Time Settings]	Configure the time of each day of the week to turn on and off this machine.	
	[Set All]	The setting for the selected day of the week is applied to the same day of the week in other weeks.
	[Delete]	Cancels the selected input value.
[Date Settings]	Configure the days wh cel the setting, press the	en timer operation is activated individually. To canne same day again.
	[Daily Setting]	Configure the days of the week when the timer operation is activated.
[Select Time for Power Save]	Configure the time to turn this machine off and on if you want to turn it off at a specific time, for example, during a lunch break.	
[Password for Non-Busi- ness Hours]	Configure whether to require a user to enter the password if the user uses this machine outside the specified time.  To make the user to enter the password, you need to specify the password.	

### **Factory default**

ractory acraam	
[Weekly Timer ON/OFF Settings]	[OFF]
[Select Time for Power Save]	[No]
[Password for Non-Busi- ness Hours]	[No]

## 7.1.6 [Restrict User Access]

Restrict the machine operation, or change or delete the copy programs by the user.

→ Press the Utility/Counter key → [Administrator Settings] → [System Settings] → [Restrict User Access].



### **Settings**

Settings			
[Copy Program Lock Settings]	Configure the registered copy programs that are prevented from being changed or deleted.		
[Delete Saved Copy Program]	Delete the registered copy programs.		
[Restrict Access to Job	Configure whether to allow users to configure the following settings.		
Settings]	[Changing Job Priority]	Configure whether to allow users to change the print priority of jobs.	
	[Delete Other User Jobs]	Configure whether to allow other users to delete jobs when the user authentication settings have been specified.	
	[Registering and Changing Addresses]	This setting is for the network scan, fax, and network fax operations. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].	
	[Changing Zoom Ratio]	Configure whether to allow users to change registered zoom ratios.	
	[Changing the "From" Address]	This setting is for the network scan operations. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].	
	[Change Registered Overlay] *	Configure whether to allow users to change registered image overlays.	
	[Biometric/IC Card Information Registra- tion] *	Configure whether to allow a registered user to register or delete biometric authentication information or IC card authentication information of the user.	
[Restrict Operation]	[Restrict Broadcast-ing]	This setting is for the network scan, fax, and network fax operations. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].	

### **Factory default**

[Changing Job Priority]	[Allow]
[Delete Other User Jobs]	[Restrict]
[Registering and Changing Addresses]	[Allow]
[Changing Zoom Ratio]	[Allow]

7.1

### **Factory default**

[Changing the "From" Address]	[Login User Address]
[Change Registered Over- lay] *	[Allow]
[Biometric/IC Card Information Registration] *	[Restrict]
[Restrict Broadcasting]	[No]

<sup>\*</sup> This item is displayed only when a **Hard Disk** is installed.

## 7.1.7 [Expert Adjustment]

Make adjustments so that output quality is increased.

→ Press the **Utility/Counter** key → [Administrator Settings] → [System Settings] → [Expert Adjustment].



### **Settings**

Settings			
[AE Level Adjustment]	Configure the initial value for AE (auto exposure). The higher the setting, the more that the original background is emphasized.		
[Printer Adjustment]	Adjust the starting print position a per type features.	and defective print images caused by pa-	
	Reference  The starting print position is factory-adjusted. Normally, you are not required to change the set values.		
	[Leading Edge Adjustment]	p. 7-11	
	[Centering]	p. 7-11	
	[Leading Edge Adjustment (Duplex Side 2)]	p. 7-11	
	[Centering (Duplex 2nd Side)]	p. 7-11	
	[Erase Leading Edge]	Adjust leading edge erase width. For details on displaying this item, contact your service representative.	
	[Vertical Adjustment]	Adjust the feed direction zoom ratio of paper types. For details on displaying this item, contact your service representative.	
	[Media Adjustment]	p. 7-12	

Settings			
[Finisher Adjustment]	Adjust the staple, folding, and punch position of the <b>Finisher FS-527</b> . Otherwise, adjust where to place the paper alignment plate of the <b>Finisher FS-529</b> .  This item is displayed if the <b>Finisher FS-527</b> or <b>Finisher FS-529</b> is installed.		
	Reference  Create a sample in advance, and then adjust them while checking the sample.		
	[Center Staple Position]	p. 7-12	
	[Half-Fold Position]	p. 7-13	
	[Punch Horizontal Position Adjustment]	p. 7-13	
	[Punch Regist Loop Size Adjust- ment]	p. 7-14	
	[Paper Alignment Plate Settings]	p. 7-14	
[Paper Separation Adjust- ment]	Adjust the paper position where the print.	he two sides are separated for 2-sided	
[Gradation Adjustment]	Adjust irregular gradation levels o	f print images.	
	[Maximum Density Adjustment]	This function is useful when the required printing result is not obtained, for example, the printing density is too high or too low. Scan the amount of toner adhered on an output test pattern, and adjust to the optimal density. For details, refer to page 7-14.	
	[Gradation Adjustment]	This function is useful when a print image is not reproduced with consistent density. Scan the density of an output test pattern and adjust to the optimal gradation. For details, refer to page 7-15.	
	[Initialization]	Clear the correction values of both [Maximum Density Adjustment] and [Gradation Adjustment], and return them to the factory default value (0). For details, refer to page 7-16.	
[Scanner Area]	Adjust the scan range of the scanner. For details on displaying this item, contact your service representative.		
[ADF Adjustment]	Make adjustments for scanning images in the <b>ADF</b> . For details on displaying this item, contact your service representative.		
[Line Detection]	[Prior Detection Setting]	Configure whether to issue an alert when the <b>Slit Scan Glass</b> is dirty.  • Select an alert display format and contamination detection level.	
	[Feed Cleaning Settings]	Configure whether to remove a dirt on the <b>Slit Scan Glass</b> each time one sheet of paper passes through the ADF when scanning an original using the <b>ADF</b> .	
[User Paper Settings]	Settings to configure include Basi	or [User Paper 1] through [User Paper 4]. ic Weight and Media Adjustment. , contact your service representative.	

7.1

### **Settings**

Settings		
[Erase Adjustment]	[Non-Image Area Erase Operation Settings]	Configure Non-Image Area operation settings. [Auto]: Automatically detects the background density of the original, and selects either [Bevel] or [Rectangular] accordingly. [Specify]: Allows you to manually specify an erase method and original density. As an erase method, select [Bevel] or [Rectangular]. Specify an original density from five levels.
[Maximum Density Adjust- ment]	This function is useful when the required printing result is not obtained, for example, the printing density is too high or too low.  Adjust the amount of toner that is to be adhered to the paper based on the printing density value set to the highest level in order to fine-adjust the entire printing density setting (amount of toner).  If the required printing density result is not obtained after the maximum density has been adjusted, contact your service representative.  Press [Dark] or [Light] to adjust the printing density.	
[Drum Dry]	If the room temperature changes rapidly or the humidity is high, dew may form around the photo conductor in this machine, causing smudgy images to be generated. In this case, using this function removes dew condensation from around the photo conductor.  Press <b>Start</b> to start drum dry processing.	
[Replenish Toner]	originals with many black areas, the	

### **Factory default**

,	
[AE Level Adjustment]	Standard (2)
[Leading Edge Adjustment]	0.0 mm
[Centering]	0.0 mm
[Leading Edge Adjustment (Duplex Side 2)]	0.0 mm
[Centering (Duplex 2nd Side)]	0.0 mm
[Media Adjustment]	[Auto]
[Center Staple Position]	0.0 mm
[Half-Fold Position]	0.0 mm
[Punch Horizontal Position Adjustment]	0
[Punch Regist Loop Size Adjustment]	0
[Paper Separation Adjust- ment]	0.0 mm
[Prior Detection Setting]	[Yes] [Warning Display]: [TYPE1] [Detection level]: [Std.]
[Feed Cleaning Settings]	[Clean]
[Non-Image Area Erase Operation Settings]	[Erase Operation]: [Specify] [Erase Method]: [Rectangular] [Original Density]: [1]

### **Factory default**

[Maximum Density Adjust-	[3]
ment]	

## [Leading Edge Adjustment]


Adjust the starting print position at the leading edge of each type of paper (with respect to the paper feed direction).

- Press the **Utility/Counter** key **→** [Administrator Settings] **→** [System Settings] **→** [Expert Adjustment] **→** [Printer Adjustment] **→** [Leading Edge Adjustment].
  - → To adjust the starting print position at the leading edge of the second side for 2-sided printing (with respect to the paper feed direction), press [Leading Edge Adjustment (Duplex Side 2)].
- Select a paper type to be adjusted.
- 3 Load the paper into the **Bypass Tray**.
- 4 Press the Start key.

A test pattern is printed.

- 5 Check that the distance from the starting print position of the test pattern to the edge of the paper (a) is 3/16 inches (4.2 mm).
  - → Press [+] or [-] to adjust the width.

    Press the **Start** key to print a test pattern.
- 6 Press [OK].



### [Centering]


Adjust the starting print position at the left edge of each paper tray (with respect to the paper feed direction).

- ✓ Only 8-1/2 × 11  $\square$  (A4  $\square$ ) paper can be used to adjust the **Bypass Tray**.
- Press the **Utility/Counter** key **→** [Administrator Settings] **→** [System Settings] **→** [Expert Adjustment] **→** [Printer Adjustment] **→** [Centering].
  - → To adjust the starting print position at the left edge of the second side for 2-sided printing (with respect to the paper feed direction), press [Centering (Duplex 2nd Side)].
- Select a paper tray to be adjusted.
- 3 Press the **Start** key.

A test pattern is printed.

- 4 Check that the distance from the starting print position of the test pattern to the left edge of the paper (b) is  $1/8\pm1/32$  inches (3.0  $\pm$  0.5 mm).
  - → Press [+] or [-] to adjust the width.

    Press the **Start** key to print a test pattern.
- 5 Press [OK].




### [Media Adjustment]

Adjust defective print images caused by paper type features.

- Press the **Utility/Counter** key **►►** [Administrator Settings] **►►** [System Settings] **►►** [Expert Adjustment] **►►** [Printer Adjustment] **►►** [Media Adjustment].
- Select a paper type to be adjusted.
  - → If defective images exist on the back side of 2-sided copy paper, select [2nd Side].
- 3 Press [+] or [-] to specify an adjusted value.
  - → If missing parts or white spots exist in print images, press [-]. If the surface of the print image is rough, press [+].
- 4 Press [OK] **►►** [Close].
- 5 Copy, and then check the print image.

## [Center Staple Position]

Adjust the stapling position for each paper size when printing with the center staple function.



- Adjust the half-fold position before adjusting the center stapling position.
- ✔ Before making any adjustments, create a sample using the center staple function. Adjust the center staple position while checking the created sample.
- ✓ This adjustment is available if the Saddle Stitcher SD-509 is installed.
- When stapling in parallel with the left edge of paper, contact your service representative.
- Press the **Utility/Counter** key **→** [Administrator Settings] **→** [System Settings] **→** [Expert Adjustment] **→** [Finisher Adjustment] **→** [Center Staple Position].
- Select the size of paper of which the center staple position is adjusted.
- 3 Press [+] or [-] to adjust the staple position while checking the sample.
- 4 Press [OK].
- 5 Create a sample, and check the print result.


# Reference

To adjust the half-fold position:

Press the **Utility/Counter** key → [Administrator Settings] → [System Settings] → [Expert Adjustment] → [Finisher Adjustment] → [Half-Fold Position].

#### [Half-Fold Position]


Adjust the center staple & fold and half-fold positions for each paper size.



- ✔ Before making any adjustments, create a sample using the half-fold function. Adjust the center staple position while checking the created sample.
- ✓ This adjustment is available if the Saddle Stitcher SD-509 is installed.
- When adjusting the half-fold position in parallel with the left edge of paper, contact your service representative.
- Press the **Utility/Counter** key **►►** [Administrator Settings] **►►** [System Settings] **►►** [Expert Adjustment] **►►** [Finisher Adjustment] **►►** [Half-Fold Position].
- Select the size of paper of which half-fold position is adjusted.
- 3 Press [+] or [-] to adjust the half-fold position while checking the sample.
- 4 Press [OK].
- 5 Create a sample, and check the print result.

### [Punch Horizontal Position Adjustment]

Adjust the horizontal position of the punched holes for each paper type.



- Before making any adjustments, create a sample using the punch settings. Adjust the center staple position while checking the created sample.
- ✓ This adjustment is available if the Punch Kit PK-517 is installed.
- Press **Utility/Counter** [Administrator Settings] [System Settings] [Expert Adjustment] [Finisher Adjustment] [Punch Horizontal Position Adjustment].
- Select the type of paper of which the horizontal punched hole position is adjusted.
- 3 Press [+] or [-] to adjust the punched hole position while checking the sample.
- 4 Press [OK].
- 5 Create a sample, and check the print result.

## [Punch Regist Loop Size Adjustment]

Correct the orientation of the paper and adjust the punched hole position to be parallel with the left edge of the paper. The angle of the punched hole is corrected by adjusting the resistance applied to the paper for each paper type.

- This adjustment is available if the Punch Kit PK-517 is installed.
- 1 Press the Utility/Counter key ➤ [Administrator Settings] ➤ [System Settings] ➤ [Expert Adjustment] ►► [Finisher Adjustment] ►► [Punch Regist Loop Size Adjustment].
- 2 Select a paper type for which the punched hole angle is adjusted.
- 3 Press [+] or [-] to adjust the punch position.
- 4 Press [OK].
- 5 Create a sample, and check the print result.

## [Paper Alignment Plate Settings]

Adjust the width of the paper alignment plate to align the output sheets of paper.

- This item is available if the Finisher FS-529 is installed.
- Press Utility/Counter→ [Administrator Settings]→ [System Settings]→ [Expert Adjustment]→ [Finisher Adjustment]►► [Paper Alignment Plate Settings].
- 2 Select the paper alignment plate position.
- 3 Press [+] or [-] to adjust the position.
- 4 Press [OK].

# [Maximum Density Adjustment]

This function is useful when the required printing result is not obtained, for example, the printing density is too high or too low. Scan the amount of toner adhered on an output test pattern, and adjust to the optimal density.

- Before correcting the maximum density, fine-adjust the printing density (amount of toner) using Maximum Density Adjustment.
- After correcting the maximum density, be sure to also correct the gradation.
- If the required printing density result is not obtained even after the maximum density has been corrected, contact your service representative.
- Press the **Utility/Counter** key **→** [Administrator Settings] **→** [System Settings] **→** [Expert Adjustment] ►► [Gradation Adjustment].



Press [Maximum Density Adjustment].

7-14 bizhub 423/363/283/223


- 3 Select paper used to output a test pattern.
  - $\rightarrow$  As a paper size, select 11 × 17  $\square$ , 8-1/2 × 11  $\square$ , A3  $\square$ , or A4  $\square$ .
  - → Paper in the Bypass Tray cannot be selected.
- 4 Press the Start key.
- 5 A test pattern is printed.
  - → Selecting 11 × 17 🖃 or A3 🖃 outputs one sheet, and selecting 8-1/2 × 11 🖫 or A4 🖫 outputs two sheets.
- 6 Place the printed test pattern on the Touch Panel in the orientation displayed in the Original Glass.
  - → For the test patterns of  $8-1/2 \times 11$   $\square$  or A4  $\square$ , place two output sheets side by side.
- Place 10 or more sheets of blank paper on top of the test pattern to prevent it from becoming transparent.
- 8 Close the ADF or Original Cover.
- 9 Press the **Start** key.

The test pattern is scanned.

#### [Gradation Adjustment]

This function is useful when a print image is not reproduced with consistent density. Scan the density of an output test pattern and adjust to the optimal gradation.

- Adjust the gradation three times.
- Press the **Utility/Counter** key **►►** [Administrator Settings] **►►** [System Settings] **►►** [Expert Adjustment] **►►** [Gradation Adjustment].



- 2 Press [Gradation Adjustment].
- 3 Select paper used to output a test pattern.
  - $\rightarrow$  As a paper size, select 11 × 17  $\square$ , 8-1/2 × 11  $\square$ , A3  $\square$ , or A4  $\square$ .
  - → Paper in the Bypass Tray cannot be selected.
- 4 Press the **Start** key.
- 5 A test pattern is printed.
  - → Selecting 11 × 17 □ or A3 □ outputs one sheet, and selecting 8-1/2 × 11 □ or A4 □ outputs two sheets.
- 6 Place the printed test pattern on the **Touch Panel** in the orientation displayed in the **Original Glass**.
  - $\rightarrow$  For the test patterns of 8-1/2 × 11  $\square$  or A4  $\square$ , place two output sheets side by side.

- 7
- Place 10 or more sheets of blank paper on top of the test pattern to prevent it from becoming transparent.
- 8 Close the ADF or Original Cover.
- 9 Press the Start key.
  The test pattern is scanned.
- 10 Repeat steps 2 through 9 two more times.

# [Initialize Adjustment Value]

Clear the correction values of both [Maximum Density Adjustment] and [Gradation Adjustment], and return them to the factory default value (0).

Press the **Utility/Counter** key **►** [Administrator Settings] **►** [System Settings] **►** [Expert Adjustment] **►** [Gradation Adjustment].



- 2 Press [Initialization].
- 3 Select [Initialize], and press the Start key.
  This starts resetting the correction value.

#### 7.1.8 [List/Counter]

Configure the job settings list print settings and paper count settings for this machine.

→ Press the Utility/Counter key → [Administrator Settings] → [System Settings] → [List/Counter].



#### **Settings**

#### **Settings**

[Paper Size/Type Counter]	Register a combination of paper size and paper type for a counter. Every time the counter is changed, the count is reset to 0.	
	[Counter Clear]	Resets the count to 0.
	[Paper Size]	Select the paper size of the counter.
	[Paper Type]	Select the paper type of the counter.


#### **Factory default**

[Job Settings List]	•	[1-Sided]
	•	Tray 1

## 7.1.9 [Reset Settings]

Configure auto reset settings.

- ✓ All settings performed in the following tabs during operation using the copy function are automatically reset to the initial settings after the specified time has elapsed. [Basic], [Original Setting], [Original Type], [Application]
- ✓ Even if [OFF] is selected for System Auto Reset Time, the system auto reset function operates when this machine is not used for one minute during user authentication/account track operations.
- Press the Utility/Counter key → [Administrator Settings] → [System Settings] → [Reset Settings].



#### **Settings**

[System Auto Reset]	[Priority Mode]	Configure a mode to be displayed in the system auto reset mode.
	[System Auto Reset Time]	Configure whether to perform system auto reset. Specify a time until the initial screen appears if this machine is not operated. The specified time is not canceled.
		Reference If user authentication or enhanced security mode is enabled, the administrator settings mode or user authentication mode is logged off according to the setting for System Auto Reset Time.
		In the enlarge display mode, the system auto reset mode is disabled.
[Auto Reset]	Specify a time until the	perform auto reset in the selected mode.  basic settings screen appears and the settings are es if this machine is not operated.

[Job Reset]	[When Account is changed]	Configure whether to reset the settings when you log off if the user authentication or account track settings have been configured.
	[When original is set on ADF]	Configure whether to reset the settings when an original is loaded in the <b>ADF</b> .
	[Next Job]	Configure whether to reset the following settings when the next job is selected.  • [Staple Setting]  • [Original Set/Bind Direction]  • [Reset Data After Job]  The destination of data is always reset.

[Priority Mode]	[Copy]
[System Auto Reset Time]	1 minute
[Auto Reset]	<ul><li>[Copy]: 1 Minute</li><li>[Fax/Scan]: 1 Minute</li><li>[User Box]: 1 Minute</li></ul>
[When Account is changed]	[Reset]
[When original is set on ADF]	[Do Not Reset]
[Next Job]	<ul> <li>[Staple Setting]: [OFF]</li> <li>[Original Set/Bind Direction]: [OFF]</li> <li>[Reset Data After Job]: [Reset All]</li> </ul>

# Reference

To configure user authentication/account track:

Press the **Utility/Counter** key → [Administrator Settings] → [User Authentication/Account Track] → [General Settings].

# 7.1.10 [User Box Settings]

This setting is for the User Box functions. For details, refer to the [User's Guide Box Operations].

## 7.1.11 [Standard Size Setting]

Configure settings relating to the capability for detecting original size and the foolscap paper sizes.

For details on displaying this item, contact your service representative.

→ Press the **Utility/Counter** key **>>** [Administrator Settings] **>>** [System Settings] **>>** [Standard Size Settings].



#### **Settings**

[Original Glass Original Size Detect]	Configure the capability for detecting original sizes.
[8 1/2 × 14/Foolscap Size Detection] (Metric area on- ly)	Specify whether to detect a size of 8-1/2 × 14 or a foolscap size.
[Foolscap Size Setting]	Select the size that you want to use when the paper size is close to 13 inches.

#### **Factory default**

[Original Glass Original Size Detect]	[Table 1]
[8 1/2 × 14/Foolscap Size Detection]	[8-1/2 × 14]
[Foolscap Size Setting]	[8 × 13]

# 7.1.12 [Stamp Settings]

Configure header and footer settings to be printed.

→ Press the **Utility/Counter** key → [Administrator Settings] → [System Settings] → [Stamp Settings].



_
7

Settings		
[Header/Footer Settings]	Register or change a header and footer. To use the header/footer function in Application Setting, a header and footer must be registered in advance.	
	[New]	<ul> <li>Enter a registration name, and then configure detailed header and footer settings.</li> <li>Configure whether to print a header and footer, and then configure print contents.</li> <li>[Text]: Enter text.</li> <li>[Date/Time]: Select a format to display the date and time.</li> <li>[Other]: Specify the distribution control number. Select whether to include the Job Number, Serial Number, and Account/User Name.</li> <li>Configure pages and text details.</li> <li>[Pages]: Select whether to print the header and footer on all pages or only on the first page.</li> <li>[Text Details]: Select the size and type of the text for the header and footer to be printed. The text color can also be specified when faxing or scanning.</li> </ul>
	[Delete]	Deletes the selected header or footer.
	[Check/Edit]	Change the selected header or footer.
[Fax TX Settings]		ax and network fax operations. [User's Guide Network Scan/Fax/Network Fax Op-

[Cav. TV Cattingsal	[[]]
[Fax TX Settings]	[Cancel]

# 7.1.13 [Blank Page Print Settings]

Configure whether to print stamps or overlay on blank pages.

Press the Utility/Counter key ►► [Administrator Settings] ►► [System Settings] ►► [Blank Page Print Settings].



#### **Settings**

Configure whether to print stamp/composition on blank pages.

#### **Factory default**

[Blank Page Print Settings]	[Do Not Print]

## 7.1.14 [Skip Job Operation Settings]

Configure whether to start processing for the next job when the current job stops due to running out of paper in the paper tray. Selecting [Yes] provides no print queue time due to job stopping.

Press the **Utility/Counter** key **►►** [Administrator Settings] **►►** [System Settings] **►►** [Skip Job Operation Settings].



#### **Settings**

[Fax]	Configure whether to skip a job in the fax mode.
[Other than Fax]	Configure whether to skip a job in a mode other than the fax mode.


#### **Factory default**

[Skip Job Operation Set-	[Fax]: [Yes]
tings]	[Other than Fax]: [Yes]

## 7.1.15 [Default Bypass Paper Type Setting]

Configure the initial settings for the paper type to be used for the bypass tray. The initial setting for the paper type is applied after the job finishes or the tray runs out of paper.

→ Press **Utility/Counter** → [Administrator Settings] → [System Settings] → [Default Bypass Paper Type Setting]



#### **Settings**


Configure whether to specify the initial setting for paper type for the bypass tray. When you specified this, select a paper type.

[Default Bypass Paper	[Yes]
Type Setting]	[Paper Type]: [Plain Paper]

# 7.1.16 [Page Number Print Position]

Specify a page number print position when printing page numbers after configuring 2-sided print or booklet settings. Select whether to print the page numbers on a same position on all pages or on positions symmetric with respect to the stapling position.

Press the **Utility/Counter** key **→** [Administrator Settings] **→** [System Settings] **→** [Page Number Print Position].



### **Settings**

[Left & Right Bind: All the		
Same Top & Bottom Bind:		
All the Same]		
FI 6: 6 DI I : DI I 6		

[Left & Right Bind: Symmetrical Top & Bottom Bind: All the Same]

[Left & Right Bind: Symmetrical Top & Bottom Bind: Symmetrical]

Select a desired print position.

#### **Factory default**

[Page Number Print Position]

[Left & Right Bind: All the Same Top & Bottom Bind: All the Same]

## 7.1.17 [Advanced Preview Setting]

Configure settings to fax or scan a document. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].

# 7.2 [Administrator/Machine Settings]

Register administrator information and E-mail address of this machine.

- ✓ The device name entered under the Input Machine Address may not be supported by your operating system.
- Press the Utility/Counter key → [Administrator Settings] → [Administrator/Machine Settings].



#### **Settings**

[Administrator Registra- tion]	Register administrator information displayed on the Service/Admin. Information screen of the Guidance screen and the From address for sending E-mail from this machine.
[Input Machine Address]	Register the device name and E-mail address of this machine. The device name is used as a part of the name of the file created on this machine. The E-mail address can be used for Internet fax.

#### **Factory default**

[Device Name]	The default abbreviation is input for the product name. If necessary, it can
	be changed freely.

# 7.3 [One-Touch/User Box Registration]

This setting is for the User Box, network scan, fax, and network fax operations. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations] and [User's Guide Box Operations].

# 7.4 [User Authentication/Account Track]

Configure the authentication settings to control the use of this machine.

Type and functions of authentication

- User Authentication
  - Appropriate for controlling users. To allow unregistered users to use this machine, public user settings are required.
- Restricts accessible functions.
- Counts the number of outputting and scanning by user.
- Configure whether to allow sending fax and E-mail in color for each user.
- The maximum number of copies that can be output can be specified for each user.
- Operates a Personal User Box for each user and group box.
- Controls the access allowed level of the destination.
- Prohibits jobs of other users from being deleted.
- Account Track
  - Appropriate for controlling groups or multiple users.
- Counts the number of outputting and scanning by account.
- Configure whether to allow sending fax and E-mail in color for each account.
- The maximum number of copies that can be output can be specified for each account.
- Operates the group box.

#### Reference

- Either user authentication or account track settings can be configured, or user authentication can be synchronized with account track. Settings can be configured for the both and used without being synchronized.
- A total of 1000 users and accounts can be registered. A total of 100 users and accounts can be registered when a Hard Disk is not installed.
- To register more than 1000, use PageScope Authentication Manager. You can register up to 30000
  users and accounts.
- The authentication using PageScope Authentication Manager is available only when a Hard Disk is installed.

### 7.4.1 [General Settings]

Configure the settings for enabling the authentication functions.

- ✔ Before registering a user, select an authentication method. If all management data is cleared after the authentication method was selected, the histories of the registered users, print, send, receive, and save jobs are deleted.
- → Press the Utility/Counter key → [Administrator Settings] → [User Authentication/Account Track] → [General Settings].



7
7

[User Authentication]	Configure whether to u	se user authentication.
	[OFF]	Disables user authentication.
	[ON (External Server)]	Restricts users who can access this machine us ing the external authentication server. This setting is available when external authentication server settings are configured.
	[ON (MFP)]	Restricts users who can access this machine us ing this machine.
[Public User Access]	Allows public user accepted.	esses when the enhanced security mode is disa-
	[Restrict]	Prohibits unregistered users from using this machine.
	[ON (With Login)]	A public user can use this machine after pressing [Public User Access] in the Login screen to log ir to this machine.
	[ON (Without Login)]	A public user can use this machine without log- ging in to this machine in the Login screen.
[Account Track]	[OFF]/[ON]	Configure whether to use the account track function.
[Account Track Input Meth-	Select an authenticatio	n method when configuring account track settings
od]	[Account Name & Password]	Enter the account name and password to log in
	[Password Only]	Enter only the password to log in.     You cannot configure this when user authen tication settings are configured.
[Synchronize User Authentication & Account Track]	Configure the authentication operation settings when both user authentication and account track settings are configured. Configure whether to automatically select the account assigned to the user during logging in.	
	[Synchronize]	Allows the user to log in to one account assigned to the user.  The user who succeeded in user authentication can log in without account track authentication.
		Reference This function is appropriate for managing each user by account.
	[Do Not Synchronize]	Allows the user to log in to some accounts. The user who succeeded in user authentication performs account track authentication to log in.
		Reference This function is appropriate when each user performs multiple duties and counting is performed by duty.
[When # of Jobs Reach Maximum]	Configure the action of this machine that is taken when the output count of the job reaches the limit specified for the user or account.	
	[Skip Job]	Stops the running job, and then automatically starts the next job.
	[Stop Job]	Stops all jobs.
[Number of User Counters Assigned]	Configure how many of a total of 1000 users and account registrations should be allowed for user registration at maximum. The remaining registration number is for accounts.  When user authentication and account track settings are configured, the number of counters assigned for users can be specified.  Up to 99 users can be registered when a <b>Hard Disk</b> is not installed.	

#### **Settings**

[Ticket Hold Time Setting]	Enter a time to hold the Kerberos authentication tickets. This item is available when the external server authentication settings are configured and	
	[Server Type] is set to [Active Directory].	

#### **Factory default**

[User Authentication]	[OFF]
[Public User Access]	[Restrict]
[Account Track]	[OFF]
[Account Track Input Method]	[Account Name & Password]
[Synchronize User Authentication & Account Track]	[Synchronize]
[Number of User Counters Assigned]	[Skip Job]
[Number of User Counters Assigned]	500
[Ticket Hold Time Setting]	60 min.

## Reference

To configure external server settings:

Press the **Utility/Counter** key → [Administrator Settings] → [User Authentication/Account Track] → [External Server Settings].

For details on enhanced security settings, contact your service representative.

# 7.4.2 [User Authentication Settings]

Configure the user and user counter management settings.

- When only user authentication settings are configured, User Authentication Setting are enabled.
- ✓ If only user authentication settings are configured, up to 1000 users can be registered. If user authentication and account track settings are configured, up to 500 users can be registered as initial settings.
- ✓ If only user authentication settings are configured while a Hard Disk is not installed, up to 100 users can be registered. If user authentication and account track settings are configured, up to 50 users can be registered as initial settings.
- Press the Utility/Counter key ► [Administrator Settings] ► [User Authentication/Account Track] ► [User Authentication Settings].



#### Settings

7.4

Settings			
[Administrative Settings]	[User Name List]	Configure whether to display a key to display a list of registered users in the Login screen. This item is enabled when the enhanced security settings are disabled.	
	[Default Function Permission]	Configure an initial value for function permission to users who are authenticated on the external server.	
	[ID & Print Settings] *	Configure whether to use the ID & print function. Also configure whether to immediately print unauthenticated jobs or public user job or save it in the ID & Print User Box.	
	[ID & Print Operation Settings] *	With the authentication unit installed, specify the screen transition and operation to be performed directly after the authentication has been completed by the authentication unit when ID & print jobs are stored.	
	[Default Operation Selection] *	In the Login screen for user authentication where ID and print jobs are stored, specify the default values for the operation to be carried out after authentication has been completed.  When using this machine while the ID & print function is disabled, the user can select [Access] to log in to this machine without specifying the operation to be carried out after authentication.	
[User Registration]	Register users who can access this machine. Select a desired registration number, and then press [Edit]. Settings for registered users can be changed.  Selecting a user and pressing [Delete] delete the selected user.  If public user access is allowed, functions available to public users can be restricted. To change the setting for public users, select the registration number "000".		
	[User Name]	<ul> <li>Enter a user name.</li> <li>Once a user name is registered, it cannot be changed.</li> <li>A user name that has already been registered cannot be used again.</li> </ul>	
	[Password]	Enter the password.	
	[E-Mail Address]	Enter an E-mail address.	
	[Account Name]	Specify the account track of the registered user when account track settings are configured. Before you select an account name, you must registered it.	
	[Output Permission]	Apply the following restrictions to the selected user or all users.  • [Send]  Configure whether to allow the user to send fax and E-mail in color.	
	[Max. Allowance Set]	Configure the max. allowance for the selected user or all users. When not specifying it, select [No Limit].  • [Total Allowance] Specify the number of copies that can be output by the user.	
	[Register Auth. Info.]	Press [Edit], and then register authentication information. This setting is available when the optional authentication unit is installed.	

### **Settings**

Comings	[Function Permission]	Restrict functions available to the selected user or all users. Specify whether to allow the following functions:  • [Copy]  • [Scan]  • [Fax]  • [Print]  • [User Box]  • [Print Sent Document]  • [Save to External Memory]  • [External Memory Document Scan] *  • [Manual Destination Input] (If [Allow] is selected, specify either to allow Manual Destination Input or manage the destination manually.)  • [Biometric/IC Card Information Registration]  • [Mobile/PDA]
	[Pause]	Suspends the use of this machine for the selected user. If [Stop Job] is selected, the specified user cannot log in to this machine.  It is convenient to set Suspend for users who do not use this machine temporarily or who have lost an IC card, instead of deleting them.  If [All Users] is selected, you can suspend the use of this machine for all the registered users.  If Suspend is selected for a specific account, it is also suspended for users who belong to that account even if [Continue Job] is selected for this setting.
	[lcon]	Select an icon.
[User Counter]	[Reset All Counters]	Resets all counters for all users.
	[Counter Details]	Shows the use status for the selected user.  Press [Clear Counter] to reset the counter.  The public user counter is specified for the last page.

## Factory default

[User Name List]	[OFF]
[Default Function Permission]	[Save to External Memory]/[External Memory Document Scan]: [Restrict] Other items: [Allow]
[ID & Print Settings] *	[ID & Print]: [OFF] (when the authentication unit is not installed) [ON] (when the authentication unit is installed) [Public User]: [Print Immediately]
[ID & Print Operation Settings] *	[Print All Jobs]
[Default Operation Selection]	[Begin Printing]
[Output Permission]	[Send]: [Allow]
[Max. Allowance Set]	[Total Allowance]: [No Limit]
[Function Permission]	[Copy]: [Allow] [Scan]: [Allow] [Fax]: [Allow] [Print]: [Allow] [User Box]: [Allow] [Print Sent Document]: [Allow] [Save to External Memory]: [Restrict] [External Memory Document Scan]: [Restrict] * [Manual Destination]: [Allow]/[Allow All] [Biometric/IC Card Info. Registration]: [Restrict] [Cellular Phone/PDA]: [Allow]

[Pause]	[Continue Job]
[lcon]	

<sup>\*</sup> This item is displayed only when a **Hard Disk** is installed.



To specify the maximum number of registrations for the user:

Press the **Utility/Counter** key → [Administrator Settings] → [User Authentication/Account Track] → [General Settings] → [Number of User Counters Assigned].

# 7.4.3 [Account Track Settings]

Configure the account and account counter management settings.

- ✓ When only account track settings are configured, Account Track Settings is enabled.
- If only account track settings are configured, up to 1000 accounts can be registered. If user authentication and account track settings are configured, up to 500 accounts can be registered as initial settings.
- ✓ If only account track settings are configured while a Hard Disk is not installed, up to 100 accounts can be registered. If user authentication and account track settings are configured, up to 50 accounts can be registered as initial settings.
- Press the Utility/Counter key ► [Administrator Settings] ► [User Authentication/Account Track] ► [Account Track Settings].



#### **Settings**

[Account Track Registration]	<ul> <li>Select a desired registration number, press [Edit], and then regis change the account.</li> <li>Select an account to be deleted, and the press [Delete].</li> </ul>	
	[Account Name]	Specify the account name.  • An account name that has already been registered cannot be used again.
	[Password]	Enter the password.

Setti	ings
-------	------

7.4

	[Output Permission]	Apply the following restrictions to the selected account or all accounts.  • [Send] Specify whether to allow the account members to send fax or E-mail in color.
	[Max. Allowance Set]	Configure the max. allowance for the selected account or all accounts. When not specifying it, select [No Limit].  • [Total Allowance] Configure the number of copies that can be output by a member of the account.
	[Pause]	Suspends the use of this machine for the selected account. If [Stop Job] is selected, the specified user cannot log in to this machine. It is convenient to set suspend for accounts that do not use this machine temporarily, instead of deleting them.  If [All Accounts] is selected, you can suspend the use of this machine for all registered accounts.  If [Stop Job] is selected, it is also suspended for users who belong to the accounts.
[Account Track Counter]	[Reset All Counters]	Resets all counters for all accounts.
	[Counter Details]	Shows the use status for the selected account. Press [Clear Counter] to reset the counter.

#### **Factory default**

[Output Permission]	[Send]: [Allow]
[Max. Allowance Set]	[Total Allowance]: [No Limit]



To specify the maximum number of registrations for the account:

Press the **Utility/Counter** key → [Administrator Settings] → [User Authentication/Account Track] → [General Settings] → [Number of User Counters Assigned].

# 7.4.4 [Print without Authentication]

This setting is for the print operations. For details, refer to the [User's Guide Print Operations].

### 7.4.5 [Print Counter List]

Select the paper tray and print format to be used for printing the counter list.

- This function is enabled when user authentication or account track settings are configured.
- Press **Utility/Counter** Key **►** [Administrator Settings] **►** [User Authentication/Account Track] **►** [Print Counter List].



#### **Settings**

[Paper Tray]	Select the desired paper tray.	
[Simplex/Duplex]	Select Print (1-Sided) or Print (2-Sided).	
[Print Item]	Configure whether to print all data or printing data only.	

#### **Factory default**

<ul><li> [Paper Tray]: Tray 1</li><li> [Simplex/Duplex]: [1-Sided]</li><li> [Print Item]: [All Data]</li></ul>
• [Print item]: [All Data]

# 7.4.6 [External Server Settings]

Configure the external server that performs user authentication.

Press the **Utility/Counter** key **→** [Administrator Settings] **→** [User Authentication/Account Track] **→** [External Server Settings].



#### **Settings**

Select a number for the desired external server. You can also change the settings for the registered servers.

#### **Settings**

[New]/[Edit]	[Server Name]	Enter the name of the external server.
	[Server Type]	Configure an external server type, and then configure the settings for required items.
[Delete]	Delete the selected external server.	
[Set as Default]	Configure an external server specified as the initial value. Select a desired server, and then press the [Set as Default] button.	



For details on configuring external server settings, refer to the [User's Guide Network Administrator].

# 7.4.7 [Limiting Access to Destinations]

This setting is for the network scan, fax, and network fax operations. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations] and [User's Guide Network Administrator].

## 7.4.8 [Authentication Device Settings]

Configure the authentication operations when the optional authentication unit is installed.

#### Reference

- This function is available only when a Hard Disk is installed.
- This setting is available when the optional authentication unit is installed.
- Press the Utility/Counter key ► [Administrator Settings] ► [User Authentication/Account Track] ► [Authentication Device Settings].





#### **Settings**

[General Settings]	[Card Authentication]	Displayed when the Authentication Unit (IC card type) AU-201 is installed.  • [IC Card Type] Select the type of the IC card to be used in this machine. The FeliCa card ([FeliCa], [SS-FC], [FCF], or [FCF (Campus)]) or Type A card ([Type A]) can be selected. If [FeliCa+Type A], [SSFC+Type A], [FCF+Type A], or [FCF (Campus) + Type A] is selected, both the FeliCa and Type A cards can be used in this machine at the same time. If [SSFC] or [SSFC+Type A] is selected, specify [Company Code] or [Company Identification Code].  • [Operation Settings] Specify how to log in to this machine. [IC Card Authentication] allows the user to log in by simply placing the IC card. [Card Authentication + Password] allows the user to log in by placing the IC card and entering the password.	
	[Bio Authentication]	Displayed when the Authentication Unit (biometric type) AU-102 is installed.  • [Beep Sound] Specify whether to output a beep when reading the finger vein pattern.  • [Operation Settings] Specify how to log in to this machine. [1-tomany authentication] allows the user to log in by simply placing his or her finger on the authentication unit. [1-to-1 authentication] allows the user to log in by entering the user name and placing his or her finger on the authentication unit.	
[Logoff Settings]	Configure whether to le	Configure whether to log out when scanning of the original finishes.	

# 7.4.9 [User/Account Common Setting]

Specify whether to display the logout confirmation screen when authentication is enabled.

- ✓ This function is enabled if authentication function settings have been configured.
- → Press the Utility/Counter key → [Administrator Settings] → [User Authentication/Account Track] → [User/Account Common Setting].



#### **Settings**

[Logout Confirmation Screen Display Setting] Configure whether to display the logout confirmation screen when you press the **Access** key to log out.

[Logout Confirmation	[ON]
Screen Display Setting]	

# 7.4.10 [Scan to Home Settings]

This setting is for the network scan operations. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations] and [User's Guide Network Administrator].

# 7.4.11 [Scan to Authorized Folder Settings]

This setting is for the network scan, fax, and network fax operations. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations] and [User's Guide Network Administrator].

# 7.5 [Network Settings]

This setting is for the network operations. For details, refer to the [User's Guide Network Administrator].

# 7.6 [Copier Settings]

Configure the settings used by the copy functions.

→ Press the **Utility/Counter** key **>>** [Administrator Settings] **>>** [Copier Settings].



#### **Settings**

[Auto Zoom (Platen)]	Configure whether Auto Select is automatically selected when a paper tray is selected manually while an original is placed on the <b>Original Glass</b> .	
[Auto Zoom (ADF)]	Configure whether Auto Select is automatically selected when a paper tray is selected manually while an original is placed in the <b>ADF</b> .	
[Specify Default Tray when APS Off]	Configure which paper tray to be selected when the APS (Auto Paper) setting is canceled.	
	[Tray Before APS ON]	Uses the paper tray specified before the APS was selected.
	[Default Tray]	Uses Tray 1.
[Select Tray for Insert Sheet]	Configure the default paper tray loaded with paper for the cover pages (front cover), inserted sheets and the chapter title pages.	
[Print Jobs During Copy Operation]	Configure whether to accept print data or fax data while a copy operation is being performed.	
	[Accept]	Accepts print data or fax data to print.
	[Receive Only]	Prints print data or fax data after the copy operation is finished.
[Automatic Image Rotation]	When the original orientation is different from paper orientation, the image is rotated depending on the setting. Configure when the image is automatically rotated.	
[Card Shot Settings]	Register card copy setting. If [Card Shot] is selected in [Application], the function can be invoked with the registered setting.	
	[Layout]	Specify where to place the front and back sides of a card.
	[Zoom]	Specify to copy a card with the full size or enlarge an image to fit paper.
	[Store Original Size]	Change and register the pre-specified original size or [Original Name].

#### **Factory default**

[Auto Zoom (Platen)]	[OFF]
[Auto Zoom (ADF)]	[ON]
[Specify Default Tray when APS Off]	[Tray Before APS ON]

[Select Tray for Insert Sheet]	[Tray 2]	
[Print Jobs During Copy Operation]	[Accept]	
[Automatic Image Rotation]	[When Auto Paper/Auto Zoom is set]	
[Card Shot Settings]	[Layout]: [Top/Bottom]     [Zoom]: [Full Size]	

# 7.7 [Printer Settings]

This setting is for the print operations. For details, refer to the [User's Guide Print Operations].



# 7.8 [Fax Settings]


This setting is for the fax and network fax operations. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].



# 7.9 [System Connection]

Configure settings for software, cellular phone, or PDA that can be accessed with this machine.

→ Press **Utility/Counter** → [Administrator Settings] → [System Connection].



### **Settings**

[OpenAPI Set- tings]	[Access Setting]	Specify whether to allow the user to access this machine from other system that is using OpenAPI.	
	[SSL/Port Set- tings]	[SSL Setting]	To use SSL encryption, select [SSL Only] or [SSL/Non-SSL].  If [Enhanced Security Mode] is enabled, [SSL Only] is enabled.
		[Port No.]	Enter a port number.
		[Port Number (SSL)]	Enter the port number to be used for SSL communication.
		[Client Certificate]	Specify whether to request for client certificates.  If you authenticate the client by requesting for its certificate (verification of client certificate), select [Enable].
		[Certificate Verification Level Settings]	To verify a certificate, configure settings to verify the certificate. [Expiration Date]: Select whether to check that the target certificate is within the validity period. [Key Usage]: Select whether to check that the certificate key is being used properly. [Chain]: Select whether to check that the certificate chain (certification path) is correct. [Expiration Date Confirmation]: Select whether to check the target certificate for validation. [CN]: Select whether to check that the CN of the certificate matches the server address.
	[Authentication]	Specify whether to authenticate an access from other system that is using OpenAPI.  To authenticate, enter the login name and password in [Login Name] and [Password].  When user authentication is performed or when acquiring the device information with the PageScope Authentication Manager, set the Authentication setting of the OpenAPI Setting screen of the machine to [OFF].	

### Settings

_	
[Prefix/Suffix Automatic Setting]	Select whether to automatically add prefix and suffix to a destination number. If [Prefix/Suffix Automatic Setting] is set to [ON], the other settings will be restricted. For details, refer to the [User's Guide Network Administrator].
[Printer Informa- tion]	Specify [Printer Name], [Printer Location], [Printer Information], and [Print URI]. The [Printer Information] setting is linked to [Printer Information] in [HTTP Server Settings].
[Cellular Phone/PDA Set- ting]	Specify whether to allow the user to print data in a cellular phone or PDA or save such data in a User Box.

## Factory default

[Access Setting]	[Allow]
[SSL Setting]	[Non-SSL Only]
[Request Client Certificate]	[Invalid]
[Expiration Date]	[Confirm]
[Key Usage]	[Do Not Confirm]
[Chain]	[Do Not Confirm]
[Expiration Date Confirmation]	[Do Not Confirm]
[CN]	[Do Not Confirm]
[Authentication]	[OFF]
[Prefix/Suffix Automatic Setting]	[OFF]
[Cellular Phone/PDA Setting]	[Restrict]

# 7.10 [Security Settings]

Configure the settings for the restricting the functions of this machine for processing secret data.

### 7.10.1 [Administrator Password]

Change the administrator password.

- ✓ The administrator password can be entered using 0 through 8 digits.
- ✓ If password rules are specified, an 8-digit password must be entered.
- If you enter an incorrect administrator password a configured number of times, you are prohibited from using this machine. In this case, contact your service representative.
- Press the Utility/Counter key ➤ [Administrator Settings] ➤ [Security Settings] ➤ [Administrator Password].



#### **Factory default**

[Administrator Password]

12345678

- 2 Enter the administrator password, and then press [OK].
- 3 Enter a new administrator password.
- 4 Press [Password Confirmation], and enter the administrator password again.
- 5 Press [OK].

The password is changed.

# Reference

To configure password rule settings:

Press the **Utility/Counter** key → [Administrator Settings] → [Security Settings] → [Security Details] → [Password Rules].

### 7.10.2 [User Box Administrator Setting]

Configure settings for the User Box operations. For details, refer to the [User's Guide Box Operations]. Reference

• This function is available only when a **Hard Disk** is installed.

# 7.10.3 [Administrator Security Levels]

Configure settings so that the user can change some of the settings accessible only to the administrator. Settings allowed to the user appear in User Settings.

→ Press **Utility/Counter** [Administrator Settings] [Security Settings] [Administrator Security Levels].



#### **Settings**

3 -	
[Level 1]	Allows the user to change the following settings.  In [Power Save Settings]  In [Auto Zoom (Platen)]  In [Auto Zoom (ADF)]  In [Specify Default Tray when APS Off]  In [Select Tray for Insert Sheet]  In [Automatic Image Rotation]  In [Card Shot Settings]
[Level 2]	Allows the user to change the following settings.  • All settings allowed in Level 1  • [Output Settings]  • [AE Level Adjustment]  • [Blank Page Print Settings]  • [Change E-Mail Address]  • [Print Jobs During Copy Operation]
[Prohibit]	Does not allow the user to change the settings allowed in Level 1 and Level 2.

#### **Factory default**

#### 7.10.4 [Security Details]

Configure security detail settings to restrict the functions of this machine. You can restrict the functions to enhance security.

Press the Utility/Counter key → [Administrator Settings] → [Security Settings] → [Security Details].



#### **Settings**

#### [Password Rules]

Configure whether to enable the password rules.

When enabled, the restrictions are applied to the following passwords. The set passwords must be changed to ones that meet the conditions.

- Administrator Password
- User password
- Account password
- User Box password
- · Security document password

#### <Conditions of the password rules>

- Specify a password in 8 or more digits.
- Uppercase and lowercase letters are differentiated.
- Only half-width symbols can be used. For some of the passwords, specification of """, "+", and "space" is restricted.
- A password that consists of a repetition of the same character cannot be specified.
- The same password as one before being changed cannot be registered.

# [Prohibited Functions When Authentication Error]

Configure restrictions on operation when you enter one of the following passwords incorrectly.

- User password
- Account password
- User Box password
- Security document password
- Administrator Password

[Mode 1]	Disables operations for a specified time if authentication fails.
[Mode 2]	Disables operations of the control panel if authentication fails.  Specify the max. allowance for authentication operation frequency.
[Release]	Releases the prohibited operations due to failure in authentication, enabling the operations.
[Release Time Set- tings]	Configure the length of time until prohibited operations are automatically released.

Settings		
[Confidential Document Access Method]	Synchronizes with the settings for [Prohibited Functions When Authentication Error], automatically changes it.  • [Mode 1]  Requires entering security document ID and password before selecting a security document from a User Box.  • [Mode 2]  Performs authentication based on the password after you enter the security document ID and select a security document from a User Box.	
[Manual Destination Input]	This setting is for the network scan, fax, and network fax operations. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].	
[Print Data Capture]	This setting is for the print operations. For details, refer to the [User's Guide Print Operations].	
[Job Log Settings] *	Configure job log settings to be obtained when power is turned off and on. Specify the type of obtain log and whether to permit overwriting. Pressing [Erase Job Log] erases the job log.	
[Restrict Fax TX]	This setting is for the fax and network fax operations. For details, refer the [User's Guide Network Scan/Fax/Network Fax Operations].	
[Hide Personal Information]		
[Hide Personal Information (MIB)]	Specify whether to display the file name, address, or User Box number as MIB information in Job List.	
[Display Activity Log]	This setting is for the fax and network fax operations. For details, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].	
[Initialize]	Initializes Job History, Network Settings, Copy Program, or Store Address.	
[Job History Thumbnail Display] *	Configure whether to perform thumbnail display when displaying the job history.	
[Secure Print Only]	This setting is for the print operations. For details, refer to the [User's Guide Print Operations].	
[Copy Guard]	<ul> <li>Specify whether to use the copy guard function.</li> <li>If [Copy Guard] is selected in [Application], you can embed copy inhibit information on paper. You can also detect copy inhibit information embedded on paper.</li> <li>This item is displayed when the optional Security Kit SC-507 is installed.</li> </ul>	
[Password Copy]	Specify whether to use the password copy function.     If [Password Copy] is selected in [Application], you can embed a password on paper. You can also detect a password embedded on paper.     This item is displayed when the optional <b>Security Kit SC-507</b> is installed.	

[Password Rules]	[Invalid]	
[Prohibited Functions When Authentication Error]	<ul> <li>[Prohibit Functions When Auth. Error]: [Mode 1]</li> <li>[Release Time Settings]: 5 min.</li> </ul>	
[Confidential Document Access Method]	[Mode 1]	
[Manual Destination Input]	[Allow All]	
[Print Data Capture]	[Allow]	
[Job Log Settings] *	[No]	
[Restrict Fax TX]	[OFF]	
[Hide Personal Information]	[OFF]	
[Hide Personal Information (MIB)]	[ON]	
[Display Activity Log]	[ON]	

[Job History Thumbnail Display] *	[OFF]
[Secure Print Only]	[No]
[Copy Guard]	[No]
[Password Copy]	[No]

<sup>\*</sup> This item is displayed only when a **Hard Disk** is installed.

## 7.10.5 [Enhanced Security Mode]

The enhanced security mode cannot be enabled when any of the current functional settings conflict with the enhanced security mode.

When the enhanced security mode is enabled, the settings required for the mode or the settings that have been forcibly switched when entering the mode cannot be changed.

### Required settings

To enable the enhanced security mode, the following settings must have been configured.

Administrator Settings	Required settings
[User Authentication/Account Track] / [General Settings] / [User Authentication]	Select either [ON (External Server)] or [ON (MFP)].  When you enable account track, select [Account Name & Password] for the account track input method.
[Security Settings] / [Administrator Password]	Set a password complying with password rules.
[Security Settings] / [HDD Settings] / [HDD Encryption Setting] *	Specify a HDD encryption passphrase.
[Security] / [PKI Settings] / [SSL Setting] in Page-Scope Web Connection	<ul> <li>Set [Mode using SSL/TLS] to [Admin. Mode] and [User Mode].</li> <li>Set [Encryption Strength] to [AES-256] or [3DES-168].</li> </ul>
<ul> <li>[Management Function Choice]</li> <li>[CE Password]</li> <li>[CE Authentication]</li> <li>[HDD] *</li> <li>All the settings above must be configured by your service representative.</li> </ul>	These items must be configured by your service representative. For details, contact your service representative.

<sup>\*</sup> This item is displayed only when a Hard Disk is installed.

#### Settings to forcibly changed

When the enhanced security is enabled, the following settings are forced.

- The changed settings will not revert when the enhanced security mode is turned off.
- After the password rules have been changed, any passwords that do not comply with the changed rules will not be authenticated. For details on the password rules, refer to page 7-45.
- For details on the network settings to be forcibly changed, refer to the [User's Guide Network Scan/Fax/Network Fax Operations].

Administrator Settings	Settings to forcibly changed
[System Settings] / [Restrict User Access] / [Restrict Access to Job Settings] / [Registering and Changing Addresses]	Set to [Restrict].
[User Authentication/Account Track] / [General Settings] / [Public User Access]	Set to [Restrict].

Administrator Settings	Settings to forcibly changed
[User Authentication/Account Track] / [User Authentication Settings] / [Administrative Settings] / [User Name List]	Set to [OFF].
[User Authentication/Account Track] / [Print without Authentication]	Set to [Restrict].
[Network Settings] / [FTP Settings] / [FTP Server Settings]	[FTP Server Settings] is not displayed.
[Network Settings] / [SNMP Settings] / [SNMP v1/v2c Settings]	[Write Setting] is set to [Invalid].
[Network Settings] / [SNMP Settings] / [SNMP v3 Settings]	In [Write User], [Security Level] cannot be set to [OFF].
[Network Settings] / [TCP Socket Settings]	[Use SSL/TLS] is set to [ON].
[Network Settings] / [WebDAV Settings] / [WebDAV Server Settings] / [SSL Setting]	Set to [SSL Only].
[System Connection] / [OpenAPI Settings]	Set to [SSL Only].
[Security Settings] / [User Box Administrator Setting] *	Set to [Restrict].
[Security Settings] / [Security Details] / [Password Rules]	Set to [Enable].
[Security Settings] / [Security Details] / [Prohibited Functions When Authentication Error]	<ul> <li>Set to [Mode 2], and the number of tries is set to 3.</li> <li>The number of tries can be changed to 1, 2, or 3.</li> </ul>
[Security Settings] / [Security Details] / [Prohibited Functions When Authentication Error] / [Release Time Settings]	The allowable setting range is limited to 5 or more minutes. This value cannot be less than 5 minutes.
[Security Settings] / [Security Details] / [Confidential Document Access Method]	Set to [Mode 2].
[Security Settings] / [Security Details] / [Print Data Capture]	Set to [Restrict].
[Security Settings] / [Security Details] / [Hide Personal Information (MIB)]	Set to [ON].
[Security Settings] / [Security Details] / [Initialize] / [Network Settings]	[Network Settings] is not displayed.
[Security Settings] / [Security Details] / [Job History Thumbnail Display] *	Set to [OFF].
[Security Settings] / [Image Log Transfer Settings] *	Set to [OFF].
Preview [Secure Document User Box]	Only the list is displayed before the password authentication is performed.
[Network] / [E-mail Setting] / [S/MIME] in Page- Scope Web Connection	[Automatically Obtain Certificates] is set to [OFF].
	[E-Mail Text Encrypt. Method] is set to [3DES].
[Maintenance] / [Reset] / [Network Setting Clear] in PageScope Web Connection	[Network Setting Clear] is not displayed.
[Security] / [Administrator Password Setting] in PageScope Web Connection	[Administrator Password Setting] is not displayed.
CS Remote Care	Restricts the device setting in the remote mode based on CS Remote Care.

<sup>\*</sup> This item is displayed only when a **Hard Disk** is installed.

If Enhanced Security settings is enabled, various security functions are configured to allow you to ensure higher-level security of data management. For details, contact your service representative. To enable the enhanced security mode, the following settings must first be configured. Different screens appear depending on the current settings.



#### 7.10.6 [HDD/SSD Settings]

This setting is for the hard disk operations. For details, refer to the [User's Guide Box Operations].

#### Reference

• [SSD Settings] is displayed only when a **Hard Disk** is installed.

# 7.10.7 [Function Management Settings]

Configure the settings for the network functions that are difficult to count.

→ Press Utility/Counter→ [Administrator Settings] → [Security Settings] → [Function Management Settings].



#### **Settings**

[Network Function Usage Settings]	[ON]	Configure the settings for the network management that are difficult to count when managing operations.
	[OFF]	<ul> <li>The following functions cannot be used if [Network Function Usage Settings] is set to [OFF].</li> <li>PC-FAX transmission</li> <li>Using the HDD TWAIN driver to view and retrieve documents in User Boxes</li> <li>Using PageScope Box Operator to view and retrieve documents in User Boxes</li> <li>Using PageScope Scan Direct to retrieve documents in User Boxes</li> <li>Box operations using PageScope Web Connection (The User Box tab does not appear.)</li> </ul>

#### **Factory default**

·	
[Network Function Usage Settings]	[ON]

# 7.10.8 [Stamp Settings]

Manage the stamp.

→ Press the **Utility/Counter** key → [Administrator Settings] → [Security Settings] → [Stamp Settings].



#### **Settings**

[Stamp Settings]	[Apply Stamps]	Configure whether to add a stamp when printing or sending. To add a stamp, configure stamp contents settings.
		Reference  If a stamp is added, print settings cannot be configured in [Stamp/Composition] of [Application].
	[Delete Registered Stamp]	<ul> <li>[Stamp]         Deletes all registered stamps.</li> <li>[Copy Protect/Stamp Repeat]         Deletes all stamps registered in Copy Protect and the stamp repeat function.</li> </ul>

#### **Factory default**

[Apply Stamps] [Printing]: [Do Not Apply] [Send]: [Do Not Apply]



To configure copy protect and stamp repeat settings:

Press [Application] → [Stamp/Composition].

# 7.10.9 [Driver Password Encryption Setting]

This setting is for the print operations. For details, refer to the [User's Guide Print Operations].

# 7.11 [License Settings]

Enables the optional functions of **i-Option LK-101**, **i-Option LK-102**, **i-Option LK-103**, or **i-Option LK-105**. For details on the enabling procedure, refer to the [Quick Guide Copy/Print/Fax/Scan/Box Operations].

#### Reference

- This function is available only when a **Hard Disk** is installed.
- ✓ You must purchase optional i-Option LK-101, i-Option LK-102, i-Option LK-103, or i-Option LK-105. For details, contact your service representative.
- → Press Utility/Counter→ [Administrator Settings] → [License Settings].



#### **Settings**

[Get Request Code]	Issue a request code for this machine to be registered in the license management server (LMS).
[Install License]	Enter the function code and license code obtained from the license management server (LMS).

#### Reference

You can confirm the enabled functions in [List of Enabled Functions] when the optional i-Option LK-101, i-Option LK-102, i-Option LK-103, or i-Option LK-105 function is enabled.

# 7.12 [OpenAPI Authentication Management Setting]

Configure settings to prevent our deprecated OpenAPI connection application from being registered in this machine.

For details, contact your service representative.

# 8 Maintenance

# 8 Maintenance

# 8.1 Paper

# 8.1.1 Checking the paper

#### Replenishment message

If a tray has run out of paper during printing, the message [Replenish paper or select another paper tray.] appears. Load paper in the paper tray that is highlighted in color.



#### Precautions regarding the use of paper

Do not use the following types of paper. Not observing these precautions may lead to reduced print quality, a paper jam or a damage to the machine.

- OHP transparencies that have already been fed through the machine (even if they are still blank))
- Paper that has been printed on with a heat-transfer printer or an inkjet printer
- Folded, curled, wrinkled, or torn paper
- Paper that has been left unwrapped for a long period of time
- Damp paper, perforated paper, or paper with punched holes
- Extremely smooth or extremely rough paper, or paper with an uneven surface
- Treated paper such as carbon-backed paper, thermal paper, pressure-sensitive paper, or iron-on transfer paper
- Paper that has been decorated with foil or embossing
- Paper of a non-standard shape (paper that is not rectangular)
- Paper that is bound with glue, staples or paper clips
- Paper with labels attached
- Paper with ribbons, hooks, buttons, etc., attached

# Paper storage

Store paper in a cool, dark location with little humidity. If the paper becomes damp, a paper jam may occur. Store the paper flat, not on its edge. Curled paper may cause a paper jam.

# 8.1.2 Loading paper

This section describes how to load paper into each tray.

If printing stops due to the tray being empty, load paper into the tray. Printing restarts automatically.

For the types of paper to be used, refer to page 12-2.

#### Loading paper in Tray 1, Tray 2, Tray 3, or Tray 4


The procedure for loading paper is common between Tray 1, Tray 2, Tray 3, and Tray 4.

The following procedure describes how to load paper into Tray 1.


- ✓ Tray 3 and Tray 4 are optional.
- ✓ When [Auto Detect] is selected on the [Paper] tab, the size of loaded paper is automatically detected.
- 1 Pull out **Tray 1**.
  - → 1. Film

#### **NOTICE**


Be careful not to touch the Film.



- 2 Slide the **Lateral Guide** to fit the size of paper being loaded.
  - → If the Lateral Guide are not positioned correctly for the loaded paper, the paper size will not be correctly detected.



- Load the paper into the tray so that the side of the paper to be printed on (the side facing up when the package was unwrapped) faces up.
  - → Do not load so many sheets of paper that the top of the stack is higher than the ▼ mark.
  - → If paper is curled, flatten it before loading it.
  - → If special paper is loaded, the paper type must be specified.
  - → Load letterhead paper so that the side to be printed on faces down.



4 Close Tray 1.




To configure paper settings:

Press [Basic] ► [Paper].

#### Loading paper in LCT

The following procedure describes how to load paper in LCT.


- ✓ LCT is an option.
- ✓ You cannot pull out the LCT tray when the Sub Power Switch is turned off. You cannot also pull out the LCT tray in the Low Power or Sleep mode.
- 1 Press Tray Release Button.
  - → This unlocks the LCT tray and slides the LCT tray slightly forward




- 2 Pull out the LCT tray.
  - → 1. Film


#### **NOTICE**

Be careful not to touch the Film.



- 3 Load paper into the right side of the LCT tray so that the side to be printed (the side facing up when the package was unwrapped) faces up.
  - → Do not load so many sheets of paper that the top of the stack is higher than the ▼ mark.
  - → Do not load the **LCT** tray with paper of a size other than that previously specified.
  - → If paper is curled, the paper type must be specified.
  - → If special paper is loaded, the paper type must be specified.
  - → Load letterhead paper so that the side to be printed on faces down.
- 4 Load paper into the left side of the LCT tray so that the side to be printed (the side facing up when the package was unwrapped) faces up.





5 Close the **LCT** tray.

# Reference


To configure paper settings:

Press [Basic] ►► [Paper].

# Loading paper into the Bypass Tray

- Open the Bypass Tray.
  - → To load large-sized paper, pull out the tray extension.


Be careful not to touch the surface of the Paper Take-Up Roller with your hand.



- With the side to be printed on facing down, insert the paper as far as possible into the feed slot.
  - → The image will be printed on the surface of the paper facing down when the paper is loaded into the bypass tray.
  - → Do not load so many sheets of paper that the top of the stack is higher than the ▼ mark.
  - → If paper is curled, flatten it before loading it.
  - → Push the **Lateral Guide** firmly up against the edges of the paper.
  - → Load letterhead paper so that the side to be printed on faces up.
  - → When loading postcards:

Load them in the a orientation, as shown in the illustration. To use postcards other than the


 $4 \times 6$  (A6) size, check the size of postcards to be used, and then specify the size on the Custom Size screen before using them.



→ When using envelopes:


Expel air from the envelopes, and then load them while holding the folds of the envelopes.

Load them with the flap side up, as shown in the illustration. The flap side of envelopes cannot be printed on.




→ To load label sheets:

Load them in the  $\square$  orientation, as shown in the illustration. A label sheet consists of the printing surface, sticking layer, and pasteboard. Peel off the pasteboard, then you can stick the label to other objects.



3 Slide the **Lateral Guide** to fit the size of paper being loaded.



- 4 Select the paper type.
  - → To use label sheets, select [Thick 1].
  - $\rightarrow$  If you select  $4 \times 6 \square$  (A6 Card  $\square$ ), the paper type is automatically set to [Thick 2].

# Reference

To configure paper settings:

Press [Basic] ► [Paper].

#### 8.2 Consumables

#### 8.2.1 Checking consumables

#### Replacement message

When it is time to replace the **Toner Bottle** or **Drum Unit**, an advanced warning message appears at the top of the screen.

 $\label{thm:condition} For details on replacing the \textbf{Toner Bottle}, refer to [Quick Guide Copy/Print/Fax/Scan/Box Operations].$ 

For details on replacing the **Drum Unit**, contact your service representative.

When the message appears, make a preparation and replace the **Toner Bottle** according to the guidance contained in your maintenance agreement.

When it is almost time to replace the **Toner Bottle**, an advanced warning message similar to the one shown below appears.

When the message appears, prepare to replace the **Toner Bottle** according to the guidance contained in your maintenance agreement.




When it is time to replace the **Toner Bottle** or **Drum Unit**, an advanced warning message similar to the one shown below appears. Replace them according to the guidance contained in your maintenance agreement.

For the Toner Bottle, the machine stops operating after the message appears.

#### **Toner Bottle**



#### **Drum Unit**



If a user continues to operate the machine while a warning message is displayed, the following replacement message appears. Replace the **Toner Bottle** according to the guidance contained in your maintenance agreement. For **Drum Unit**, contact your service representative.

#### **Toner Bottle**



#### **Drum Unit**



# Checking consumables status

In the Check Consumable Life screen, you can check the status (usage level) of consumables.

1 Press the **Utility/Counter** key.



- 2 Press [Check Consumable Life].
  - → To print the list of usage levels, press [Print List], then [Start] or the **Start** key.



# **Viewing counters**

On the Meter Count screen, you can check the total number of prints since counting started. In the Coverage Rate screen, the consumed amount of toner can be viewed.

- Press the Utility/Counter key.
- 2 Press [Meter Count] ▶ [Check Details].
  - → To print the counter list, press [Print List], select paper, and then press the **Start** key.




→ To display the Coverage Rate screen, press [Coverage Rate].



# Checking the total number of pages printed

Pressing Total Counter displays the total number of pages printed to date


1. Total counter




# 8.3 Cleaning procedure

#### **Slit Scan Glass**

1 Open the ADF.



- Wipe the Slit Scan Glass with a dry cloth.
  - → Wipe off stains from the back side to the front side along the guide.




# Original Glass, Control Panel, Paper Take-Up Roller

#### **NOTICE**

Do not press the Control Panelhard, or the keys and Touch Panel may be damaged.

→ Wipe the surface using a soft, dry cloth.




# **Housing, Original Pad**

#### **NOTICE**

Never use solvents, such as benzene or thinner, to clean the Original Pad.

→ Wipe the surface using a soft cloth moistened with a mild household detergent.



# Troubleshooting


# 9 Troubleshooting

This chapter describes troubleshooting.

# 9.1 When a problem is detected (call a service representative)

If a problem is detected, perform the operation described in the message. If the problem is not resolved, perform the following operations, and then contact your service representative.


Normally, the phone number and fax number of your service representative appear in the center of the screen.




If a defective part can be separated in order to be able to continue operations after a problem has been detected, [Continue] or [Recover Data] is displayed. To continue operations, select any key. However, the problem has not been resolved, so contact your service representative immediately.

#### Problems that cannot be corrected by the user

- Write down the malfunction code in the Service Call screen.
- 2 Turn off the Sub Power Switch.



3 Turn off the Main Power Switch.



- 4 Unplug the machine.
- 5 Contact your service representative and inform them of the written down malfunction code.

# 9.2 Troubleshooting table

# Simple troubleshooting

The following explains simple troubleshooting procedures. If the problem is not corrected after the described operation is performed, contact your service representative.

Description of problem	Check points	Remedy
The machine does not start up when the <b>Main Power Switch</b> is turned on	Is power being supplied from the electrical outlet?	Correctly insert the power supply plug into the electrical outlet.
	Has the <b>Sub Power Switch</b> been turned on?	Turn on the <b>Sub Power Switch</b> .
Copying does not start	Is the <b>Top Right Door</b> of the machine open?	Securely close the <b>Top Right Door</b> of the machine.
	Is there any paper that matches the original?	Load paper of the appropriate size into the paper tray.
The image is light.	Is the copy density set to [Light]?	Press [Dark] in the Density screen to copy at the desired copy density. (p. 5-18)
	Is the paper damp?	Replace with new paper. (p. 8-3)
The image is dark.	Is the copy density set to [Dark]?	Press [Light] in the Density screen to copy at the desired copy density. (p. 5-18)
	Was the original not pressed close enough against the <b>Original Glass</b> ?	Position the original so that it is pressed closely against the <b>Original Glass</b> . (p. 3-5)
The image is partially obscured	Is the paper damp?	Replace with new paper. (p. 8-3)
or blurry.	Was the original not pressed close enough against the <b>Original Glass</b> ?	Position the original so that it is pressed closely against the <b>Original Glass</b> . (p. 3-5)
There are dark specks or spots throughout the printed output	Is the <b>Original Glass</b> dirty?	Wipe the <b>Original Glass</b> with a soft, dry cloth. (p. 8-11)
There are streaks in the printed output	Is the Slit Scan Glass dirty?	Clean the <b>Slit Scan Glass</b> with a dry cloth. (p. 8-11)
	Is the <b>Original Pad</b> dirty?	Clean the <b>Original Pad</b> with a soft cloth dampened with a mild detergent. (p. 8-12)
	Was the original printed on highly translucent material, such as diazo photosensitive paper or OHP transparencies?	Place a blank sheet of paper on top of the original. (p. 3-5)
	Is a 2-sided original being copied?	If a thin 2-sided original is being copied, the print on the back side may be reproduced on the front side of the copy. In the Background Removal screen, select a lighter background density. (p. 5-18)



Description of problem	Check points	Remedy
The image is printed at an angle	Is the original positioned correctly?	Correctly position the original against the <b>Original Scale</b> . (p. 3-5) Load the original into the <b>ADF</b> , and slide the adjustable <b>Lateral Guide</b> to fit the size of the original. (p. 3-4)
	Is the original incorrectly positioned in the <b>ADF</b> ?	If the original cannot be fed correctly through the <b>ADF</b> , make copies by positioning the original on the <b>Original Glass</b> . (p. 3-5)
	Is the <b>Slit Scan Glass</b> dirty? (while using the ADF)	Clean the <b>Slit Scan Glass</b> with a dry cloth. (p. 8-11)
	Are the adjustable <b>Lateral Guide</b> incorrectly positioned against the edges of the paper?	Slide the adjustable <b>Lateral Guide</b> against the edges of the paper.
	Was curled paper loaded into the paper tray?	Flatten the paper before loading it.
The printed page is curled	Was paper that curls easily (as with recycled paper) used?	Remove the paper from the paper tray, turn it over, and then load it again.
		Replace with new dry paper. (p. 8-3)
The edge of the printed image is dirty	Is the <b>Original Pad</b> dirty?	Clean the <b>Original Pad</b> with a soft cloth dampened with a mild detergent. (p. 8-12)
	Was the selected paper size larger than the original? (With a Zoom setting of "Full Size" (100.0%))	Select a paper size that is the same size as the original. Otherwise, select Auto to enlarge the copy to the selected paper size. (p. 5-7)
	Is the size or orientation of the original different from that of the paper? (With a Zoom setting of "Full Size" (100.0%))	Select a paper size that is the same size as the original. Otherwise, select a paper orientation that is the same as that of the original.
	Was the copy reduced to a size smaller than the paper? (with a reduced zoom ratio specified)	Select a zoom ratio that adjusts the original size to the selected paper size. Otherwise, select Auto to enlarge the copy to the selected paper size. (p. 5-7)
Even though a paper jam was cleared, copies cannot be produced	Is paper jammed at other locations?	Remove any jammed paper from other locations.
Printing with the "2-Sided > 1- Sided" or "2-Sided > 2-Sided" settings are not available	Have settings been selected that cannot be combined?	Check the combinations of the selected settings.
Copying is not possible even though the password is entered on a machine with account track settings configured	Did the message [Your account has reached its maximum allowance.] appear?	Contact your administrator.
The original is not fed	Is the ADF slightly open?	Securely close the <b>ADF</b> .
	Is the original one that does not meet the specifications?	Check that the original is one that can be loaded into the <b>ADF</b> . (p. 12-6)
	Is the original correctly loaded?	Position the original correctly. (p. 3-4)



Description of problem	Check points	Remedy
The Finisher FS-527, Finisher FS-529, or Job Separator JS-505 does not operate	Is any power being supplied to the connector?	Check that the cord is correctly inserted into the connector.
The staple is incorrectly positioned by 90	Has the staple position been correctly specified?	Specify the desired position for stapling. (p. 5-11)
The pages that were fed out were not uniformly loaded and the punched holes or staples	Is the paper curled?	Remove the paper from the paper tray, turn it over, and then load it again.
are incorrectly positioned	Is there a gap between the Lateral Guide in the paper tray and the sides of the paper?	Slide the <b>Lateral Guide</b> in the paper tray against the sides of the paper so that there is no gap.
	Is the paper type configured correctly?	Configure the paper type of the selected tray correctly.
Though the authentication unit is connected with this machine sing a USB cable, the status indicator LED does not light in green	A malfunction of the USB port of this machine is suspected.	Turn off the Main Power Switch of this machine, disconnect the USB cable from this machine or authentication unit, and then connect it again. Wait at least 10 seconds, and then turn on the Main Power Switch of this machine.
Though the authentication unit is connected with the computer	MA malfunction of the USB port of your computer is suspected.	Restart your computer.
using a USB cable, the status in- dicator LED does not light in green	Has the authentication unit driver being installed correctly?	Check that the driver is correctly installed in your computer. (p. 10-2), (p. 11-2)
No notice sound is given when scanning is started or authentication is finished on this machine	Has the notice sound being set to OFF on this machine?	Turn on the notice sound of this machine. (p. 10-2)
When message [Registration failed] appears in the machine that failed in registration	The scanning time on the authentication unit is limited per scanning. If scanning does not finish within the limited time, the corresponding message appears.  For details on the scanning time, contact your service representative.	To finish scanning within the limited time, refer to [Quick Guide Copy/Print/Fax/Scan/Box Operations] to confirm how to perform authentication and how to place your finger when scanning. During scanning, place the scanned part on the scanning section correctly, and do not
When message [Failed to authenticate.] appears in the machine that failed in login		
When the [Failed to read data. Place your finger once again and the Click [Start reading] button. ] message appears on this machine where registration fails	The scanning time on the authentication unit is limited to five seconds per scan. If scanning does not finish within five seconds, the corresponding message appears.	move it until results have been obtained. If the scanned part is dusty or rough and dry when performing authentication, a correct image will not be able to be obtained, and scanning may not finish. Clean your finger, and then scan it again, or improve the rough and dry condition of your finger. If the scanned part is too thick or thin (when the finger width is outside the range from 3/8 inch (10 mm) to 1 inch (25 mm)), a correct image will not be able to be obtained, and scanning may not finish. Try "stretching your finger", "placing your finger deeply", or "placing your finger shallowly" on the scanning section.



Description of problem	Check points	Remedy
Scanning does not start	Have you placed your finger correctly on the authentication unit?	Refer to [Quick Guide Copy/Print/Fax/Scan/Box Operations] to confirm how to perform authentication and how to place your finger when scanning. During scanning, place the scanned part on the scanning section correctly, and do not move it until results have been obtained. If the scanned part is dusty or rough and dry when performing authentication, a correct image will not be able to be obtained, and scanning may not finish. Clean your finger, and then scan it again, or improve the rough and dry condition of your finger. If the scanned part is too thick or thin (when the finger width is outside the range from 3/8 inch (10 mm) to 1 inch (25 mm)), a correct image will not be able to be obtained, and scanning may not finish. Try "stretching your finger", "placing your finger deeply", or "placing your finger shallowly" on the scanning section.
	Did you restart this machine after connecting the authentication unit to this machine?	Turn off the Main Power Switch of this machine, disconnect the USB cable from this machine or authentication unit, and then connect it again. Wait at least 10 seconds, and then turn on the Main Power Switch of this machine.
When message [Failed to register.] appears in the machine that failed in registration	The scanning time of the authentication unit is limited to 10 seconds. If scanning does not finish within the limited time, the corre-	To finish scanning within the limited time, refer to [Quick Guide Copy/Print/Fax/Scan/Box Operations] to confirm how to place
When a message appears on the computer where registration fails	sponding message appears.	the IC card.
When message [Failed to authenticate.] appears in the machine that failed in login	When IC card authentication + password authentication is enabled Did you enter the correct password?	Check the password, and then enter the correct one if not.
Scanning does not start	Did you restart this machine after connecting the authentication unit to this machine?	Turn off the Main Power Switch of this machine, disconnect the USB cable from this machine or authentication unit, and then connect it again. Wait at least 10 seconds, and then turn on the Main Power Switch of this machine.
Connecting the authentication unit to the computer starts the hardware uninstall wizard	Is the USB port to which the authentication unit is connected the same as the one used when installing the driver?	If you connect the authentication unit to a different USB port from the one used when installing the driver, the hardware uninstall wizard may start. Use the same USB port as the one used when installing the driver.

# Main messages and their remedies

If any message other than those listed below appears, perform the operation described in the message.

Message	Cause	Remedy
[Originals left on original glass.]	The original has been left on the Original Glass.	Remove the original from the <b>Original Glass</b> .
[Paper of matching size is not available. Select the paper size.]	Paper of a suitable size is not loaded in a paper tray.	Either select paper of a different size or load paper of a suitable size.
[Load paper in the bypass tray.]	Paper of a suitable size is not loaded in the <b>Bypass Tray</b> .	Load paper of the appropriate size into the <b>Bypass Tray</b> .
[The original size cannot be detected. Select the paper size.]	<ul><li>(1) The original is not positioned correctly.</li><li>(2) An original with a nonstandard size or with a size too small to be detected is loaded.</li></ul>	<ul><li>(1) Position the original correctly.</li><li>(2) Select the correct paper size.</li></ul>
[The image will not fit in the selected paper size. Position the original in a different orientation.]	The image does not fit in the paper.	Turn the original 90 and load it.
[The output tray has reached its capacity. Remove paper from the tray indicated by →.]	Copy cannot be performed because the paper loading capacity of the output tray of the displayed Finisher FS-527, Finisher FS-529, or Job Separator JS-505 has reached the maximum.	Remove all paper from the indicated tray.
[Enter a login user name and password, and then touch [Login] or press [Access].]	User authentication settings have been configured. Copies cannot be made unless a user name and correct password are entered.	Enter the correct user name and password. (p. 4-8)
[Enter Account Name and password, and then touch [Login] or press the [Access] key.]	Account track settings have been configured. Copies cannot be made unless an account name and correct password are entered.	Enter the correct account name and password. (p. 4-8)
[Your account has reached its maximum allowance.]	The limit on the number of pages that can be printed has been reached.	Contact the administrator of the machine.
[The part indicated by $\rightarrow$ is open. Ensure that it is properly closed.]	Since a machine door or cover is open or an option is not installed correctly, the machine is unable to make copies.	Make sure that all doors and covers of this machine and options are closed securely.
[Install the toner bottle (K).]	The <b>Toner Bottle</b> is not installed correctly.	Reinstall each consumable and replaceable part. Or contact your service representative.
[Set the toner bottle, and close all doors.]	The <b>Toner Bottle</b> is not installed correctly.	Reinstall each consumable and replaceable part. Or contact your service representative.
[Replenish paper.]	The indicated tray has run out of paper.	Add paper. (p. 8-3)
[Toner bottle (K) is low. Replace when indicated.]	The toner is about to run out.	Prepare a spare <b>Toner Bottle</b> for replacement following the guidance contained in your maintenance agreement.
[Replace Toner Bottle(K)]	The toner is about to run out.	Replace the <b>Toner Bottle</b> following the guidance contained in your maintenance agreement.

9-8 bizhub 423/363/283/223



Message	Cause	Remedy
[The toner needs to be replaced. Follow the instructions to re- place the toner bottle and close the supply door.]	Toner is depleted.	Replace the <b>Toner Bottle</b> following the guidance contained in your maintenance agreement.
[No more staples. Replace the staple cartridge, or cancel stapling.]	The staples have run out.	Replace the <b>Staple Cartridge</b> .
[Misfeed detected. Remove pa- per according to the instruc- tions.]	Since a paper jam occurred, the machine is unable to make copies.	Clear the jammed paper.
[Empty the hole-punch scrap box. To continue the job, cancel punching.]	(1) The hole-punch scrap box is full. (2) The <b>Punch Scrap Box</b> is not installed.	(1) Throw punch scraps away from the <b>Punch Scrap Box</b> . Install the <b>Punch Scrap Box</b> .
[Reset the following number of originals.]	After clearing a paper jam, it is necessary to reload certain pages of the original that have already been fed through the <b>ADF</b> .	Load the indicated original pages into the <b>ADF</b> .
[An internal error occurred. Open and then close the top right door to remedy a problem. If the trouble code appears again, contact your Service Rep.]	The machine malfunctioned and is unable to make copies.	Take a remedy according to the message displayed in the screen. If the problem is not resolved or released, inform your service representative of the malfunction code displayed in
[An internal error occurred. Turn the main switch OFF and ON. If the trouble code appears again, contact your Service Rep.]		the screen.
[Malfunction detected. Please call your Service Representative.]	The machine malfunctioned and is unable to make copies.	Inform your service representative of the code displayed in the screen.
[Clean the original glass on the left with the glass cleaner. Continuing using the machine in this condition may cause lines to appear in the output.]	The <b>Slit Scan Glass</b> is dirty.	Clean the <b>Slit Scan Glass</b> with a dry cloth.
[Now Downloading Program Data from the Firmware server.]	<ul><li>(1) CS Remote Care was activated by your service representative.</li><li>(2) Internet ISW is being downloaded.</li></ul>	Do not turn off the <b>Sub Power Switch</b> while this message is displayed. After turning off the <b>Sub Power Switch</b> , turn off the <b>Main Power Switch</b> , and then contact your service representative.
[Authentication information entered is invalid, due to failed access attempts. Contact your administrator.]	The authentication information has become invalid since the authentication attempts have failed the specified number of times.	Contact the administrator of the machine.
[Due to failed access attempts, the current administrator password is invalid.]	The administrator password has become invalid since the authentication attempts have failed the specified number of times.	Turn the machine off, then on again. Turn off the <b>Main Power Switch</b> , and then wait at least 10 seconds before turning it on again.
[The job log has reached the maximum allowed. Contact the administrator.]	The write area of the job log has reached the maximum allowed.	Obtain the job log using Page- Scope Web Connection.
[No Animation Guide data available. Contact your administrator.]	Animation guide data is not installed.	For details on installing animation guide data, contact your service representative.

9.2

Message	Cause	Remedy
[Verify that external keyboard is properly connected. It may not be connected or multiple keyboards may be connected.]	The compact keyboard is not connected to this machine.	Turn off the main power of this machine, connect the compact keyboard to this machine. Wait at least 10 seconds, and then turn on the main power of this machine.

# Icons that appear in the touch-panel screen


Icon	Description
Ē-	Indicates that data is being sent from the machine, regardless of the current mode.
<b>G</b> -	Indicates that the machine is receiving data, regardless of the current mode.
4	Indicates that there is an error with the printing or scanning function. Press this icon to view a screen containing a warning code.
View Warning	If the warning screen has been closed while a warning occurs, press this button to display the warning screen again.
ð	Appears when there is a message indicating that consumables must be replaced or the machine requires maintenance. Press this icon to display the message, and then perform the replacement or maintenance procedure.
POP	Appears when an error occurs with the connection to the POP server.
¥	Indicates that there is no paper in the paper tray.
	Indicates that very little paper remains in the paper tray.
🖺 Sec	Indicates that enhanced security mode is enabled.
*	Appears when the external memory (USB memory) is not connected.
<b>₩</b>	Indicates that a nonstandard external memory has been connected to this machine, therefore, USB connection is not enabled.
6	Indicates that the job is in the waiting-for-redial status because, for example, the recipient's line is busy when sending with the G3 Fax or IP Address Fax function.

Authentication unit (biometric type)

10.1

# 10 Authentication unit (biometric type)

This chapter describes the Authentication Unit (biometric type) AU-102.



1. Authentication Unit (biometric type) AU-102

# 10.1 Using an authentication unit (biometric type)

The **Authentication Unit (biometric type) AU-102** is a "biometrics (biometric authentication) system" that scans finger vein patterns to perform personal authentication. Using the biometric authentication, you can log in to this machine where user authentication settings are configured in order to execute a print job.

Place your forefinger straight so that your forefinger cushion slightly touches the hollow and protuberance part of the scanning section. Secure your middle finger and thumb on the both sides of the authentication unit to prevent your forefinger to be used for authentication from rotating.

For details on how to place your finger on the authentication unit, refer to page 10-16.

#### NOTICE

Do not place anything other than your finger on the scanning section during scanning operation. Doing so may cause a malfunction.

Do not disconnect the USB cable from the authentication unit or computer during a scanning operation. Doing so may cause the system to become unstable.

The status indicator LED and notice sound indicate the status of the authentication unit.

Status indicator LEDs	Status
Lit in green	Ready state or authentication is completed
Flash in green	During authentication or scanning operation
Lit in red	Authentication failed or scanning failed
Unlit	The authentication unit is not recognized

Notice sound	Status
One short blip sound	Scanning starts
One short blip sound	During a retry after authentication failed
Two short blip sound	Authentication completed
One short blip and one long beep sound	Authentication failed
One long beep sound	Scanning canceled

To use the **Authentication Unit (biometric type) AU-102**, first register the user's finger vein patterns in this machine. The registered user, who is authenticated with the finger vein pattern, can log in to this machine or execute a print job. This section explains how to configure the required settings in this machine, register users, and log in with authentication.

# 10.1.1 Configuring this machine

#### **NOTICE**

User authentication settings must be configured with MFP authentication on this machine.

This device does not support external server authentication. To combine account track settings with user authentication settings, set Synchronize User Authentication & Account Track to [Synchronize].

- 1 Use the **Control Panel** of this machine to display the Administrator Settings screen. Press [User Authentication/Account Track], then [General Settings].
- Set [User Authentication] to [ON (MFP)], and then press [OK].



3 Press [Yes], and then [OK].



- 4 Press [Authentication Device Settings].
- 5 Press [General Settings].
- 6 Press [Bio Authentication].

Configure [Beep Sound] and [Operation Settings].



- → For [Beep Sound], specify whether to give a "blip" sound when the finger vein pattern is scanned successfully.
- → For [Operation Settings], specify how to log in to this machine after registration.
  [1-to-many authentication]: Allows the user to log in by simply placing his or her finger.
  [1-to-1 authentication]: Allows the user to log in by entering the user name and placing his or her finger.

For details on how to log in to this machine, refer to page 10-16.

- 8 Press [OK] twice.
- 9 Press [Logoff Settings].
- 10 Specify whether to log out the user when scanning the original has finished after the user logged in with the authentication unit.



- 11 Press [OK].
- 12 Press [Close] twice.

#### 10.1.2 Registering a user

The following two methods can be used to register a user.

- Connect the authentication unit to this machine, and directly register the target user in this machine
- Connect the authentication unit to your computer, and use Data Administrator to register the target user

#### **NOTICE**

The registered user data is saved in the HDD of this machine. Changing the user authentication type of this machine or formatting the HDD will erase the registered user data.

#### Registering a user using the Control Panel of this machine

Use the **Control Panel** of this machine to display the Administrator Settings screen. Press [User Authentication/Account Track], and then [User Authentication Settings].

#### **NOTICE**

[User Authentication Settings] is disabled when User Authentication is set to [OFF] in General Settings.

- 2 Press [User Registration].
- 3 Select a desired registration number, and then press [Edit].



4 Press [Register Auth. Info.].



5 Press [Edit].



6 Place your finger on the authentication unit to scan the finger vein pattern.



- → Scan the finger vein pattern three times; reset the same finger each time and then press [Scan] for each scanning.
- → After scanning the finger vein patterns, place the same finger on the authentication unit, and press [Authentication Test].
- → If your finger vein patterns have been authenticated in the authentication test, press [New]. If authentication has failed, retry scanning the finger.
- 7 Press [Close] twice.
- 8 Enter the user name and password.
- 9 Configure function permission settings as required.
- 10 Press [OK].
- 11 Press [Close].

#### Registering a user using Data Administrator

To use **Data Administrator**, configure this machine, and set up Data Administrator. For setup, install the **BioDriver (USB-Driver)** of the authentication unit, and then install **Data Administrator Bio Plugin**.

#### **NOTICE**

Before setup, install **Data Administrator** V4.0 or later in your computer. For the **Data Administrator** operating environment and installation procedure, refer to the **Data Administrator** User's Guide.

# Checking the version of the installed Data Administrator


From the [Help] menu of **Data Administrator**, select [Version Information].

#### **NOTICE**

This software cannot be used if the version is "3.x". Install "4.x".

If Data Administrator V3.x is installed, it is removed when V4.x is installed.

- 2 Click [Plug-in version].
- 3 In [Plug-in information list], confirm the plugin version of **Data Administrator**.



 $\rightarrow$  This software is available if the plugin version is "4.x".

# Setup

- Turn the Main Power Switch of this machine off, and disconnect the authentication unit from this machine.
- 2 Install BioDriver (USB-Driver)

Connect the authentication unit to the USB port of your computer.


The [Found New Hardware] dialog box appears.

3 Select [Locate and install driver software (recommended)].




4 Insert the application CD-ROM provided with the authentication unit into the CD-ROM drive of the computer.

5 Click the [Browse my computer for driver software (advanced)].




6 Check that the driver's search location is the application CD-ROM, and then click [Next].




→ When the driver's search location is not the application CD-ROM, click [Browse]. Select the **Bio-Driver (USB-Driver)** folder on the CD-ROM, and then click [OK].



→ Installation starts.




7 Click [Close].



Installation of BioDriver (USB-Driver) is completed.

- Install Data Administrator Bio Plugin.

  Open the DA\_Bio\_Plugin folder on the application CD-ROM, and then click setup.exe.
- Select a language, and then click [OK].




The installation program starts.

10 Follow the on-screen instructions to proceed with the installation.


11 Click [Next].




12 Select [I accept the terms in the license agreement], and then click [Next].



13 Click [Install].




14 Click [Finish].



Installation of the Data Administrator Bio Plugin is completed, which completes the setup.

#### **User registration**

To register a user with **Data Administrator**, connect the authentication unit to the USB port of the computer, and also connect the computer to this machine via network.



- If the authentication unit is already connected to this machine, turn the **Main Power Switch** of this machine off, and then disconnect the authentication unit.
  - → When the authentication unit is already connected to the computer, go to step 4.

#### **NOTICE**

To turn the **Main Power Switch** off and on, first turn the **Main Power Switch** off, and then turn it on after 10 or more seconds has elapsed. Not doing so may result in an operation failure.

When connecting or disconnecting the USB cable, hold the plug. Otherwise, the machine may be damaged or a failure may occur.

- Turn on the Main Power Switch of this machine.
- 3 Connect the authentication unit to the USB port of the computer that contains **Data Administrator**.

#### **NOTICE**

Do not connect another USB device to the same port as for the authentication unit. Doing so reduces the USB power supply, resulting in an operation failure.


To use the USB hub, be sure to connect the self-power USB hub that supplies 500 mA or more.

Restart the procedure 5 or more seconds after connecting the authentication unit.


4 Data Administrator starts, and device information of this machine is imported.

The Device Information window appears.


→ For details on how to import device information, refer to the **Data Administrator** User's Guide.



In Select Function, select [Authentication Settings] - [User Setting], and then click [Add].




6 Select the desired template, and then click [OK].



The User Registration window appears.

- 7 Enter the user name and password, select the [AU-102] tab, and then click [Register Auth. Info].
  - → Enter the E-mail address and other information as required.




- 8 Register finger vein patterns.
  - → Scan a finger vein pattern three times; reset the same finger and then press [Start Reading] for each scanning.
  - → After scanning the finger vein patterns, place the same finger, and click [Authentication Test].
  - → If the authentication test has succeeded, press [Register].
  - → If the authentication test has failed, place your finger on the authentication unit again, and click [Authentication Test].
  - → If the authentication has failed, click [Reset] to repeat the scanning process.



- 9 Click [Registration].
- 10 Click [OK].
  - → Repeat steps 5 to 10 to register all users.



- 11 Click [Export to the device].
  - → Select the user name and click [Edit] to change the registered data.




- 12 Click [Write].
  - → **Data Administrator** provides the batch copy function that batch-configures the registered user data in multiple machines with the authentication unit enabled.



The registered user data is configured in this machine.

13 Click [OK].



14 Disconnect the authentication unit from the USB port of the computer.

15 Turn the Main Power Switch of this machine off, connect the authentication unit to this machine, and turn the Main Power Switch of this machine on.

#### NOTICE

To turn the **Main Power Switch** off and on, first turn the **Main Power Switch** off, and then turn it on after 10 or more seconds has elapsed. Not doing so may result in an operation failure.

When connecting or disconnecting the USB cable, hold the plug. Otherwise, the machine may be damaged or a failure may occur.

## 10.1.3 Logging in to this machine


This section explains how to log in to this machine with the finger vein pattern authentication.

- To use authentication unit (biometric type), register the finger vein pattern in advance.
- If authentication fails frequently, finger vein patterns may not be registered correctly. Register finger vein patterns again.
- Authentication is carried out when you simply place your finger on the [1-to-many authentication]. Authentication is carried out when you enter the user name and place your finger on the [1-to-1 authentication].
- Press [ID & PW] to [Login] by entering the [User Name] and the [Password], without using the authentication unit.

#### When [1-to-many authentication] has been specified

Place your finger on the authentication unit.






The basic settings screen appears.

## When [1-to-1 authentication] has been specified

1 Select [User Name], and enter the user name.



2 Place your finger on the authentication unit.




The basic settings screen appears.



type)

# 11 Authentication unit (IC card type)

This chapter describes the Authentication Unit (IC card type) AU-201.



1. Authentication Unit (IC card type) AU-201

## 11.1 Using authentication unit (IC card type)

The **Authentication Unit (IC card type) AU-201** is an "IC card authentication" system that reads the IC card to perform personal authentication. Using this system, you can perform authentication with an IC card to log in to this machine or execute a print job when User Authentication is enabled in this machine.

To use the authentication unit, first register the card ID of the user in this machine. The registered user, who is authenticated with the card ID, can log in to this machine or execute a print job. This section explains how to configure the required settings in this machine, register users, and log in with authentication.

For details on how to place the IC card in the authentication unit, refer to the [Quick Guide Copy/Print/Fax/Scan/Box Operations].

#### **NOTICE**

Authentication Unit (IC card type) AU-201 must be installed inside the Working Table WT-506.

Do not disconnect the USB cable while using the authentication unit. Doing so may cause the system to become unstable.

Do not leave the IC card within 1-9/16 inch (40 mm) of the card reader.

## 11.1.1 Configuring this machine

#### **NOTICE**

Authentication Unit (IC card type) AU-201 must be installed inside the Working Table WT-506.

User authentication settings must be configured with MFP authentication on this machine.

This device does not support external server authentication. For [Public User Access] or [Account Track] settings, refer to page 7-25. To combine account track settings with user authentication settings, set Synchronize User Authentication & Account Track to [Synchronize].

Use the **Control Panel** of this machine to display the Administrator Settings screen. Press [User Authentication/Account Track], then [General Settings].

2 Set [User Authentication] to [ON (MFP)], and then press [OK].



3 Press [Yes], and then [OK].



- 4 Press [Authentication Device Settings].
- 5 Press [General Settings].
- 6 Press [Card Authentication].
- 7 Configure [IC Card Type] and [Operation Settings].



- → In [IC Card Type], specify the required IC card type.
- → For [Operation Settings], specify how to log in to this machine after registration. [Card Authentication]: Allows the user to log in by simply placing the IC card. [Card Authentication + Password]: Allows the user to log in by placing the IC card and entering the password.

For details on how to log in to this machine, refer to page 11-15.

- 8 Press [OK] twice.
- 9 Press [Logoff Settings].
- 10 Specify whether to log out the user when scanning the original has finished after the user logged in with the authentication unit.



- 11 Press [OK].
- 12 Press [Close] twice.

## 11.1.2 Registering a user

The following two methods can be used to register a user.

- Connect the authentication unit to this machine, and directly register the target user in this machine
- Connect the authentication unit to your computer, and use Data Administrator to register the target user

#### NOTICE

The registered user data is saved in the HDD of this machine. Changing the user authentication type of this machine or formatting the HDD will erase the registered user data.

#### Registering a user using the Control Panel of this machine

- 1 Use the **Control Panel** of this machine to display the Administrator Settings screen. Press [User Authentication/Account Track], and then [User Authentication Settings].
- 2 Press [User Registration].
- 3 Select a desired registration number, and then press [Edit].




4 Press [Register Auth. Info.].



5 Press [Edit].



6 Place the IC card on the authentication unit, and press [OK].



- 7 When message [Registration complete.] appears, press [Close] twice.
- 8 Enter the user name and password.
- 9 Configure function permission settings as required.
- 10 Press [OK].
- 11 Press [Close].

#### Registering a user using Data Administrator

To use **Data Administrator**, configure this machine, and set up Data Administrator. For setup, install the **IC Card Driver (USB-Driver)** of the authentication unit, and then install **Data Administrator IC Card Plugin**.

#### NOTICE

Before setup, install **Data Administrator** V4.0 or later in your computer. For the **Data Administrator** operating environment and installation procedure, refer to the **Data Administrator** User's Guide.

#### **Checking the version of the installed Data Administrator**


From the [Help] menu of **Data Administrator**, select [Version Information].

#### **NOTICE**

This software cannot be used if the version is "3.x". Install "4.x".

If Data Administrator V3.x is installed, it is removed when V4.x is installed.

- Click [Plug-in version].
- 3 In [Plug-in information list], confirm the plugin version of **Data Administrator**.



→ This software is available if the plugin version is "4.x".

#### **Setup**


- Turn the **Main Power Switch** of this machine off, and disconnect the authentication unit from this machine.
- 2 Install IC Card Driver (USB-Driver).

Connect the authentication unit to the USB port of your computer. The [Found New Hardware] dialog box appears.


3 Select [Locate and install driver software (recommended)].



- Insert the application CD-ROM provided with the authentication unit into the CD-ROM drive of the computer.
- 5 Click the [Browse my computer for driver software (advanced)].




6 Check that the driver's search location is the application CD-ROM, and then click [Next].




→ When the driver's search location is not the application CD-ROM, click [Browse]. Select the IC Card Driver (USB-Driver) folder in the CD-ROM, and click [OK].



→ Installation starts.



7 Click [Close].



Installation of the IC Card Driver (USB-Driver) is completed.

- Install Data Administrator IC Card Plugin.

  Open the IC\_Card\_Plugin folder on the application CD-ROM, and then click setup.exe.
- 9 Select a language, and then click [OK].




The installation program starts.


- 10 Follow the on-screen instructions to proceed with the installation.
- 11 Click [Next].




12 Select [I accept the terms in the license agreement], and then click [Next].



13 Click [Install].




14 Click [Finish].



Installation of the Data Administrator IC Card Plugin is completed, which completes the setup.

#### **User registration**

To register a user with **Data Administrator**, connect the authentication unit to the USB port of the computer, and also connect the computer to this machine via network.



- If the authentication unit is already connected to this machine, turn the **Main Power Switch** of this machine off, and then disconnect the authentication unit.
  - → When the authentication unit is already connected to the computer, go to step 4.

#### **NOTICE**

To turn the **Main Power Switch** off and on, first turn the **Main Power Switch** off, and then turn it on after 10 or more seconds has elapsed. Not doing so may result in an operation failure.

When connecting or disconnecting the USB cable, hold the plug. Otherwise, the machine may be damaged or a failure may occur.

- Turn on the Main Power Switch of this machine.
- 3 Connect the authentication unit to the USB port of the computer that contains **Data Administrator**.

#### NOTICE

Do not connect another USB device to the same port as for the authentication unit. Doing so reduces the USB power supply, resulting in an operation failure.


To use the USB hub, be sure to connect the self-power USB hub that supplies 500 mA or more.

Restart the procedure 5 or more seconds after connecting the authentication unit.


4 Data Administrator starts, and device information of this machine is imported.

The Device Information window appears.


→ For details on how to import device information, refer to the **Data Administrator** User's Guide.



5 In Select Function, select [Authentication Settings] - [User Setting], and then click [Add].




6 Select the desired template, and then click [OK].




The User Registration window appears.


- 7 Enter the user name and password, and select the [IC card authentication] tab.
  - → Enter the E-mail address and other information as required.




- Place the IC card on the authentication unit, and click [Start reading].
  - → If necessary, click [Card ID Input] to register the card ID.
- 9 Click [OK].
  - → Repeat steps 5 to 9 to register all users.



- 10 Click [Export to the device].
  - → Select the user name and click [Edit] to change the registered data.




- 11 Click [Write].
  - → **Data Administrator** provides the batch copy function that batch-configures the registered user data in multiple machines with the authentication unit enabled.



The registered user data is configured in this machine.

12 Click [OK].



13 Disconnect the authentication unit from the USB port of the computer.



14 Turn the Main Power Switch of this machine off, connect the authentication unit to this machine, and turn the Main Power Switch of this machine on.

#### NOTICE

To turn the **Main Power Switch** off and on, first turn the **Main Power Switch** off, and then turn it on after 10 or more seconds has elapsed. Not doing so may result in an operation failure.

When connecting or disconnecting the USB cable, hold the plug. Otherwise, the machine may be damaged or a failure may occur.

## 11.1.3 Logging in to this machine


This section explains how to log in to this machine with IC card authentication.

- To use authentication unit (IC card type), register the information recorded in the IC card in advance.
- If authentication fails frequently, IC card information may not be registered properly. Register IC card information again.
- When the IC Card authentication is enabled, a registered user is authenticated by simply placing the IC card. Authentication is carried out when you place the IC card and enter the [Password] when both IC cards and passwords are used for authentication.
- Press [ID & PW] to [Login] by entering the [User Name] and the [Password], without using the authentication unit.

## When [Card Authentication] is enabled

Place the IC card on the Working Table WT-506.






The basic settings screen appears.

## When [Card Authentication + Password] is enabled

1 Place the IC card on the Working Table WT-506.



Press [Password], and enter the password.



3 Press [Login] or the Access key.
The basic settings screen appears.

# 12 Specifications

12.1 Paper 12

# 12 Specifications

This chapter describes the specifications of the paper, machine, and options.

This product specification is subject to change without notice toward the improvement.

## 12.1 Paper

#### Paper types and paper capacities

Paper Type	Paper weight	Paper capacity
Plain paper Single Side Only*1 Special Paper*2 Letterhead*3 Colored Paper*4 User Paper 1*5 User Paper 2*5	15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)	Bypass Tray: 150 sheets Tray 1: 500 sheets Tray 2: 500 sheets Paper Feed Cabinet PC-109: 500 sheets Paper Feed Cabinet PC-208: 500 sheets Paper Feed Cabinet PC-409: 2500 sheets
Thick 1 User Paper 3 <sup>*5</sup>	24-3/16 lb to 39-7/8 lb (91 g/m <sup>2</sup> to 150 g/m <sup>2</sup> )	Bypass Tray: 20 sheets
Thick 2 User Paper 4 <sup>*5</sup>	40-3/16 lb to 55-7/8 lb (151 g/m <sup>2</sup> to 210 g/m <sup>2)</sup>	Bypass Tray: 20 sheets
Transparency	_	Bypass Tray: 20 sheets
Postcards	_	Bypass Tray: 20 sheets
Envelope	_	Bypass Tray: 10 sheets
Label sheets	_	Bypass Tray: 20 sheets

<sup>\*1</sup> Paper where you do not print on both sides (for example, when something is already printed on the front side).

For paper weight and media adjustment settings, contact your service representative.

#### NOTICE

Paper other than plain paper, such as OHP transparencies and colored paper, is called special paper. Be sure to select a special paper setting for paper trays loaded with media such as OHP transparencies and colored paper.

If the paper size or paper type is not correctly specified, it will result in a paper jam or image failure.

When you select Plain Paper, Thick 1, or Thick 2 for the **Bypass Tray**, you can select Duplex 2nd Side. Select Duplex 2nd Side when you load paper where something is printed on one side.

<sup>\*2</sup> Fine and other special paper.

<sup>\*3</sup> Paper where company names, preset text, and others are already printed.

<sup>\*4</sup> Colored paper.

<sup>\*5</sup> Paper that is registered as one of frequently used paper types.

# 12.2 Machine specifications

## bizhub 423/363/283/223

#### **Specifications**

Туре	Scanner, printer, desktop, or stand-alone		
Document holder	Stationary (mirror scanning)		
Photo conductor	OPC		
Light source	White rare-gas fluorescent		
Copy system	Laser electrostatic copying		
Developing system	Dry 2-component H	IMT developing system	
Fusing system	Roller fusing systen	n	
Resolution	Scanning	600 dpi × 600 dpi	
	Output	1800 dpi equivalent × 600 dpi	
Originals	Туре	Sheets, books (two-page spread), three-dimensional objects	
	Size	Max. 11 × 17 (A3)	
	Weight	4-7/16 lb (2 kg) Three-dimensional objects	
Copying paper type	Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)), Thick 1* (24-3/16 lb to 39-7/8 lb (91 g/m² to 150 g/m²)), Thick 2* (40-3/16 lb to 55-7/8 lb (151 g/m² to 210 g/m²)), Letterhead, Colored paper, Transparency, Postcard*, Envelope*, Label sheet* 2-Sided: Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)) * Available for <b>Bypass Tray</b> .		
Number of sheets loaded in	in Plain paper 250 sheets		
Output Tray	Thick	10 sheets	
	Transparency	1 sheet	
Paper tray capacity	Tray 1/Tray 2	Plain paper: 500 sheets	
(8-1/2 × 11(A4))	Bypass Tray	Plain paper: 150 sheets, Thick 1/2: 20 sheets, Transparency/Postcard/Label sheet: 20 sheets, Envelope: 10 sheets	
Warm-up time	Period from the time the <b>Main Power Switch</b> was turned on to the time <b>Sub Power Switch</b> was turned on to get ready for printing (room temperature: 73.4 °F (23 °C)) 12 sec. or less Period from the time <b>Main Power Switch</b> was turned on to the time this machine is ready for printing (room temperature: 73.4 °F (23 °C)) 30 sec. or less When a <b>Hard Disk</b> is not installed: 25 sec. or less Warm-up time may vary depending on the operating environment and usage.		

12.2

#### **Specifications**

Image chipping width	Top edge	3/16 inches (4.2 mm)	
	Bottom edge	1/8 inches (3.0 mm)	
	Right edge	1/8 inches (3.0 mm)	
	Left edge	1/8 inches (3.0 mm)	
First copy (When printing 8-1/2 × 11 (A4 (A4 (A)))	bizhub 423/363 3.6 sec. or less bizhub 283/223 4.2 sec. or less		
Copy speed (When printing 8-1/2 × 11 (A4))	1-Sided	bizhub 423 42 sheets/min. (Thick 1/2: 13 sheets/min.) bizhub 363 36 sheets/min. (Thick 1/2: 12.5 sheets/min.) bizhub 283 28 sheets/min. (Thick 1/2: 10 sheets/min.) bizhub 223 22 sheets/min. (Thick 1/2: 9 sheets/min.)	
	2-Sided	bizhub 423 42 sides/min. bizhub 363 36 sides/min. bizhub 283 28 sides/min. bizhub 223 22 sides/min.	
Copy magnification	Full size: 100.0% ± 0.5% Enlarge <inch area="">: 121.4%, 129.4%, 154.5%, 200.0% <metric area="">: 115.4%, 122.4%, 141.4%, 200.0% Reduce: <inch area="">: 78.5%, 73.3%, 64.7%, 50.0% <metric area="">: 86.6%, 81.6%, 70.7%, 50.0% Manual: 25.0 to 400.0% (in 0.1% steps)</metric></inch></metric></inch>		
Number of continuous copies	(1 to 9999)		
Density adjustment	Copy density	Manual density adjustment (9 levels)	
	Background den- sity	Manual or automatic density adjustment (9 levels)	
Power supply	AC 120 V, 12 A, 60	Hz (AC 220 V to 240 V, 8.0 A, 50/60 Hz)	
Max. power consumption	1500 W		
Size	When the ADF is installed: Width 24-1/2 inches (623 mm) Depth 25-1/16 inches (637 mm), 31-7/16 inches (799 mm*) Height 32-1/8 inches (816 mm) When the ADF is not installed: Width 24-1/2 inches (623 mm) Depth 24-7/8 inches (632 mm), 31-1/4 inches (794 mm*) Height 27-9/16 inches (700 mm) *Size including the panel		
	Width 64-5/16 inches (1634 mm) Depth 46-3/4 inches (1187 mm) Height 61-1/8 inches (1553 mm) The dimensions above are measured when the tray extension or paper tray of the <b>Finisher FS-527</b> is pulled out while the ADF remains opened.		
Machine occupation di- mensions	Depth 46-3/4 inches Height 61-1/8 inches The dimensions abo	s (1187 mm) es (1553 mm) ove are measured when the tray extension or paper tray	
	Depth 46-3/4 inches Height 61-1/8 inches The dimensions abo	s (1187 mm) es (1553 mm) ove are measured when the tray extension or paper tray	
mensions	Depth 46-3/4 inches Height 61-1/8 inches The dimensions about of the <b>Finisher FS</b> -3	s (1187 mm) es (1553 mm) ove are measured when the tray extension or paper tray	

#### **Specifications**

Weight	<b>bizhub 423/363</b> Approx. 171-15/16 lb (78 kg) <b>bizhub 283/223</b>
	Approx. 145-1/2 lb (66 kg)

# **Auto Duplex Unit**

#### **Specifications**

Paper Type	Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m <sup>2</sup> to 90 g/m <sup>2</sup> ))
Paper Size	11 × 17 $\square$ to 5-1/2 × 8-1/2 $\square$ , A3 $\square$ to A5 $\square$ , 8 × 13 $\square^{*1}$ , 16K $\square/\square$ , 8K $\square$ Width: 5-1/2 to 11-11/16 inches (139.7 mm to 297 mm), Length: 6-1/4 to 17 inches (158 mm to 431.8 mm)  *1 There are six types of foolcaps: 8-1/2 × 13-1/2 $\square$ , 220 mm × 330 mm $\square$ , 8-1/2 × 13 $\square$ , 8-1/4 × 13 $\square$ , 8-1/8 × 13-1/4 $\square$ , and 8 × 13 $\square$ . Any one of these sizes is selectable. For details, contact your service representative.
Power supply	Supply from machine

12.3 Options

# 12.3 Options

## **Reverse Automatic Document Feeder DF-621**

#### **Specifications**

Original feed function	1-sided original, 2-sided original, mixed original		
Original types	1-Sided Plain paper (9-5/16 lb to 34-1/16 lb (35 g/m² to 128 g/m²))		
	2-sided, mixed original	Plain paper (13-5/16 lb to 34-1/16 lb (50 g/m <sup>2</sup> to 128 g/m <sup>2</sup> ))	
Original Size	1-Sided/2-Sided Originals: 11 × 17 □ to 8-1/2 × 11 □/□, A3 □ to B6 □, A6 □, 8 × 13 □		
	For details on handling mixed originals, refer to p. 5-16.		
Original loading capacity	1- or 2-sided original: Max. 100 sheets (80 g/m²)		
Power supply	Supply from machine (DC 24 V, 2.0 A)		
Max. power consumption	60 W or less		
Size	Width 23-7/16 inches (596 mm) Depth 21-5/16 inches (542 mm) Height 4-9/16 inches (116 mm)		
Weight	Approx. 25-3/8 lb (11.5 kg)		

# **Paper Feed Cabinet PC-109**

#### **Specifications**

Paper Type	Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m <sup>2</sup> to 90 g/m <sup>2</sup> ))
Paper Size	11 × 17 $\square$ to 8-1/2 × 11 $\square$ / $\square$ , 5-1/2 × 8-1/2 $\square$ , A3 $\square$ to A5 $\square$ , 8 × 13 $\square$ *1, 16K $\square$ , 8K $\square$ *1 There are six types of foolcaps: 8-1/2 × 13-1/2 $\square$ , 220 mm × 330 mm $\square$ , 8-1/2 × 13 $\square$ , 8-1/4 × 13 $\square$ , 8-1/8 × 13-1/4 $\square$ , and 8 × 13 $\square$ . Any one of these sizes is selectable. For details, contact your service representative.
Number of loadable sheets	Tray 3 Plain paper: 500 sheets
Power supply	Supply from machine
Max. power consumption	15 W or less
Size	Width 23-5/8 inches (600 mm) Depth 23-3/4 inches (603 mm) Height 12-13/16 inches (325 mm)
Weight	Approx. 66-1/8 lb (30 kg)
Unit configuration	Paper tray, 1 level

## **Paper Feed Cabinet PC-208**

#### **Specifications**

Paper Type	Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m <sup>2</sup> to 90 g/m <sup>2</sup> ))
Paper Size	11 × 17 $\square$ to 8-1/2 × 11 $\square$ / $\square$ , 5-1/2 × 8-1/2 $\square$ , A3 $\square$ to A5 $\square$ , 8 × 13 $\square$ *1, 16K $\square$ , 8K $\square$ *1 There are six types of foolscap: 8-1/2 × 13-1/2 $\square$ , 220 mm × 330 mm $\square$ , 8-1/2 × 13 $\square$ , 8-1/4 × 13 $\square$ , 8-1/8 × 13-1/4 $\square$ , and 8 × 13 $\square$ . Any one of these sizes is selectable. For details, contact your service representative.
Number of loadable sheets	Top tray ( <b>Tray 3</b> ) Plain paper: 500 sheets Bottom tray ( <b>Tray 4</b> ) Plain paper: 500 sheets
Power supply	Supply from machine
Max. power consumption	15 W or less
Size	Width 23-5/8 inches (600 mm) Depth 23-3/4 inches (603 mm) Height 12-13/16 inches (325 mm)
Weight	Approx. 72-3/4 lb (33 kg)
Unit configuration	Paper tray, 2 levels

# **Paper Feed Cabinet PC-409**

#### **Specifications**

Paper Type	Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m <sup>2</sup> to 90 g/m <sup>2</sup> ))
Paper Size	8-1/2 × 11 , A4 .
Number of loadable sheets	Plain paper: 2500 sheets
Power supply	Supply from machine
Max. power consumption	45 W or less
Size	Width 23-5/8 inches (600 mm) Depth 23-3/4 inches (603 mm) Height 12-13/16 inches (325 mm)
Weight	Approx. 70-9/16 lb (32 kg)

## Finisher FS-527

#### **Specifications**

Output tray	Output Tray 1, Output Tray 2
Feeding function	Group, Sort, Offset Group*, Offset Sort*, Staple* Fed into <b>Output Tray 2</b>
Paper Type	Group/Sort: Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)) Thick (24-3/16 lb to 79-13/16 lb (91 g/m² to 300 g/m²)), Transparency, Postcard, Envelope, Label sheet, Letterhead Offset Group/Offset Sort: Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)), Thick (24-3/16 lb to 79-13/16 lb (91 g/m² to 300 g/m²)) Staple: Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)) , Thick (24-3/16 lb to 55-5/8 lb (91 g/m² to 209 g/m²))

Paper Size	<output th="" tray<=""><th>1&gt;</th><th></th><th></th></output>	1>			
	12-1/4 × 18	□, 11 × 17 □ to 5-1/2 × 8-1/2 □/□, A3 □ to B6 □, A6 □ 6 to 12-1/4 inches (90 mm to 311.15 mm), Length: 5-1/2 to 47:139.7 mm to 1200 mm)  ay 2> □, 11 × 17 □ to 5-1/2 × 8-1/2 □/□, A3 □ to B6 □, A6 □ //16 to 12-1/4 inches (100 mm to 311.15 mm), Length: 5-1/2 to 39.7 mm to 457.2 mm)  p/Offset Sort: □, 11 × 17 □, 8-1/2 × 11 □/□, A3 □ to A5 □ 6 to 12-1/4 inches (182 mm to 311.15 mm), Length: 5-7/8 to 18 5 mm to 457.2 mm),  β-1/2 × 14 □, 8-1/2 × 11 □/□, A3 □ to A5 □ 6 to 11-11/16 inches (182 mm to 297 mm), Length: 5-7/8 to 17			
Paper loading capacity < Output Tray 1>			23-15/16 lb (60 g/m <sup>2</sup> to 90 g/m <sup>2</sup> ))	200 sheets	
	parency, Enve	elope, Label sh	6 lb (91 g/m² to 300 g/m²)), Trans- leet, Letterhead	20 sheets	
			inches (35 mm)		
Paper loading capacity < Output Tray 2>	Group/Sort	Plain pa- per (15-	8-1/2 × 11 □, A4 □ or less	3000 sheets	
		15/16 lb to 23-15/16 lb (60 g/m <sup>2</sup>	8-1/2 × 14 □, B4 □ or more	1500 sheets	
		to 90 g/m <sup>2</sup> ))	5-1/2 × 8-1/2 □, A5 □ or less	500 sheets	
		Thick (24-3/16 lb to 79-13/16 lb (91 g/m² to 300 g/m²)), Transparency, Envelope, Label sheet, Letterhead			
	Offset Group/Off- set Sort	Plain pa- per (15- 15/16 lb to 23-15/16 lb (60 g/m <sup>2</sup> to 90 g/m <sup>2</sup> ))	8-1/2 × 11 □, A4 □ or less	3000 sheets	
			8-1/2 × 14 □, B4 □ or more	1500 sheets	
			5-1/2 × 8-1/2 □, A5 □ or less	500 sheets	
	Staple	Plain pa- per (15- 15/16 lb to 23-15/16	2 to 9 sheets: 100 copies*  * 8-1/2 × 14 □, B4 □ or more: 5	0 copies	
			10 to 20 sheets: 50 copies	heets: 50 copies	
		lb (60 g/m <sup>2</sup> to 90	21 to 30 sheets: 30 copies	to 30 sheets: 30 copies	
		g/m <sup>2</sup> ))	31 to 40 sheets: 25 copies		
			41 to 50 sheets: 20 copies		
	Paper loading height: 14-3/4 inches (375 mm) (8-1/2 × 11 □, A4 □ or less) / 7-3/8 (187.5 mm) (8-1/2 × 14 □, B4 □ or more)				
Maximum number of sta- pled sheets	Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)): 50 sheets Thick (24-3/16 lb to 31-15/16 lb (91 g/m² to 120 g/m²)): 30 sheets Thick (32-3/16 lb to 55-5/8 lb (121 g/m² to 209 g/m²)): 15 sheets Example number of stapled sheets: Thick (55-5/8 lb (209 g/m²)) 2 sheets + Plain paper (23-15/16 lb (90 g/m²)) 48 sheets				
Shift amount	1-3/16 inches	(30 mm)			
Power supply	Supply from n	nachine			
Max. power consumption	56 W or less				
Size	Depth 25-1/4	inches (641 m inches (1025	mm), 42-13/16 inches*(1087 mm*)		

#### **Specifications**

Weight	Approx. 92-9/16 lb (42 kg)
Consumables	Staple SK-602 For EH-590 (Product No. 505 manufactured by MAX) (5000 staples included) × 1 unit

## Saddle Stitcher SD-509

#### **Specifications**

Feeding function	Center Staple & Fold, Half-Fold		
Paper Type	Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)) Thick (24-3/16 lb to 55-5/8 lb (91 g/m² to 209 g/m²)) * Can be used only as a cover page.		
Paper Size	12-1/4 × 18		
Maximum number of sheets that can be center-stapled	15 sheets • 14 sheets (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)) + 1 sheet (15-15/16 lb to 55-5/8 lb (60 g/m² to 209 g/m²))		
Maximum number of folded sheets	3 sheets		
Capacity of Folding Out-	Number of stapled and folded sheets	1 to 3 sheets	20 copies
put Tray		4 to 10 sheets	10 copies
		11 to 15 sheets	5 copies
Size	Width 9-7/16 inches (239 mm) Depth 22-13/16 inches (579 mm) Height 21 inches (534 mm)		
Weight	Approx. 52-15/16 lb (24 kg)		
Consumables	Staple SK-602 For EH-280 (Product No. 505 manufactured by MAX) (5000 staples included) × 2 unit		
Power supply	Supplied from Finisher FS-527.		

# Punch Kit PK-517

#### **Specifications**

Number of punch holes	2 holes, 3 holes, 4 holes		
Paper Type	Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)), Thick (24-3/16 lb to 68-1/8 lb (91 g/m² to 256 g/m²))		
Paper Size	2 holes	11 × 17 □ to 8-1/2 × 11 □/□ , A3 □ to B5 □/□ es	
	3 holes 11 × 17 □ to 8-1/2 × 11 □		
	4 holes	A3 🖬 to A4 🖟, B5 🖟	
Power supply	Supplied from Finisher FS-527.		
Size	Width 2-5/16 inches (58 mm) Depth 18-1/2 inches (470 mm) Height 5-5/16 inches (135 mm)		
Weight	Approx. 3-15/16 lb (1.8 kg)		

12.3 Options

# 12

## **Separator JS-603**

#### **Specifications**

Output tray	Output Tray 3	
Feeding function	Group, Sort	
Paper Type	Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m $^2$ to 90 g/m $^2$ ), Thick (24-3/16 lb to 68-1/8 lb (91 g/m $^2$ to 256 g/m $^2$ ), Transparency, Envelope, Label sheet, Letterhead	
Paper Size	12-1/4 × 18 □, 11 × 17 □ to 5-1/2 × 8-1/2 □, A3 □ to A5 □	
Paper loading quality	Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²): 100 sheets, Thick (24-3/16 lb to 79-13/16 lb (91 g/m² to 300 g/m²), Transparency, Envelope, Label sheet, or Letterhead: 10 sheets	
	Paper loading height: 7/8 inches (22 mm)	
Size	Width 6-1/2 inches (165 mm) Depth 15-5/16 inches (389 mm) Height 2-1/2 inches (63 mm)	
Weight	Approx. 2-3/16 lb (1 kg)	

## Finisher FS-529

#### **Specifications**

Output tray	Output Tray 1 (Elevate tray)				
Feeding function	Group, Sort, C	Group, Sort, Offset Group, Offset Sort, Staple			
Paper Type	Group/Sort: Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)), Thick (24-3/16 lb to 72-1/16 lb (91 g/m² to 271 g/m²)), Transparency, Envelope, Label sheet, Letterhead Offset Group/Offset Sort: Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)), Thick (24-3/16 lb to 55-5/8 lb (91 g/m² to 209 g/m²)) Staple: Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)), Thick (24-3/16 lb to 55-5/8 lb (91 g/m² to 209 g/m²))* Can be used only as a cover page.				
Paper Size	Group/Sort: 12-1/4 × 18 □, 11 × 17 □ to 5-1/2 × 8-1/2 □/□, A3 □ to B6 □, A6 □ Width: 3-9/16 to 12-1/4 inches (90 mm to 311.15 mm), Length: 5-1/2 to 47- 1/4 inches (139.7 mm to 1200 mm) Offset Group/Offset Sort/Staple: 11 × 17 □ to 8-1/2 × 11 □/□, A3 □ to B5 □ Width: 8-1/4 to 11-11/16 inches (210 mm to 297 mm), Length: 7-3/16 to 17 inches (182 mm to 431.8 mm)				
Paper loading quality	Group/Sort	Plain paper (15- 15/16 lb to 23-	8-1/2 × 11 □, A4 □ or less	300 sheets	
		15/16 lb (60 g/m <sup>2</sup> to 90 g/m <sup>2</sup> ))	8-1/2 × 14 □, B4 □ or more	250 sheets	
		Thick (24-3/16 lb to 72-1/16 lb (91 g/m² to 271 g/m²)), Transparency, Envelope, Label sheet, Letterhead			
	Offset Group/Off- set Sort	Plain paper (15- 15/16 lb to 23- 15/16 lb (60 g/m <sup>2</sup> to 90 g/m <sup>2</sup> ))	8-1/2 × 11 □, A4 □ or less	300 sheets	
			8-1/2 × 14 □, B4 □ or more	250 sheets	
		Thick (24-3/16 lb to 55-5/8 lb (91 g/m² to 209 g/m²))		10 sheets	
	Staple	Plain paper (15- 15/16 lb to 23- 15/16 lb (60 g/m <sup>2</sup> to 90 g/m <sup>2</sup> ))	8-1/2 × 11 □, A4 □ or less	300 sheets or 30 copies	
			8-1/2 × 14 □, B4 □ or more	250 sheets or 30 copies	
	Paper loading	height: 1-7/16 inches	s (37 mm)	ı	
Maximum number of sta-	8-1/2 × 11 □=,	A4 □ or less	50 sheets		
pled sheets	8-1/2 × 14 <b>□</b> ,	B4 <b>□</b> or more	30 sheets		
	Example number of stapled sheets: Thick (55-5/8 lb (209 g/m²)) 2 sheets + Plain paper (23-15/16 lb (90 g/m²)) 48 sheets * 8-1/2 × 14 □, B4 □ or more: 28 sheets			) 2 sheets +	
Shift amount	1-3/16 inches (30 mm)				
Power supply	Supply from machine				
Max. power consumption	56 W or less				
Size	Width 18-9/16 inches (471 mm), 25-3/4 inches (654 mm*) Depth 22-3/16 inches (564 mm) Height 5-13/16 inches (147 mm) * Size when the tray is pulled out				
Weight	Approx. 26-7/16 lb (12 kg)				
Consumables	Staple SK-602 For EH-590 (Product No. 505 manufactured by MAX) (5000 staples included) × 1 unit				

## **Job Separator JS-505**

## **Specifications**

Output tray	Output Tray 1, Output Tray 2		
Feeding function	Group, Sort, Offset Group, Offset Sort		
Paper Type	< <b>Output Tray 1</b> > Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)) < <b>Output Tray 2</b> > Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)), Thick (24-3/16 lb to 71-5/16 lb (91 g/m² to 268 g/m²)), Transparency, Postcard, Envelope, Label sheet		
Paper Size	<b>Output Tray 1&gt;</b> 11 × 17 □ to 8-1/2 × 11 □/□, A3□ to A5 □ With: 5-13/16 to 11-11/16 inches (148 mm to 297 mm), Length: 8-1/4 to 17 inches (210 mm to 431.8 mm) <b>Output Tray 2&gt;</b> 12-1/4 × 18 □, 11 × 17 □ to 5-1/2 × 8-1/2 □/□, A3 □ to B6 □, A6 □, Postcard □ Width: 3-9/16 to 12-1/4 inches (90 mm to 311.1 mm), Length: 5-1/2 to 47-1/4 inches (139.7 mm to 1200 mm)		
Paper loading quality	<b>Output Tray 1&gt;</b> Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)): 50 sheets Paper loading height: 9/16 inches (14.5 mm) <b>Output Tray 2&gt;</b> Plain paper (15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)): 150 sheets Thick (24-3/16 lb to 71-5/16 lb (91 g/m² to 268 g/m²)), Transparency, Postcard, Label sheet: 20 sheets, Envelope: 10 sheets Paper loading height: 1-1/16 inches (27.6 mm)		
Power supply	Supply from machine		
Max. power consumption	40 W or less		
Shift amount	1-3/16 inches (30 mm)		
Offset function	< <b>Output Tray 2&gt;</b> 11 × 17 □ to 5-1/2 × 11 □/□ , A3 □ to B5 □		
Size	Width 16-5/8 inches (423 mm), 21-3/8 inches (543 mm) Depth 18-3/4 inches (477 mm) Height 5-1/8 inches (129.5 mm) * Size when the tray is pulled out		
Weight	Approx. 11 lb (5 kg)		

# Authentication Unit (biometric type) AU-102

#### **Specifications**

Name		AU-102	
Biometric sensor system		Transmission-type optical system	
Verification time		Approx. 1 sec. or less	
Interface		USB 2.0	
Dimensions		Width 2-5/16 inches (59 mm) Depth 3-1/4 inches (82 mm) Height 2-15/16 inches (74 mm)	
Weight		Approx. 3/16 lb (Approx. 96 g) (excluding USB cable)	
Max. power consumption (mA)		DC 5 V 500 mA	
System conditions (during operation)	Ambient temperature	41 °F to 95 °F (5 °C to 35 °C)	
	Humidity	20% to 80% (No dew condensation)	
System conditions (during non-operation)	Ambient temperature	32 °F to 122 °F (0 °C to 50 °C)	
	Humidity	20 to 80% (No dew condensation)	

Ο	ecif		•
<b>∿</b> n	$\Delta CIT$	гот	ınnc

Compatible computer	CPU	PC/AT compatible, 1 GHz or more
	Memory	128 MB or more
	HDD	Free space: 100 MB or more
	Monitor	800 × 600 pixels, 16-bit color or more
	Network	TCP/IP
	Application	Microsoft Internet Explorer 6.0 (SP1) or later Microsoft .NET Framework (SP1) or later
	Interface	USB 1.1 or later
Supported Operating Systems		Windows 2000 Professional (SP4) Windows XP Professional Edition (SP2) Windows Vista Business/Enterprise

# Authentication Unit (IC card type) AU-201

#### **Specifications**

Name		AU-201
Dimensions		Width 3-5/8 inches (92 mm) Depth 2-1/2 inches (64 mm) Height 5/8 inches (16 mm)
Weight		Approx. 1/4 lb (Approx. 120 g)
Power supply		Power received from USB port
System conditions (during operation)	Ambient temperature	32 °F to 104 °F (0 °C to 40 °C)
	Humidity	20% to 85% (No dew condensation)
System conditions (during	Ambient temperature	-4 °F to 122 °F (-20 °C to 50 °C)
non-operation)	Humidity	20% to 85% (No dew condensation)
Radio law division		Self-guided read-write communication facility
Applicable card		ISO 14443 Type A, FeliCa-based noncontact IC card, HID iClass
Acquired standard		VCCI class B
Compatible computer	CPU	PC/AT compatible, 1 GHz or more
	Memory	128 MB or more
	HDD	Free space: 100 MB or more
	Monitor	800 × 600 pixels, 16-bit color or more
	Network	TCP/IP
	Application	Microsoft Internet Explorer 6.0 (SP1) or later Microsoft .NET Framework (SP1) or later
	Interface	USB 1.1 or later
Supported Operating Systems		Windows 2000 Professional (SP4) Windows XP Professional Edition (SP2) Windows Vista Business/Enterprise

## 13 Appendix

13.1 Glossary 13

### 13 Appendix

#### 13.1 Glossary

The following describes the terms used in Copy mode.

Term	Description
[AE Level Adjustment]	Function that adjusts the background of the original. The higher the setting, the more that the document background is emphasized. (AE = Auto Exposure)
[Background Removal Level]	Function that adjusts the background density of the original with a colored background. Select a background removal method and level to copy the original.
[Binding Position]	Function that allows you to specify the position of the page margin in one side of the loaded original. Selecting the appropriate setting prevents the copy from being printed upside-down when making a 2-sided copy from a 1-sided original or when making a 1-sided copy from a 2-sided original.
[Card Shot]	Separately scans the contents of the front and back sides of a card, for example, insurance card, driver's license, or business card, and copies them together on one sheet. You can copy a card with the full size or enlarge an image to fit paper. Using the card copy function, you can save the number of sheets to be used.
[Center Staple & Fold]	Function that folds the copies in half and staples them together in the center.
[Change Tray Settings]	Function that copies the original with a paper size not specified in the paper tray or copies it on paper other than plain paper.
[Contrast]	Function that adjusts the contrast between light and dark.
[Copy Density]	Function that allows you to finely adjust the copy density in 19 levels between -3 and +3.
[Copy Guard]	To prevent unauthorized copying, this function prints a text such as Copy or Private or information such as Date/Time on all pages of paper as a copy guard (copy inhibit information) when copying. You cannot copy a page with a copy guard printed.
[Copy Protect]	Function that prints hidden text to prevent unauthorized copying. Copying a copy-protected document repeatedly prints hidden text in all pages more clearly than the original to prove the user that it is a copied document.
[Cover Sheet]	Function that attaches a sheet in the specified paper tray as a cover page.
[Density]	Function that adjusts the density of the print image in nine levels.
[Duplex 2nd Side]	Function to use when copying on paper that has already been printed on one side.
[Duplex/Combine]	Function to specify the scanning side of the original and the printing side of the paper to be 1-sided or 2-sided.
[Finishing Program]	Allows you to select a preset offset or finishing method.
[Finishing]	Allows you to select how to sort or finish copies when feeding them into the output tray.
[Half-Fold]	Function that folds printed paper in half.
[Manual]	Function that enlarges or reduces the loaded original with the zoom ratio specified using the keypad, and copies it on paper.
[Minimal]	This setting slightly reduces the image of the original and copies it at the center of the paper.
[Mirror Image]	Function that produces a copy in the mirror image of the original.

bizhub 423/363/283/223 13-2

Term	Description
[Mixed Original]	Function that detects the size of each original page and prints a copy on paper of the appropriate size when loading originals in different page sizes into the <b>Reverse Automatic Document Feeder</b> .
[Neg./Pos. Reverse]	Function that copies the original with the light- and dark-colored areas or the colors (gradations) of the image reversed.
[Offset]	Function that sorts copies.
[OHP Interleave]	Function that inserts a blank sheet between transparency films each time a transparency film is copied. This function prevents transparency films from sticking together.
[Original Direction]	Function that specifies the orientation of the original loaded into the <b>ADF</b> or placed on the <b>Original Glass</b> .
[Original Type]	Function that allows you to select the desired functions according to the original text or image type and adjust it to obtain better image quality.
[Paper]	Allows you to configure the type and the size of the paper to be printed on.
[Password Copy]	To prevent unauthorized copying, this function prints a text such as Copy or Private or information such as Date/Time on all pages of paper as a password when copying. When a sheet of paper with a password embedded is copied, the currently running job is suspended, and the password entry screen is displayed. In this case, enter the password to copy data.
[Punch]	Function that punches copies for filing.
[Save in User Box]	Function that temporarily saves the job on the hard disk so that it can be recalled later and used again.
[Separate Scan]	Function that divides the original into multiple parts for scanning when the number of original pages exceeds the maximum (100 pages) that can be loaded into the <b>ADF</b> . You can scan the original and batch-copies it as one copy job. You can also load the original on the <b>Original Glass</b> or switch to the <b>ADF</b> during scanning.
[Sharpness]	Function that emphasizes the edges of text so that it can be read more easily. This function also enables you to adjust the original image.
[Sheet/Cover/Chapter Insert]	Allows you to configure editing functions according to your copying requirement.
[Staple]	Function that staples copies.
[Text Enhancement]	Function that allows you to configure the reproduction quality of the text when copying originals consisting of text that overlaps images such as illustrations or graphs (text with a background).
[Zoom]	Function that changes the zoom ratio of the copy.
ADF	The acronym for <b>Reverse Automatic Document Feeder</b> . It can automatically scan originals. ( <b>ADF</b> = Automatic document feeder)
APS	The acronym for Auto Paper Select. (APS = Auto Paper Select)
ATS	Function that automatically switches trays. (ATS=Auto Tray Switch)
Auto Paper	Function that detects the size of the original placed on the <b>Original Glass</b> or loaded into the <b>ADF</b> , and automatically selects paper of the same size if it is set to Full Size or selects the paper size appropriate to the specified zoom ratio.
Auto Zoom	Function that automatically selects the appropriate zoom ratio when you place an original in the <b>ADF</b> or on the <b>Original Glass</b> , and selects the paper size.
Combine Originals	Function that arranges reduced copies of multiple original pages on a single copy page. You can select, "2in1", "4in1", or "8in1" depending on the number of pages to be combined.
Finishing Preview	Function that allows you to check the finishing status with a preview image before printing.

bizhub 423/363/283/223 13-3

Term	Description
Group (Access permission)	Function that limits the addresses that can be accessed by each user in order to assure security.
Group (Copy or Finishing)	Function that prints copies in pages. This function first prints the specified number of copies of the first page, and then prints the second page in the same way.
Proof Copy	Function that prints a sample copy and stops printing temporarily before printing a large number of copies. This prevents copy errors from occurring in a large number of copies.
Sort	Function that prints a document in sets of copies. The second copy set is printed after all of the first copy set is finished.

bizhub 423/363/283/223 13-4

# Index

### 14 Index

### 14.1 Index by item

A	
Access	4-8
Accessibility	4-12
Account track	4-8
Account track settings	7-30
ADF connector	2-7
Adjusting the center staple position	7-12
Adjusting the half-fold position	7-13
Adjusting the punch horizontal position	7-13
Adjusting the punch resistance loop	7-14
Administrator password	7-43
Administrator security levels	7-44
Administrator settings	7-2
Administrator/machine settings	7-23
Advanced preview	4-19
Application settings	5-20
Authentication device settings	7-33
Authentication unit	2-2
Authentication unit (biometric type)	10-2, 12-12
Authentication unit (IC card type)	11-2, 12-13
Automatic duplex unit	2-9, 12-5
В	
_	0.40
Basic tab	
Blonk naga print pottings	
Blank page print settings	
Book copy	
Book copy/repeat	
Booklet	
Booklet original	
Bottom right door  Bottom right door release lever	
_	
Brightness adjustment dial	
Bypass tray	2-5
C	
C	4-17
Card copy	
Cellular phone/PDA setting	
Centering	
Centering (duplex 2nd side)	
Changing e-mail addresses	
Changing icons	
Changing passwords	
Charger-cleaning tool	
Checking consumables	
Checking job settings	
Checking the total number of pages printed	
Cleaning procedure	

Configuring the basic settings					5-3
Control panel	2-5,	2-1	Ο,	4-2,	8-11
Copier settings				6-8,	7-37
Copy disk					2-2
Copy function					5-2
Copy guard					.5-45
Copy protection					.5-44
Copying					4-5
Copying mixed originals					.5-16
Cover sheet					.5-22
Coverage rate					8-9
Custom display settings					6-6
Custom size					5-6
D					
Data indicator					2-10
Date/time					
Date/time settings					
Daylight saving time					
Default bypass paper type setting .					
Driver password encryption setting					
Drum unit					
Duplex/combine					
					0
E					
Editing pages					
Eject assist lever					
Enhanced security mode					
Enlarge display					
Erasing					
Erasing frames					
Erasing non-image areas					
Expert adjustment					
External server settings					.7-32
F					
Fax board power save					7-3
Fax kit					2-2
Fax settings					.7-40
Fax/scan					4-5
Fax/scan settings					.6-10
Finisher	2	2-2,	12	2-7, 1	12-11
Finisher connector					2-7
Finisher FS-527					.2-14
Finisher FS-529					.2-16
Finishing					
Fold/bind					.5-12
Folding output tray					.2-14
Front door				2-5,	2-14
Function keys					.2-10

Function management settings	7-49	Lock release knob	2-9
Functions/settings display area	2-12	M	
Fusing cover lever	2-9		40.0
Fusing unit	2-9	Machine specifications	
Fusing unit top cover	2-9	Main power switch	
G		Maintenance  Maximum density adjustment	
General settings7	25 7 24	Media adjustment	
_	•	Message display area	
GroupingGuidance		Meter count	
Guide lever		Mirror image	
H	2-14	Mode memory	
Handle	0.14	N	
HDD settings		Negative-positive reversal	5.20
Header/footer		Network connector	
Horizontal transport unit cover		Network settings	
Housing		Network settings	7-30
riousing	0-12	0	
I		Offsetting	5-11
IC card type	11-2	OpenAPI authentication management s	settings7-52
Icon display area	2-12	Option configuration	2-2
Icons	9-10	Option mounting kit	2-2
Image adjustment	5-36	Options	12-6
Image repeat	5-33	Original glass	2-9, 8-11
Inserting images	5-24	Original glass cleaner	2-9
Inserting sheets	5-23	Original output tray	
Inside of the main body	2-9	Original pad	
Interleaving OHP transparencies		Original scales	
Interrupt	4-4	Original setting	
J		Original tray	
Jack for connecting a telephone (TEL PORT1) .	2-7	Original type	
Jack for connecting a telephone (TEL PORT2).		Output settings	
Jam removal dial2-9, 2-15, 2		Output tray	,
Job list	•	Output tray 1	•
Job separator		Output tray 2	•
Job separator JS-505		Outside of main body (Front)	
Job separator JS-603		Outside of the main body (rear)	
•		Overlay	
K		Overlaying registered images	5-52
Keypad	2-10	P	
L		Page margin	5-35
Lateral guides	2-5	Page number	5-41
LCT		Page number print position settings	7-22
Leading edge adjustment		Paper	5-5, 8-2, 12-2
Leading edge adjustment (duplex side 2)		Paper alignment plate settings	7-14
Left cover		Paper cabinet	12-6, 12-7
Left cover release lever		Paper capacities	
Left panel2	-12, 5-56	Paper feed cabinet	
License settings		Paper types	
Limiting access to destinations		Paper-empty indicator	
List/counter		Password	
Listing jobs	5-57	Placing originals	
Loading paper	8-3	Power cord	
Loading paper into the bypass tray	8-5	Power indicator	
Local interface kit	2-2	Power save	4-11

Power save settings7-3
Power switch for dehumidifying heater2-7
Print head glass cleaning tool2-9
Print without authentication7-31
Printer settings6-11, 7-39
Printing counter list7-32
Program jobs5-26
Proof copy4-18
Punch5-12
Punch kit2-2, 2-14, 12-9
Punch kit PK-5172-14
Punch scrap box2-15
·
Q
Quick copy tab2-12
R
Register auth. info6-15
Registering one-touch destinations or user boxes7-24
Replacement message8-7
Replenishment message8-2
Reset4-4
Reset settings7-17
Restricting user accesses7-7
Reverse automatic document feeder12-6
S
Saddle stitcher2-2, 2-14, 12-9
Saddle stitcher SD-5092-14
Saving in user boxes
Scan to authorized folder settings7-35
Scan to home settings7-35
Security details7-45
Security kit2-2
Security settings7-43
Separate scan5-13
Separate scan5-13 Separating chapters5-25
•
Separating chapters5-25
Separating chapters5-25 Separator12-12
Separating chapters         5-25           Separator         12-12           Service call         9-2
Separating chapters
Separating chapters
Separating chapters       5-25         Separator       12-12         Service call       9-2         Settings common to user and account track authentication       7-34         Skip job operation settings       7-21
Separating chapters       5-25         Separator       12-12         Service call       9-2         Settings common to user and account track authentication       7-34         Skip job operation settings       7-21         Sorting       5-11         Specifications       12-2
Separating chapters       5-25         Separator       12-12         Service call       9-2         Settings common to user and account track authentication       7-34         Skip job operation settings       7-21         Sorting       5-11         Specifications       12-2         Stamp       5-43
Separating chapters       5-25         Separator       12-12         Service call       9-2         Settings common to user and account track authentication       7-34         Skip job operation settings       7-21         Sorting       5-11         Specifications       12-2         Stamp       5-43         Stamp repetition       5-47
Separating chapters       5-25         Separator       12-12         Service call       9-2         Settings common to user and account track authentication       7-34         Skip job operation settings       7-21         Sorting       5-11         Specifications       12-2         Stamp       5-43         Stamp repetition       5-47         Stamp settings       7-19, 7-50
Separating chapters       5-25         Separator       12-12         Service call       9-2         Settings common to user and account track authentication       7-34         Skip job operation settings       7-21         Sorting       5-11         Specifications       12-2         Stamp       5-43         Stamp repetition       5-47         Stamp settings       7-19, 7-50         Stamp unit       2-2
Separating chapters       5-25         Separator       12-12         Service call       9-2         Settings common to user and account track authentication       7-34         Skip job operation settings       7-21         Sorting       5-11         Specifications       12-2         Stamp       5-43         Stamp repetition       5-47         Stamp settings       7-19, 7-50         Stamp unit       2-2         Stamp/composition       5-40
Separating chapters       5-25         Separator       12-12         Service call       9-2         Settings common to user and account track authentication       7-34         Skip job operation settings       7-21         Sorting       5-11         Specifications       12-2         Stamp       5-43         Stamp repetition       5-47         Stamp settings       7-19, 7-50         Stamp unit       2-2         Stamp/composition       5-40         Staple cartridge       2-14
Separating chapters       5-25         Separator       12-12         Service call       9-2         Settings common to user and account track authentication       7-34         Skip job operation settings       7-21         Sorting       5-11         Specifications       12-2         Stamp       5-43         Stamp repetition       5-47         Stamp settings       7-19, 7-50         Stamp unit       2-2         Stamp/composition       5-40         Staple cartridge       2-14         Stapling       5-11
Separating chapters       5-25         Separator       12-12         Service call       9-2         Settings common to user and account track authentication       7-34         Skip job operation settings       7-21         Sorting       5-11         Specifications       12-2         Stamp       5-43         Stamp repetition       5-47         Stamp settings       7-19, 7-50         Stamp unit       2-2         Stamp/composition       5-40         Staple cartridge       2-14         Stapling       5-11         Start       4-4
Separating chapters       5-25         Separator       12-12         Service call       9-2         Settings common to user and account track authentication       7-34         Skip job operation settings       7-21         Sorting       5-11         Specifications       12-2         Stamp       5-43         Stamp repetition       5-47         Stamp settings       7-19, 7-50         Stamp unit       2-2         Stamp/composition       5-40         Staple cartridge       2-14         Stapling       5-11         Start       4-4         Status indicator       2-5
Separating chapters       5-25         Separator       12-12         Service call       9-2         Settings common to user and account track authentication       7-34         Skip job operation settings       7-21         Sorting       5-11         Specifications       12-2         Stamp       5-43         Stamp repetition       5-47         Stamp settings       7-19, 7-50         Stamp unit       2-2         Stamp/composition       5-40         Staple cartridge       2-14         Stapling       5-11         Start       4-4         Status indicator       2-5         Stop       4-4
Separating chapters       5-25         Separator       12-12         Service call       9-2         Settings common to user and account track authentication       7-34         Skip job operation settings       7-21         Sorting       5-11         Specifications       12-2         Stamp       5-43         Stamp repetition       5-47         Stamp settings       7-19, 7-50         Stamp unit       2-2         Stamp/composition       5-40         Staple cartridge       2-14         Stapling       5-11         Start       4-4         Status indicator       2-5         Stop       4-4         Storage box       2-5
Separating chapters       5-25         Separator       12-12         Service call       9-2         Settings common to user and account track authentication       7-34         Skip job operation settings       7-21         Sorting       5-11         Specifications       12-2         Stamp       5-43         Stamp repetition       5-47         Stamp settings       7-19, 7-50         Stamp unit       2-2         Stamp/composition       5-40         Staple cartridge       2-14         Stapling       5-11         Start       4-4         Status indicator       2-5         Stop       4-4

System connection	7_/1
System settings	
Т	
Take-up roller	8-11
Telephone jack 2 (LINE PORT2)	2-7
Toner bottle	2-9
Toner supply indicators	2-12
Top right door	2-5
Top right door release lever	2-5
Total counter	2-9
Touch panel	2-10, 2-12
Tray 1	2-5, 8-3
Tray 2	2-5, 8-3
Tray 3	2-5, 8-3
Tray 4	2-5, 8-3
Tray extension	2-16, 2-17
Tray release button	2-5
Troubleshooting	9-2
Troubleshooting table	
Turning off automatic rotation	5-14
U	
USB port (type A) USB2.0/1.1	2-5 2-7
USB port (type B) USB2.0/1.1	
User authentication	
User authentication/account track	
User box	
User box administrator setting	
_	
User settings	
Utility/counter	4-6
W	
Waste toner box	
Watermark	
Weekly timer setting	
Working table	2-2
Z	
Z-folded original	5-17
Zoom	E 7

### 14.2 Index by button

Index by button

Numerics		Blank Page Print Settings	. 6-4, 7-20
1-Sided > 1-Sided	5-8	Book Copy	5-31
1-Sided > 2-Sided		Book Copy/Repeat	5-31
2/4/8 Repeat		Book Spread	5-32
2in1		Booklet	5-37
2-Sided > 1-Sided		Booklet Original	5-34
2-Sided > 2-Sided		Bottom	5-38
4in1/8in1		Bypass Tray	5-5
A		С	
Access	1_Q	C(clear)	4-17
Accessibility	_	Card Authentication	
Account Name		Card Shot	
Account Track	•	Card Shot Setting	
Account Track Counter		Cellular Phone/PDA Setting	•
Account Track Counter		Center Erase	
•		Center Staple & Fold	
Account Track Registration		Center Staple Position	
Account Track Settings		Centering	
Administrative Settings		Centering (Duplex 2nd Side)	
Administrator Password		Change E-Mail Address	
Administrator Registration		Change Icon	
Administrator Security Levels		Change Password	
Administrator Settings		Change Setting	
Administrator/Machine Settings		Change Tray Settings	
AE Level Adjustment	•	Chapter Paper	
All Jobs		Chapters	
Application		Check Consumable Life	
Apply Stamps		Check Details	
Authentication Device Settings		Check Job	
Auto		Check job	•
Auto Booklet ON when Fold & Staple .		Check Job Set.	
Auto Color Level Adjust		Check/Change Temporarily	
Auto Detect		Color Selection Settings	
Auto Paper Select for Small Original		Composition	
Auto Reset		Confidential Document Access Method	
Auto Reset Confirmation			
Auto Rotate OFF		Consumables Replace Processing Procedure	
Auto Sort/Group Selection		Conind Paner	
Auto Tray Selection Settings		Copied Paper	
Auto Tray Switch ON/OFF		Copier Settings 6-6,	
Auto Zoom (ADF)		Copy	
Auto Zoom (Platen)		Copy Density	
Auto Zoom for Combine/Booklet		Copy Jacob	
Automatic Image Rotation	6-9, 7-37	Copy Insert	
В		Copy Program Lock Settings	
Back (Blank)	5-22	Copy Protect	
Back (Copy)		Copy Screen	
Background Removal		Counter Details	
Background Removal Level		Covers Rete	•
Basic		Coverage Rate	
Binding Position		Current Jobs	
Bio Authentication		Custom Display Settings	
Blank		Custom Size	5-6
DIGITIT	5-23		

D		Frame	5-38
Date Format	5-41	Frame Erase	5-32, 5-38
Date Settings	7-6	Front (Blank)	5-22
Date/Time 5-40, 5-44, 5-46, 5-		Front (Copy)	5-22
Date/Time Settings		Front and Back Cover	5-32
Daylight Saving Time		Front Cover	5-32
Default Bypass Paper Type Setting		Full Size	5-7
Default Copy Settings		Function	4-15
Default Enlarge Display Settings		Function Management Settings	7-49
Default Function Permission		Function Map	4-15
Default Operation Selection		Function Permission	7-29
Default Tab		G	
Default Tab Density Settings		•	7.05.7.04
Delete5-		General Settings	
Delete Registered Stamp		Get Request Code	
Delete Saved Copy Program		Gradation Adjustment	
Deleted Jobs		Group	
Density		Guidance	4-15
Density/Background	•	Н	
Despeckle		Half-Fold	5-38
Detail		Half-Fold Position	
Detail Settings 5-44, 5-46, 5-		Half-Fold Specification	
Display Activity Log		HDD Settings	
Document Name		Header/Footer	
Dot Matrix Original		Header/Footer Settings	
Driver Password Encryption Setting		Hide Personal Information	
Drum Dry		Hide Personal Information (MIB)	
Duplex/Combine		-	
		I	
E		Icon	7-29
Edit Image5-	20, 5-29	ID & Print Operation Settings	7-28
Edit Name	4-7	ID & Print Settings	7-28
E-Mail Address	7-28	Image Adjust	5-36
Enhanced Security Mode	7-47	Image Adjustment	5-30
Enlarge Display	4-14	Image Repeat	5-33
Enlarge Display Mode Confirmation	4-13	Image Shift	5-36
Enlargement Rotation	6-8	Increase Priority	5-58
Enter Power Save Mode	7-3	Initialization	7-9
Erase	5-38	Initialize	7-46
Erase Adjustment	7-10	Input Machine Address	7-23
Expert Adjustment	7-8	Insert Image	5-24
External Server Settings	7-32	Insert Paper	5-23
F		Insert Sheet	5-23
	0.0	Insert Sheet Setting	5-42
FAX Active Screen		Install License	7-51
Fax Settings		Interleave Paper	5-21
Fax TX Settings		Interrupt	4-4
Fax/Scan		1	
Fax/Scan Settings		J	
Feed Cleaning Settings		Job Details	
Finished Jobs		Job History	
Finisher Adjustment		Job History Thumbnail Display	
Finishing		Job List	•
Finishing Program		Job Log Settings	
Fixed Zoom		Job Reset	7-18
Fold/bind	5-12		

K		OpenAPI Settings	7-41
Key Repeat Start/Interval Time	4-13	Original Setting	5-15
		Original Type5	-18, 5-19
L		Other 5-44, 5-46, 5-	-47, 5-48
Language Selection	6-3	Other Functions	4-15
Layout	5-54	Output Permission7-28, 7-	-30, 7-31
Leading Edge Adjustment	7-11	Output Settings	
Leading Edge Adjustment (Duplex Side 2)	7-11	Output Tray Settings	
Left	5-38	Overlay	5-50
Left Bind	5-37	D	
Left Panel Display Default	6-6	Р	
License Settings	7-51	P 5-23, 5	-24, 5-26
Limiting Access to Destinations	7-33	Page Margin	
Line Detection	7-9	Page Number	5-41
List/Counter	7-16	Page Number Print Position	6-4, 7-22
Login	4-9	Page Number Type	5-42
Logoff Settings	7-34	Pages 5-41, 5-43, 5-	-51, 5-53
Logout Confirmation Screen Display Setting		Paper	5-5, 5-22
	7-34, 7-35	Paper Separation Adjustment	7-9
Low Power	7-3	Paper Size/Type Counter	7-17
Low Power Mode Settings	7-3	Paper Tray Settings	6-3
		Password	4-9, 7-28
M		Password Copy5	-46, 7-46
Management List		Password for Non-Business Hours	7-6
Manual		Password Rules	7-45
Manual Destination Input	7-46	Pause7-	-29, 7-31
Margin Position	5-36	Photo	•
Max. Allowance Set	7-28, 7-31	Position5	
Maximum Density Adjustment	7-11	Position Setting	•
Maximum Density Compensation	7-10	Power Save	
Measurement Unit Settings		Power Save Key	
Media Adjustment	7-12	Power Save Settings	
Message Display Time	4-13	Prefix/Suffix Automatic Setting	
Meter Count	8-9	Preset Stamp	
Minimal	5-7	Print	
Mirror Image	5-30	Print Counter List	
Mixed Original	5-15	Print Data Capture	
Mode Memory	4-7	Print Jobs During Copy Operation	
NI		Print Lists	
N		Print Position	
Name and Function of Parts		Print without Authentication	
Neg./Pos. Reverse			
Network Function Usage Settings		Print/Fax Output Settings	
Network Settings	7-36	Printer Adjustment	
No Matching Paper in Tray Setting	6-3	Printer Information	
None	5-38	Printer Settings	•
Non-Image Area Erase	5-39	Prior Detection Setting	
Non-Image Area Erase Operation Settings	7-10	Program Jobs	
Number of User Counters Assigned	7-26	Prohibited Functions When Authentication Error	
0		Proof Copy	
0	_	Public User Access	•
Offset		Punch	
OHP Interleave		Punch Horizontal Position Adjustment	
ON (External Server)		Punch Regist Loop Size Adjustment	7-14
ON (MFP)		Q	
One-Touch/User Box Registration			0.0
OpenAPI Authentication Management Setting	s7-52	Quick Setting 1	6-6

Quick Setting 2	6-6	Sleep	7-3
Quick Setting 3	6-6	Sleep Mode Settings	
Quick Setting 4	6-6	Sort5-	11, 5-23, 5-24, 5-26
D.		Sound Setting	4-13
R		Specify Default Tray when APS Off	6-8, 7-37
Recall Header/Footer		Stamp	5-43
Recall Overlay Image		Stamp Repeat	
Receive		Stamp Settings	7-19, 7-50
Register Auth. Info.		Stamp Type/Preset Stamps	5-43
Register Authentication Information		Stamp/Composition	
Register Overlay Image		Staple	
Register Program	4-7	Start	
Registered Overlay		Starting Chapter Number	
Registered Stamp	5-44, 5-48	Starting Page Number	
Release Held Job	5-58	Stop	
Replenish Toner	7-10	Store	
Reset	4-4, 5-49	Synchronize User Authentication & A	
Reset All Counters	7-29, 7-31		
Reset Settings	7-17	System Auto Reset	7-17
Restrict Access to Job Settings	7-7	System Auto Reset Confirmation	
Restrict Fax TX	7-46	System Connection	
Restrict Operation	7-7	System Settings	
Restrict User Access	7-7		
Right	5-38	Т	
Right Bind	5-37	Text	5-19
Rotate Image	4-20	Text Details	5-41, 5-42
RX Display	6-7	Text Enhancement	5-19
C		Text Size	5-43
S		Text/Photo	5-19
Save		Ticket Hold Time Setting	7-27
Save & Print		Time Format	5-41
Save in User Box		Time Settings	7-6
Scan to Authorized Folder Settings		Time Zone	7-5
Scan to Home Settings		Top	5-38
Scan/Fax Settings		Touch Panel Adjustment	4-12
Search by Operation		Transparency	5-21
Search Option Settings		Tray 1	5-5
Secure Print Only	7-46	Tray 2	5-5
Security Details	7-45	Tray 3	5-5
Security Settings	7-43	Tray 4	5-5
Select Keyboard		TX Display	6-7
Select Time for Power Save	7-6		
Select Tray for Insert Sheet	6-8, 7-37	U	
Send	5-57	User Authentication	
Separate Scan	5-13	User Authentication Settings	
Separate Scan Output Method	6-8	User Authentication/Account Track	
Separation	5-32	User Box	
Server Name	4-9	User Box Administrator Setting	7-43
Service/Admin. Information	4-15	User Box Settings	6-6, 7-18
Set Range	5-33	User Counter	7-29
Sharpness	5-31	User Name	4-9, 7-28
Sheet/Cover/Chapter Insert		User Name List	4-9, 7-28
Shift Output Each Job		User Preset Zoom	5-7
Shortcut Key 1		User Registration	7-28
Shortcut Key 2		User Settings	4-6, 6-2
Skip Job Operation Settings		User/Account Common Setting	
		Utility/Counter	

V	
View Finishing4-	20
View Pages4-	
View Status4-	
W	
Watermark5-	50
Watermark Type5-	50
Weekly Timer ON/OFF Settings	<sup>7</sup> -6
Weekly Timer Settings	<b>7-</b> 6
When # of Jobs Reach Maximum7-	26
When AMS Direction is Incorrect6	8-6
With Margin5-	33
Without Margin5-	33
X	
X/Y5	ō-6
Z	
Z-Folded Original5-	15
Zoom4-19, 5-7, 5-	



http://konicaminolta.com